


Mazda 323

Workshop Manual Supplement

JMZ BG93J200



1/92

12/92

Mazda

Mazda 323 Workshop Manual Supplement

FOREWORD

This is a supplement to the workshop manual(s) shown below. This supplement describes service procedures of new or modified mechanical and/or electrical systems. For service procedures and important safety notices not contained in this supplement, please refer to the previous workshop manual.

Workshop Manual:

Form No.1203-10-89F (Vol.1)
1206-10-89F (Vol.2)
1229-10-89L
1275-10-91C

All information in this supplement was the latest available at the time of printing, all alterations related to modifications will be notified by Service Bulletin.

Mazda Motor Corporation
HIROSHIMA, JAPAN

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers (VIN) shown on the following page.

CONTENTS

Title			Section
General Information			GI
Pre-Delivery Inspection and Scheduled Maintenance			A
Engine	B3, B6, BP (SOHC)		B1
	BP (DOHC)		B2
	PN		B3
Lubrication System			D
Cooling System			E
Fuel and Emission Control System	Carburetor		F1
	EGI	Leaded Fuel BP (DOHC)	F2
		Unleaded Fuel BP (DOHC and SOHC) B6 (SOHC)	F3
		Unleaded Fuel B3 (SOHC)	F4
	Diesel		F5
Engine Electrical System			G
Clutch			H
Manual Transaxle	F25M-R		J1
	G25M-R		J2
	G25MX-R		J3
Automatic Transaxle	Electronically Controlled		K1
	Hydraulically Controlled		K2
	Transfer		K3
Propeller Shaft			L
Front and Rear Axles			M
Steering System			N
Braking System			P
Wheels and Tires			Q
Suspension			R
Body			S
Body Electrical System			T
Heater and Air Conditioner System			U
Technical Data			TD
Special Tools			ST
Parts Index			PI
Wiring Diagram	Refer to the form No. 5232-10-92A		Z

This manual explains only the sections marked with shadows (■)

VEHICLE IDENTIFICATION NUMBERS (VIN)

JMZ BG83J200 500001 -

GENERAL INFORMATION

IMPORTANT INFORMATION	GI- 2
BASIC ASSUMPTIONS	GI- 2
SAFETY RISK	GI- 2
POSSIBLE LOSS OF WARRANTY	GI- 2
WARNING ON LUBRICANTS AND GREASES	GI- 2
HOW TO USE THIS MANUAL	GI- 3
PREPARATION	GI- 3
REPAIR PROCEDURE	GI- 3
SYMBOLS	GI- 4
NOTES, CAUTIONS, AND WARNINGS	GI- 4
FUNDAMENTAL PROCEDURES	GI- 4
PROTECTION OF THE VEHICLE	GI- 4
A WORD ABOUT SAFETY	GI- 5
PREPARATION OF TOOLS AND MEASURING EQUIPMENT	GI- 5
SPECIAL TOOLS	GI- 5
REMOVAL OF PARTS	GI- 5
DISASSEMBLY	GI- 5
REASSEMBLY	GI- 6
ADJUSTMENTS	GI- 7
RUBBER PARTS AND TUBING	GI- 7
JACK AND SAFETY STAND POSITIONS	GI- 8
VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS	GI- 8
MAINTENANCE NOTE	GI- 9
SPEEDOMETER TESTER CHECK	GI- 9
BRAKE TESTER CHECK	GI- 9
CHASSIS DYNAMOMETER CHECK	GI-10
WHEEL BALANCER	GI-10
TOWING	GI-10
IDENTIFICATION NUMBER LOCATIONS	GI-12
UNITS	GI-12
ABBREVIATIONS	GI-12
CAUTION	GI-13
INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM	GI-13
PRECAUTIONS TO TAKE WHEN SERVICING AN ELECTRICAL SYSTEM	GI-14
HANDLING CONNECTORS	GI-15
USING ELECTRICAL MEASURING EQUIPMENT	GI-16

IMPORTANT INFORMATION**BASIC ASSUMPTIONS**

This workshop manual assumes that you have certain special tools that are necessary for the safe and efficient performance of service operations on Mazda vehicles and that you know how to use them properly. It also assumes that you are familiar with automobile systems and basic service and repair procedures. You should not attempt to use this manual unless these assumptions are correct and you understand the consequences described below.

SAFETY RISK

This manual contains certain notes, warnings, and other precautionary information that you should carefully read and follow to reduce the risk of personal injury to yourself or others and the risk of improper service that may damage the vehicle or render it unsafe. If there is no such information in regard to any specific service method, this does not mean there is no possibility that personal safety or vehicle safety will be jeopardized by the use of incorrect methods or tools.

POSSIBLE LOSS OF WARRANTY

The manufacturer's warranty on Mazda vehicles and engines can be voided if improper service or repairs are performed by persons other than those at an Authorized Mazda Dealer.

WARNING ON LUBRICANTS AND GREASES

Avoid all prolonged and repeated contact with mineral oils, especially used oils. Used oils contaminated during service (e.g., engine sump oils) are more irritating and more likely to cause serious effects, including skin cancer, in the event of gross and prolonged skin contact.

Wash skin thoroughly after work involving oil.

Protective hand cleaners may be of value provided they can be removed from the skin with water. Do not use gasoline, paraffin, or other solvents to remove oil from the skin.

Lubricants and greases may be slightly irritating to the eyes.

Repeated or prolonged skin contact should be avoided by wearing protective clothing if necessary. Particular care should be taken with used oils and greases containing lead. Do not allow work clothing to be contaminated with oil. Dry clean or launder such clothing at regular intervals.

9MUGIX-002

HOW

PREI

PA

CE

Exam

MA

PRI

SS

43

P

REPA

1. Mc

par

as

2. Exq

illu

3. Par

vic

Exarr

SHOW

EXPE

PART

SHOW

APPLI

POINT

ETC.

SHOW

RELA

PAGE

SERVI

*1. T

*2. T


HOW TO USE THIS MANUAL

PREPARATION

PREPARATION points out the needed **Special Service Tool (SST)** for the service operation that it proceeds. Gather all necessary **SST** before beginning work.

GI


Example:



REPAIR PROCEDURE

1. Most repair operations begin with an overview illustration. It identifies the components, shows how the parts fit together, and visual parts inspections. If a damaged or worn part is found, repair or replace it as necessary.
2. Expendable parts, tightening torques, and symbols for oil, grease, and sealant are shown in the overview illustration.
3. Pages related to service procedures are shown under the illustration. Refer to this information when servicing the related part.

Example:









*1: The numbering (ex. ①) shows service procedure.

*2: Units shown in Nm {kgfm, ftlb} unless otherwise specified

GI HOW TO USE THIS MANUAL/FUNDAMENTAL PROCEDURES

SYMBOLS

There are six symbols indicating oil, grease, and sealant. These symbols show the points of applying such materials during service.

Symbol	Meaning	Kind
	Apply oil	New engine oil or gear oil as appropriate
	Apply brake fluid	Only brake fluid
	Apply automatic transmission fluid	Only ATF
	Apply grease	Appropriate grease
	Apply sealant	Appropriate sealant
	Apply petroleum jelly	Appropriate petroleum jelly

05UGIX-005

Note

- When special oil or grease is needed, this is shown in the illustration.

NOTES, CAUTIONS, AND WARNINGS


As you read through the procedures, you will come across NOTES, CAUTIONS, and WARNINGS. Each one is there for a specific purpose. **NOTES** give you **added information** that will help you to complete a particular procedure. **CAUTIONS** are given to prevent you from making an error that could **damage the vehicle**. **WARNINGS** remind you to be especially careful in those areas where carelessness can cause **personal injury**. The following list contains some general WARNINGS you should follow when you work on a vehicle.

9MUGIX-036

FUNDAMENTAL PROCEDURES

PROTECTION OF THE VEHICLE

Always be sure to cover fenders, seats, and floor areas before starting work.




9MUGIX-037

FUNDAMENTAL PROCEDURES

GI

GI




9MUGIX-003

A WORD ABOUT SAFETY

The following precautions must be followed when jacking up the vehicle.

1. Block the wheels.
2. Use only the specified jacking positions.
3. Support the vehicle with safety stands.


Start the engine only after making certain the engine compartment is clear of tools and people.



9MUGIX-038

PREPARATION OF TOOLS AND MEASURING EQUIPMENT


Be sure that all necessary tools and measuring equipment are available before starting any work.



47U0GX-005

SPECIAL TOOLS


Use special tools when they are required.



47U0GX-006

REMOVAL OF PARTS


While correcting a problem, try also to determine its cause. Begin work only after first learning which parts and subassemblies must be removed and disassembled for replacement or repair.



9MUGIX-039

DISASSEMBLY


If the disassembly procedure is complex, requiring many parts to be disassembled, all parts should be disassembled in a way that will not affect their performance or external appearance and identified so that reassembly can be performed easily and efficiently.



9MUGIX-040

1. Inspection of parts

When removed, each part should be carefully inspected for malfunctioning, deformation, damage, and other problems.




9MUGIX-041

2. Arrangement of parts

All disassembled parts should be carefully arranged for re-assembly.


Be sure to separate or otherwise identify the parts to be replaced from those that will be reused.



47U0GX-010

3. Cleaning parts for reuse

All parts to be reused should be carefully and thoroughly cleaned in the appropriate method.



9MUGIX-004

REASSEMBLY

Standard values, such as torques and certain adjustments, must be strictly observed in the reassembly of all parts.


Refer to STANDARD BOLT AND NUT TIGHTENING TORQUE in Section TD for tightening torques not mentioned in the main text.

If removed, these parts should be replaced with new ones:

- | | |
|----------------|-----------------|
| 1. Oil seals | 2. Gaskets |
| 3. O-rings | 4. Lock washers |
| 5. Cotter pins | 6. Nylon nuts |

Depending on location:

1. Sealant should be applied to gaskets.
2. Oil should be applied to the moving components of parts.
3. Specified oil or grease should be applied at the prescribed locations (such as oil seals) before reassembly.




9MUGIX-042

FUNDAMENTAL PROCEDURES

GI


GI



67U0GX-002

ADJUSTMENTS

Use suitable gauges and/or testers when making adjustments.



9MUGIX-005

RUBBER PARTS AND TUBING

Prevent gasoline or oil from getting on rubber parts or tubing.


GI JACK AND SAFETY STAND POSITIONS/VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

JACK AND SAFETY STAND POSITIONS

FRONT END

Jack position:


At the front crossmember



03UGIX-007

Safety stand positions:

On both sides of the body frame




03UGIX-008

REAR END

Jack position:

At the center of the rear crossmember (2WD)


At the rear differential (4WD)



03UGIX-801

Safety stand positions:

On both sides of the body frame




03UGIX-010

VEHICLE LIFT (2-SUPPORT TYPE) POSITIONS

FRONT END

Frame

Side sills




9MUGIX-010

REAR END

Frame

Side sills



9MUGIX-011

MAINTENANCE NOTE


SPEEDOMETER TESTER CHECK

GI


Caution

- Do not clutch abruptly.
- Do not attempt rabbit starts or accelerate quickly.


13EGIX-302



13EGIX-303



13EGIX-304



13EGIX-305

[Front wheel free-roller method]

1. Set the free roller securely on the floor under the front wheels by matching it to the wheel base and front tread.
2. Place the vehicle softly on the tester and free roller.
3. Start the engine, and engage the clutch softly at a low speed in 2nd gear; then gradually increase the speed.
4. Upon completion of the test, stop the engine by gradually decelerating with soft braking.

[Front wheel jack-up method]

1. Place the rear wheels on the roller
2. Jack up the front wheels and mount on a safety stand.
3. Start the engine, and engage the clutch softly at a low speed in 2nd gear; then gradually increase the speed

Caution


- When using either the front wheel free-roller method or front wheel jack-up method, secure the vehicle to prevent forward and lateral movement by attaching towing hardware (chain or wire) to the front and rear tow hook or tie-down hook.

BRAKE TESTER CHECK


Caution

- To stabilize the drag force of the viscous coupling, conduct the brake test after the speedometer test.


1. Place the wheels to be tested (front or rear) on the roller.
2. Shift into NEUTRAL.
3. Drive the tester roller and check.



13EGIX-306



13EGIX-307



13EGIX-308

CHASSIS DYNAMOMETER CHECK

Caution

- Do not clutch abruptly.
- Do not attempt rabbit starts or accelerate quickly.

1. Remove the propeller shaft.
2. Lock the center differential (2WD).
3. Place the front wheels on the roller.
4. Lock the rear wheels and apply the parking brake.
5. Drive the tester roller and check.
6. Upon completion of the test, gradually decelerate with soft braking and stop the engine.
7. When the test is done, return the differential lock rod to the free condition (4WD) and reinstall the propeller shaft.

WHEEL BALANCER (On-the-car Balance)

1. Jack up all four wheels. Support the wheels to be checked (front or rear) with the wheel balancer sensor stand and the remaining wheels with safety stands.
2. Set the on-the-car balancer. With the center differential in free condition, drive the tires with the engine; then check.





MAINTENANCE NOTE

GI

TOWING


Caution

• Use method ④ to tow vehicles having problems in the steering system or drivetrain.


Towing method	Items to confirm		Remarks
	Parking brake	Transaxle shift position	
① Rope towing 	Released	Neutral	
② Towing with front wheels off ground 	Released	Neutral	Remove propeller shaft
③ Towing by wrecker truck 	Released	Neutral	Remove propeller shaft
④ Towing or hauling with all wheels off ground 	Engaged	Any position	

13EGIX-309

TIE-DOWN HOOKS — FRONT




TIE-DOWN HOOKS — REAR (HATCHBACK)



GI IDENTIFICATION NUMBER LOCATIONS/UNITS/ABBREVIATIONS

IDENTIFICATION NUMBER LOCATIONS



9MUGIX-015

UNITS

N.m {kgfm or kgfcm, ftlbf or inlbf}	Torque
rpm	Revolutions per minute
A	Ampere(s)
V	Volt(s)
Ω	Ohm(s) (resistance)
kPa {kgf/cm ² , psi}	Pressure (usually positive)
mmHg {inHg}	Pressure (usually negative)
W	Watt
Liters {US qt, Imp qt}	Volume
mm {in}	Length

89U0GX-006

ABBREVIATIONS

ABDC	After bottom dead center
A/C	Air conditioner
ACC	Accessories
ATX	Automatic transaxle
ATDC	After top dead center
ATF	Automatic transmission fluid
BAC	Bypass air control
BBDC	Before bottom dead center
BTDC	Before top dead center
CPU	Central processing unit

EC-AT	Electronically-controlled automatic transmission
ECU	Engine control unit
EGI	Electronic gasoline injection
E/L	Electrical load
EX	Exhaust
IC	Integrated circuit
IGN	Ignition
IN	Intake
INT	Intermittent
ISC	Idle speed control
LH	Left hand
M	Motor
MIL	Malfunction indicator lamp
MTX	Manual transaxle
OD	Overdrive
OFF	Switch off
ON	Switch on
PCV	Positive crankcase ventilation
PRC	Pressure regulator control
P/S	Power steering
P/W	Power window
RH	Right hand
SST	Special service tool
ST	Start
SW	Switch
TDC	Top dead center
4WD	4-wheel drive

03UGIX-802

CAI

INST

If a
and
Whe

1. In

2. In

3. E

4. D

AT


CAUTION

INSTALLATION OF MOBILE TWO-WAY RADIO SYSTEM

If a mobile two-way radio system is installed improperly or if a high-powered type is used, the EGI system and other systems may be affected.

When the vehicle is to be equipped with a mobile two-way radio, observe the following precautions:



1. Install the antenna at the farthest point from control units.
2. Install the antenna feeder as far as possible from the control unit harnesses (**at least 30 cm (11.8 in.)**).
3. Ensure that the antenna and feeder are properly adjusted.
4. Do not install a high-powered mobile two-way radio system.



PRECAUTIONS TO TAKE WHEN SERVICING AN ELECTRICAL SYSTEM

- Note the following items when servicing the electrical system.
- Do not alter the wiring or electrical equipment in any way; this may damage the vehicle or cause a fire from short-circuiting a circuit or overloading it.

- The negative (-) battery cable must be removed first and installed last.
- Do not replace with fuses exceeding specified capacity.

**Caution**

- Be sure that the ignition and other switches are off before disconnecting or connecting the battery cables. Failure to do so may damage the semiconductor components



Caution

- Replacing a fuse with one of a larger capacity than designated may damage components or cause a fire.

- Secure harnesses with provided clamps to take up slack.

- Tape areas of the harness that may rub or bump against sharp edges to protect it from damage.

- When mounting components, be sure the harness is not caught or damaged.





**Caution**

- Clamp all harnesses near vibrating components (for example, the engine) to remove slack and to prevent contact resulting from vibration.

- Disconnect heatsensitive parts (for example, relays and ECU) when performing maintenance (such as welding) where temperatures may exceed 80°C [176°F].

- Make sure that the connectors are securely connected when installed.

- Do not handle electrical components roughly or drop them.





























CAUTION

GI

HANDLING CONNECTORS












Caution

- Be sure to grasp the connectors, not the wires, when disconnecting them.

Connector removal		Checking connector contacts	Checking for loose terminals	Replacing terminals
Push type	Remove 			<CPU connector> 1. Raise the rear cover. 2. Lift the tab with a thin piece of metal and remove the terminal. 
				
				
				
				<General connector> Lift the tab with a thin piece of metal and remove the terminal. 
				
				
				
Pull-up type				<Round connectors> 1. Raise the cover. 2. Lift the terminal to remove it. 3. Make sure the terminal is securely mounted in the connector when installing. 
				
				
				
Spring type				<Common ground connectors> 1. Raise the cover. 2. Remove A. 3. Lift the tab with a thin piece of metal and remove the terminal. 
				

13EGIX-3-1

USING ELECTRICAL MEASURING EQUIPMENT

Equipment	Use	Operation	Handling precautions
Test lamp 	Test to find open or shorted circuits	<ul style="list-style-type: none"> Connect the test lamp between the circuit being measured and a ground. The lamp will light if the circuit is energized to the point tested. 	<ul style="list-style-type: none"> Test lamps use 12V 1.4W or 3.4W bulbs or light-emitting diodes (LEDs). Using a large-capacity bulb may damage the C.U.
Jumper wire 	Used to create a temporary circuit	<ul style="list-style-type: none"> Connect the jumper wire between the terminals of a circuit to bypass a switch. 	<ul style="list-style-type: none"> Do not connect the jumper wire from the power source line to ground; this may cause burning or other damage to harnesses or electronic components.
Voltmeter 	Used for measuring the voltage of a circuit to find possible opens or shorts.	<ul style="list-style-type: none"> Connect the positive (+) probe to the point where voltage is to be measured and the negative (-) probe to a ground. 	<ul style="list-style-type: none"> Connect the voltmeter in parallel with the circuit. Set the range to the desired voltage. Use the service hole when measuring the voltage at the diagnosis connector.  <ul style="list-style-type: none"> Tie a thin wire to the positive (+) probe to access narrow terminals.
Ohmmeter 	Used to find opens and shorts in the circuit, to confirm continuity and to measure resistance.	<ul style="list-style-type: none"> Zero the ohmmeter. Verify that voltage is not applied to the circuit. Connect the probes between two points in a circuit. 	<ul style="list-style-type: none"> Zero the meter after switching to the measuring range. Before using the ohmmeter, make sure the ignition switch is off or the negative (-) battery cable is disconnected to prevent burning or otherwise damaging the ohmmeter.
Ammeter 	Used to check alternator output, current supplied to the starter, and dark current within a circuit. Note Dark current is the constant flow of current while the ignition switch is OFF.	<ul style="list-style-type: none"> Connect the ammeter in series with the circuit by touching the positive (+) probe to the power-side terminal and the negative (-) probe to the ground-side terminal. 	<ul style="list-style-type: none"> Set the range to the desired amperage. Connect the ammeter in series with the circuit. The ammeter may be burned or otherwise damaged if it is connected in parallel.

13EGIX-312

A

A

PRE-DELIVERY INSPECTION AND SCHEDULED MAINTENANCE SERVICES

PRE-DELIVERY INSPECTION TABLE	A- 2
SCHEDULED MAINTENANCE SERVICES	A- 3
MAINTENANCE TABLE.....	A- 3
REMARKS	A- 3

13E0AX-301

A PRE-DELIVERY INSPECTION TABLE

PRE-DELIVERY INSPECTION TABLE

EXTERIOR

INSPECT and **ADJUST**, if necessary, the following items to specification:

- ☐ Glass, exterior bright metal and paint for damage
- ☐ Wheel lug nuts
- ☐ Tire pressures
- ☐ All weatherstrips for damage or detachment
- ☐ Operation of bonnet release and lock
- ☐ Operation of trunk lid, hatch and fuel lid opener (if equipped)
- ☐ Door operation and alignment
- ☐ Headlight aiming

INSTALL the following parts:

- ☐ Wheel caps or rings (if equipped)
- ☐ Outside mirror(s)

UNDER BONNET-ENGINE OFF

INSPECT and **ADJUST**, if necessary, the following items to specification:

- ☐ Fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- ☐ Engine oil level
- ☐ Power steering fluid level (if equipped)
- ☐ Brake master cylinder fluid levels
- ☐ Clutch master cylinder fluid levels (if equipped)
- ☐ Windshield washer reservoir fluid level
- ☐ Radiator coolant level and specific gravity
- ☐ Tightness of water hose clamps
- ☐ Tightness of battery terminals, electrolyte level and specific gravity
- ☐ Manual transaxle oil level
- ☐ Drive belt(s) tension
- ☐ Carburetor linkage (choke control, wide open throttle position, etc.) (carburetor model only)
- ☐ Accelerator cable and linkage for free movement
- ☐ Headlight cleaner and fluid level (if equipped)

BLEED air from fuel line (diesel engine only)

CLEAN the spark plugs (except for diesel engine)

INTERIOR

INSTALL the following parts:

- ☐ Rubber stopper for inside rear view mirror (if equipped)
- ☐ Fuse for accessories

CHECK the operation of the following items:

- ☐ Seat controls (sliding and reclining) and head rest
- ☐ Seat belts and warning system
- ☐ Ignition switch and steering lock
- ☐ Power window (if equipped)
- ☐ Door locks including child proof door locks
- ☐ Inhibitor switch (ATX only)
- ☐ All lights including warning and indicator lights
- ☐ Ignition key reminder buzzer (if equipped)

- ☐ Horn, wipers and washers (front and rear, if equipped)
- ☐ Antenna (if equipped)
- ☐ Cigarette lighter and clock (if equipped)
- ☐ Remote control outside mirror (if equipped)
- ☐ Heater, defogger and air conditioner at various mode selections (if equipped)
- ☐ Sunroof (if equipped)

CHECK the following items:

- ☐ Presence of spare fuse
- ☐ Upholstery and interior finish

CHECK and **ADJUST**, if necessary, the following items:

- ☐ Operation and fit of windows
- ☐ Pedal height and free play of brake and clutch pedal
- ☐ Parking brake

UNDER BONNET-ENGINE RUNNING AT OPERATING TEMPERATURE

CHECK the following items:

- ☐ Operation of idle-up system for air conditioner or power steering (if equipped)
- ☐ Automatic transaxle fluid level
- ☐ Initial ignition timing (except diesel engine)
- ☐ Idle speed
- ☐ Operation of throttle position sensor (EGI engine)
- ☐ Operation of cold start device and glow plug warning light (diesel engine only)
- ☐ Operation of dash pot (EGI engine)

ON HOIST

CHECK the following items:

- ☐ Underside fuel, coolant and hydraulic lines, fittings, connections and components for leaks
- ☐ Tires for cuts or bruises
- ☐ Steering linkage, suspension, exhaust system and all underside hardware for looseness or damage

ROAD TEST

CHECK the following items:

- ☐ Brake operation
- ☐ Clutch operation
- ☐ Steering control
- ☐ Operation of meters and gauges
- ☐ Squeaks, rattles or unusual noises
- ☐ Engine general performance
- ☐ Emergency locking retractors

AFTER ROAD TEST

REMOVE the seat and floor mat protective covers

CHECK for the necessary owner information materials, tools and spare tire in vehicle

93E0AX-002

SCHEDULED MAINTENANCE SERVICES

A

SCHEDULED MAINTENANCE SERVICES

MAINTENANCE TABLE

Chart symbols:

- I: Inspect: Visual examination and/or functional measurement of system's operation or performance
A: Adjust: Examination resulting in adjustment or replacement
R: Replace or change
T: Tighten

A

REMARKS

After 80,000 km or 48 months, continue to follow the described maintenance at the recommended intervals.
As for * marked items in this maintenance chart, note the following points.

- *1 Major service interval at 12 months/20,000 km (12,000 miles).
Lubrication service based on distance only 10,000 km (6,000 miles) not time.
- *2 Adjust or inspect alternator and water pump drive belt, and power steering and air conditioner drive belt if equipped.
- *3 Replacement of the timing belt is required at every 100,000 km (60,000 mile). Failure to replace the timing belt may result in damage to the engine.
- *4 If the vehicle is operated under any of the following conditions, it is suggested that the engine oil and oil filter be changed more often than the recommended intervals.
 - a) Driving in dusty conditions.
 - b) Extended periods of idling or low speed operation.
 - c) Driving for a prolonged periods in cold temperatures or regularly driving only short distances.
- *5 If the vehicle is operated in very dusty or sandy areas, inspect and, if necessary, replace more often than at usual recommended intervals.
- *6 This is a full function check of all electrical systems, i.e., all lights, washers (including condition of blades) electric windows, sunroof, horn etc.
- *7 Replace every two years.
If there has been continuous hard driving, mountain driving, or if the brakes are used extensively or the vehicle is operated in extremely humid climates, the brake fluid should be changed annually.

Emission Control and Related Systems

The ignition and fuel systems are vitally important to the proper operation of the emission control and related system, as well as for efficient engine operation. It is strongly recommended that all servicing related to these systems be done by your Authorised Mazda Dealer.

13E0AX-302

A SCHEDULED MAINTENANCE SERVICES (Europe)

Maintenance interval	Maintenance interval	Number of months or km (miles), whichever comes first									
		Months ^{*1}	—	6	12	18	24	30	36	42	48
		Kilometers (Miles)	1,000 (600)	10,000 (6,000)	20,000 (12,000)	30,000 (18,000)	40,000 (24,000)	50,000 (30,000)	60,000 (36,000)	70,000 (42,000)	80,000 (48,000)

Engine

Intake and exhaust manifold nuts (Bolts)	T						T				T
Drive belts ^{*2}	A			A			A		A		A
Engine timing belt ^{*3}	Replace every 100,000 km (60,000 miles)										
Engine oil (Turbo) ^{*4}	Replace every 5,000 km (3,000 miles) or 6 months										
Oil filter ^{*4}			R	R	R	R	R	R	R	R	R
Cooling system (Including coolant level adjustment)				I			I				I
Engine coolant	Replace every 2 years										

Fuel system

Idle speed							A				
Air cleaner element ^{*5}				I			R		I		R
Fuel filter							R				R
Fuel lines and hoses				I			I		I		I

Ignition system

Initial ignition timing				I			I		I		I
Spark plugs				A			A		A		A
Spark plugs (Only for Sweden)	Adjust every 30,000 km (18,000 miles)										

Evaporative emission control system

Throttle sensor				A			A		A		A
Throttle sensor (Only for Sweden)	Adjust every 80,000 km (48,000 miles)										
Evaporative system				I			I		I		I
Evaporative system (Only for Sweden)	Inspect every 80,000 km (48,000 miles)										

Electrical system

Battery electrolyte level and specific gravity	I			I			I		I		I
All Electrical system ^{*6}			I	I			I		I		I
Headlight alignment				A			A		A		A

Chassis and body

Clutch pedal			I	I			I		I		I
Clutch fluid			I	I			I		I		I
Brake lines, hoses and connections			I	I			I		I		I
Brake pedal			I	I			I		I		I
Brake fluid ^{*7}			I	I			R		I		R
Parking brake				A			A		A		A
Power brake unit and hoses				I			I		I		I
Disc brakes				I			I		I		I
Power steering fluid			I	I			I		I		I
Power steering system and hoses				I			I		I		I

13E0AX-303

Main Inter

Chas

Steer

MTX

Rear

Trab

Bolts

Body

Exha

Tires

press

Hing

Unck

Seat

Drive

SCHEDULED MAINTENANCE SERVICES (Europe)

A

<div>Maintenance interval</div> <div>Maintenance interval</div>	Number of months or km (miles), whichever comes first									
	Months ⁻¹	—	6	12	18	24	30	36	42	48
	Kilometers	1,000	10,000	20,000	30,000	40,000	50,000	60,000	70,000	80,000
	(Miles)	(600)	(6,000)	(12,000)	(18,000)	(24,000)	(30,000)	(36,000)	(42,000)	(48,000)

A

Chassis and body (Cont'd)

Steering and front suspension			I			I				I
MTX oil						A				R
Rear axle oil		R	A	A	R	A	A	A	A	R
Transfercarrier oil		R	A	A	R	A	A	A	A	R
Bolts, nuts on chassis and body	T		T		T		T		T	
Body condition (Visual only)	Inspect annually									
Exhaust system heat shields						I				I
Tires (including spare tires) with inflation pressure adjustment			I			I		I		I
Hinges and catches			A			A		A		A
Underside of vehicle			I			I		I		I
Seat belt			I			I		I		I
Driveshaft dust boots			I			I		I		I

13EDAX 304

ENGINE (DOHC)

B2

FEATURES

OUTLINE	B2- 2
OUTLINE OF CONSTRUCTION	B2- 2
SPECIFICATIONS	B2- 2
INTERCHANGEABILITY	B2- 3
PISTON	B2- 4
CONNECTING ROD	B2- 5
CRANKSHAFT PULLEY	B2- 6
EXHAUST VALVE	B2- 7
INSTRUCTION FOR HANDLING METALLIC SODIUM-FILLED EXHAUST VALVE	B2- 8

SERVICE

SUPPLEMENTAL SERVICE INFORMATION	B2- 9
----------------------------------	-------

13E0B2-301

OUTLINE

OUTLINE OF CONSTRUCTION

- The engine is the same as of the previous BP-DOHC Turbo engine. However, some of the components are modified for greater reliability and performance.
- Metallic sodium-filled exhaust valves are adopted.

13E0B2-302

SPECIFICATIONS

Item			Engine	BP DOHC Turbo	
Type				Gasoline, 4-cycle	
Cylinder arrangement and number				In-line, 4 cylinders	
Combustion chamber				Pentroof	
Valve system				DOHC, belt-driven	
Displacement			cm ³ {cu in}	1,839 {112.2}	
Bore and stroke			mm {in}	83.0 × 85.0 {3.27 × 3.35}	
Compression ratio				8.2	
Compression pressure			kPa {kgf/cm ² , psi}-rpm	1,127 {11.5, 164}-300	
Valve timing	IN	Open	BTDC	2°	
		Close	ABDC	51°	
	EX	Open	BBDC	59°	
		Close	ATDC	6°	
Valve clearance		mm {in}		IN	0: Maintenance-free
				EX	0: Maintenance-free
Idle speed*			rpm	800 ± 50	
Ignition timing*			BTDC	10° ± 1°	
Firing order				1—3—4—2	

*...TEN terminal of diagnosis connector grounded.

13E0B2-303

INTERC
The fo
and th
Symbol

Cylinder
block
related

Cranksha
related

Timing
related

Valve
related

Lubricati
system
related

Cooling
system
related

INTERCHANGEABILITY




The following chart shows interchangeability of the main parts of the previous BP DOHC Turbo engine and the new BP DOHC Turbo engine for 4WD models.

Symbols: O Interchangeable X Not interchangeable

Part name		Interchangeability	Remark
Cylinder block related	Cylinder head	O	
	Camshaft oil seal	O	
	Cylinder head bolt	O	
	Cylinder head gasket	O	
	Cylinder head cover	O	
	Cylinder head cover gasket	O	
	Cylinder block	O	
	Main bearing cap	O	
	Main bearing support plate	O	
	Oil pan	X	
	Timing belt cover	O	
	Seal plate	O	
	Front oil seal	O	
	Rear oil seal	O	
Crankshaft related	Crankshaft	O	
	Main bearing	O	
	Thrust bearing	O	
	Connecting rod	X	
	Connecting rod bearing	O	
	Piston	X	
	Piston pin	O	
	Piston ring	Top	
		Second	
	Crankshaft pulley	X	
	Rear cover	O	
	Flywheel	O	
Timing belt related	Timing belt	O	
	Timing belt crank pulley	O	
	Camshaft pulley	O	
	Timing belt tensioner and spring	O	
	Idler	O	
Valve related	Camshaft	O	
	HLA	O	
	Valve	Intake	
		Exhaust	
	Valve spring and seat	Intake	
		Exhaust	
	Valve guide	O	
Lubrication system related	Valve seal	O	
	Oil pump	O	
	Oil pump gasket	O	
	Oil strainer	O	
	Oil strainer gasket	O	
	Oil cooler	X	
	Oil jet	X	
Cooling system related	Oil filter	O	
	Water pump	O	
	Thermostat	O	
	Radiator	O	
	Cooling fan	O	

B2

PISTON




13E0B2-305

- The piston skirt is shortened for reduced weight and friction.
- A cast iron ring carrier is installed in the piston to reduce piston-ring groove wear.
- A cooling channel is incorporated in the body of the piston. The oil jet squirts oil into this cooling channel and the oil absorbs the heat from around the ring lands, reducing piston ring and cylinder wall wear.

CONNECTING ROD


B2




13E0B2-306

- The connecting rod beam is windened for increased strength.
- The connecting rod and cap are marked with white paint for identification.

CRANKSHAFT PULLEY



ALTERNATOR DRIVE PULLEY



98 N (10 kgf, 22 lbf)

Deflection (98 N (10 kgf, 22 lbf))

mm (in)

Drive belt	New	Used	Limit
Alternator	5.5—7.0 {0.22—0.27}	6.0—7.5 {0.24—0.29}	8.0 {0.31}

Tension

N (kgf, lbf)


Drive belt	New	Used	Limit
Alternator	460—660 {46—68, 110—140}	400—580 {40—60, 88—130}	340 {35, 77}

13E0B2-307

- The alternator and water pump pulleys are changed to V-ribbed type for improved performance.
- With the adoption of the V-ribbed belt, the belt adjustment specifications are changed.

EXHAUST VALVE

B2



IDENTIFICATION OF METALLIC SODIUM-FILLED EXHAUST VALVE

13E0B2-308

- Superior heat dissipating metallic sodium-filled exhaust valves are adopted. During engine operation, the metallic sodium inside the valve stem melts. As the valve moves up and down, the sodium splashes around inside the valve and helps to absorb heat from the cylinder head and to transfer it back to the engine coolant through the valve guide. In this way, the combustion chamber temperature is reduced, reducing knocking and improving fuel efficiency.
- Special handling of sodium filled valves is required for personal safety. (See next page.)

B2 INSTRUCTION FOR HANDLING METALLIC SODIUM-FILLED EXHAUST VALVE

INSTRUCTION FOR HANDLING METALLIC SODIUM-FILLED EXHAUST VALVE

Improper handling of metallic sodium can cause severe burns, loss of eye sight, and the production of highly flammable hydrogen gas. Therefore, handle and dispose of such valves carefully.

First aid

- If metallic sodium get into your eyes, quickly flush it out with large amounts of water. See a physician.
- If it gets on your skin, wash it off with plenty of water. See a physician.
- If it catches fire, use a dry powder fire extinguisher or dry sand to put it out. Never use water.

Note

- Do not use the valve as tool.
- Do not drain the metallic sodium from the valve.
- Neutralize the metallic sodium-filled valve before its disposal.

Reference

- "C8" is embossed on the valve head to identify a metallic sodium-filled exhaust valve.

13E0B2-309

Disposal procedure

Follow the procedure below to neutralize the valve.

- (1) Prepare a water-filled bucket (10 Liters {11 US qt, 8.8 Imp qt} or more) and a dry powder fire extinguisher in a well ventilated place.
- (2) Wear safety glasses and gloves.

Note


- If the valve is broken skip Step (3).

- (3) Secure the valve in a vice and, using a hacksaw, cut a few 1.5mm {0.059 in} deep slits 30—90mm {1.2—3.5 in} from the valve stem end.
- (4) Quickly submerge the valve in the bucket of water. (Treat up to eight valve at a time.)


- (5) Leave the valve in the water for about one hour until the bubbles stop. (Stir occasionally with a metal rod for complete reaction.)

Caution


- Do not reach into the solution or let it get on your skin or clothing; burning may result.
- (6) Remove the valve with tongs and dispose of as for a conventional part.
 - (7) Follow local regulations for disposal of the solution.



13E0B2-310



13E0B2-311



13E0B2-312

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with 323 Workshop Manual [Europe, Australia (1229-10-89L)].

Engine

- Removal
- Installation

B2

- The intercooler installation position is changed because the intercooler is enlarged. With this change, the engine can be removed and installed without removing the intercooler. The engine removal / installation procedure is the same as of the previous BP-DOHC Turbo engine.

13E092-313

FUEL AND EMISSION CONTROL SYSTEMS

INDEX..... F3- 2


FEATURES

OUTLINE	F3- 4
OUTLINE OF CONSTRUCTION	F3- 4
SYSTEM DIAGRAM	F3- 5
VACUUM HOSE ROUTING	
DIAGRAM	F3- 6
WIRING DIAGRAM	F3- 7
ECU RELATIONSHIP DIAGRAM	F3- 8
SPECIFICATIONS	F3- 9
TURBOCHARGER CONTROL	F3-10
OUTLINE	F3-10
SYSTEM DIAGRAM	F3-10
WASTEGATE CONTROL	F3-11
FUEL SYSTEM	F3-12
OUTLINE	F3-12
CONTROL SYSTEM	F3-13
STRUCTURAL VIEW	F3-13
PRESSURE REGULATOR	
CONTROL SYSTEM	F3-14

SERVICE

SUPPLEMENTAL SERVICE	
INFORMATION	F3-15
SELF-DIAGNOSIS FUNCTION	F3-16
OUTLINE	F3-16
SERVICE CODE NUMBERS	F3-16
TROUBLESHOOTING GUIDE	F3-19
RELATIONSHIP CHART	F3-19
DIAGNOSTIC INDEX	F3-20
PRECAUTIONS	F3-21
SYMPTOM TROUBLESHOOTING	F3-22
TURBOCHARGER CONTROL	
SYSTEM	F3-37
TURBOCHARGER	F3-37
WASTEGATE SOLENOID VALVE	F3-38
INTERCOOLER	F3-39
FUEL SYSTEM	F3-40
FUEL PUMP	F3-40
FUEL PUMP RESISTOR/RELAY	F3-40
PRESSURE REGULATOR	F3-41
INJECTOR	F3-42
INJECTOR RESISTOR	F3-42
PRESSUR REGULATOR CONTROL	
SYSTEM	F3-43
SOLENOID VALVE (PRESSURE	
REGULATOR CONTROL)	F3-43
CONTROL SYSTEM	F3-44
PREPARATION	F3-44
ENGINE CONTROL UNIT (ECU)	F3-45

INDEX




13E0F3-302

1. Turbocharger
Removal / Installation page F3-37
2. Wastegate solenoid valve
Inspection page F3-38
3. Injector resistor
Inspection page F3-42

4. Intercooler
Removal / Installation page F3-39
5. Engine control unit (ECU)
Inspection page F3-45

1. Inject
Ins
Vo
2. Press
Ins
3. Soler
Ins



F3

13EQF3-303

- | | | | |
|-----------------------------------|------------|------------------------------------|------------|
| 1. Injector | | 4. Solenoid valve (PRC high temp.) | |
| Inspection | page F3-42 | Inspection | page F3-43 |
| Volume test | page F3-42 | 5. Fuel pump resistor/relay | |
| 2. Pressure regulator | | System operation | page F3-40 |
| Inspection | page F3-41 | Inspection | page F3-41 |
| 3. Solenoid valve (PRC low temp.) | | 6. Fuel pump (main) | |
| Inspection | page F3-43 | Inspection | page F3-40 |

OUTLINE

OUTLINE OF CONSTRUCTION

The fuel and emission control system of the new 323 4WD model is basically the same as that of the previous 323 4WD model; however some parts are changed. The changed parts and interchangeable parts are shown below.

13E0F3-304

Changed parts

Components		Contents and purpose	Reference page
INTAKE AIR SYSTEM	Turbocharger	<ul style="list-style-type: none"> Size increased for greater boost pressure Wastegate solenoid valve is located on intake port of turbocharger to make system more compact 	F3-10 F3-37
	Intercooler	Volume increased for improved	F3-10 F3-39
TURBOCHARGER CONTROL SYSTEM	Wastegate solenoid valve	<ul style="list-style-type: none"> Wastegate solenoid valve changed to duty solenoid type for increased engine power and response Wastegate solenoid valve is located on intake port of turbocharger to make system more compact 	F3-11 F3-38
FUEL SYSTEM	Pressure regulator	One-stage operation changed to two-stage operation to improve hot restarting	F3-14 F3-41
	Fuel injector	High-ohmic type change to low-ohmic type with external solenoid resistor for improved fuel supply during high-speed driving	F3-12 F3-42
	Fuel pump resistor	Resistance reduced for surer fuel supply	F3-40
CONTROL SYSTEM	Pressure regulator control system	Two-stage operation used to improve hot restarting	F3-14 F3-43
	Air flow meter	Measures larger amount of air flow increased power Resistance values changed	F3- 9

13E0F3-305

Interchangeable parts

Intake air system

- Air valve
- Air bypass valve
- Air cleaner
- Air cleaner element

Fuel system

- Fuel filter assembly
- Fuel pump (transfer)
- Fuel vapor valve
- Check valve (two-way)


Evaporative system

- Charcoal canister
- Check valve (two-way)


Control system

- Throttle sensor
- Water thermosensor
- Knock sensor and control unit
- Oxygen sensor
- Fuel pump control unit
- Main relay
- Circuit opening relay


13E0F3-306




VACUUM HOSE ROUTING DIAGRAM



WIRING



ECU RELATIONSHIP DIAGRAM



SPE

Item

Idle

Fuel

Max

Tran

Max

Fuel

Type

Pre

Reg

pre

Info

Type

Type

Res

Info

Res

Idle

Type

Res

Sol

Res

Sol

Res

Sol

Res

Wat

Res

Air

Res

Oxy

Res

Fuel

Cap

Air

Elem

Fuel


Spec

* TEN

The 12

SPECIFICATIONS

Item		Engine	BP TURBO	
Idle speed*		rpm	800 ± 50	
Ignition timing*		BTDC	10 ± 1°	
Fuel pump				
Maximum output pressure		kPa (kgf/cm ² , psi)	490—736 (5.0—7.5, 71—110)	
Transfer pump				
Maximum output pressure		kPa (kgf/cm ² , psi)	39 (0.4, 5.7) or higher	
Fuel filter				
Type	Low-pressure side		Nylon element (in fuel pump)	
	High-pressure side		Paper element	
Pressure regulator				
Regulating pressure	Low	kPa (kgf/cm ² , psi)	265—314 (2.7—3.2, 38—45)	
	High	kPa (kgf/cm ² , psi)	304—392 (3.1—4.0, 44—57)	
Injector				
Type		Low-ohmic		
Type of drive		Electromechanical		
Resistance/injector		Ω	1—3 [at 20°C (68°F)]	
Injector resistor				
Resistance/injector		Ω	6 [at 20°C (68°F)]	
Idle-speed control (ISC) valve				
Type		Rotary		
Resistance		Ω	11—13 [at 20°C (68°F)]	
Solenoid valve (purge control)				
Resistance		Ω	23—27 [at 20°C (68°F)]	
Solenoid valve (wastegate)				
Resistance		Ω	35—45 [at 20°C (68°F)]	
Solenoid valve (PRC)				
Resistance	Low temp.	Ω	33—39 [at 20°C (68°F)]	
	High temp.	Ω	33—39 [at 20°C (68°F)]	
Water thermosensor				
Resistance	kΩ	−20°C (−4°F)	14.6—17.8	
		20°C (68°F)	2.21—2.69	
		40°C (104°F)	1.0—1.3	
		80°C (176°F)	0.29—0.35	
Airflow meter				
Resistance	Ω	E ₂ ↔V _s	Fully closed	20—600
			Fully open	20—1,000
		E ₂ ↔V _c		200—400
		E ₂ ↔THAA (intake air thermosensor)	−20°C (−4°F)	13,600—18,400
			20°C (68°F)	2,210—2,690
			60°C (140°F)	493—667
		E ₁ ↔F _c	Fully closed	∞
Fully open	0			
Oxygen sensor (ceramic heater coil)				
Resistance		Ω	Approx. 6 [at 20°C (68°F)]	
Fuel tank				
Capacity		L (US gal, Imp gal)	60 (15.9, 13.2)	
Air cleaner				
Element type		Oil permeated		
Fuel				
Specification		Unleaded premium (RON 95 or higher)		


* TEN terminal of diagnosis connector grounded.
The  mark indicates newly equipped parts.

13E0F3.311

TURBOCHARGER CONTROL


OUTLINE

- The capacity of the air-to-air intercooler is increased to reduce the intake air temperature and to improve engine performance.
- With addition of the improved wastegate control system, the engine's high rpm torque is increased.



13E0F3-312

SYSTEM DIAGRAM




93G0F2-715

WASTEGATE CONTROL

The engine control unit controls the wastegate solenoid valve by duty signals to better control the boost pressure, increasing the engine's power and response.

13E0F3-313

System Diagram




FUEL SYSTEM

OUTLINE

- The pressure regulator has two vacuum ports for its two-stage operation. (Refer to page F3-43.)
- The injectors are changed from high-ohmic type to low-ohmic type for improvement of the supply of fuel during high-speed engine operation.
- To decrease the current in the injectors, an external resistor is equipped and is mounted on the aircleaner housing.


13E0F3-315

Pressur regulator



13E0F3-316


Injector




13E0F3-317

CONTROL SYSTEM

STRUCTURAL VIEW



PRESSURE REGULATOR CONTROL SYSTEM



13E0F3-318

To prevent vaporlock in the fuel system during hot restart idle, a two-stage pressure regulator is adopted to the new 323 4WD.

Low temperature operation: The vacuum to the pressure regulator (A and B ports) is cut (solenoid valve [low temp.] ON), and the fuel injection pressure is increased to 284 kPa (2.90 kgf/cm², 41 psi).

High temperature operation: The vacuum to the pressure regulator (A port) is cut (solenoid valve [high temp.] ON), and the fuel injection pressure is increased to 343 kPa (3.5 kgf/cm², 49 psi).

Condition and operation

Condition			Operation			
Coolant temperature	Intake air temperature	Engine	Solenoid valve (low temp.)	Solenoid valve (high temp.)	Operation time	Operation
Above 90°C [194°F]	40°C [104°F] — 50°C [122°F]	No load	ON	OFF	180s	Low temp.
	Above 50°C [122°F]		OFF	ON	210s	High temp.

13E0F3-319

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison to the Mazda 323 4-Wheel Drive Workshop Manual [1229-10-89L].

Turbocharger

- Removal / Installation

Wastegate solenoid valve

- Inspection

Intercooler

- Removal / Installation

Fuel pump (main)

- Inspection

Fuel pump resistor/relay

- System operation
- Inspection

Injector

- Inspection
- Volume test

Injector resistor

- Inspection

Pressure regulator control system

- Solenoid valve (pressure regulator control)

Engine control unit (ECU)

- Inspection

13E0F3 320











SELF-DIAGNOSIS FUNCTION

OUTLINE

The self-diagnostic function and diagnosis procedure are the same as for the previous 4WD model. However, there is an additional service (malfunction) code (No.35) for the new model.













13E0F3-321

SERVICE CODE NUMBERS

Sensor or subsystem	Condition	Fail-safe	Malfunction display	
			Service code no.	Output signal pattern
NE-signal	No NE-signal	—	02	ON  OFF
G signal	No G signal	Cancels two-group injection	03	ON  OFF
Knock sensor	Open or short circuit	Retards ignition timing 1°	05	ON  OFF
Airflow meter	Open or short circuit	Basic fuel injection amount fixed as for two driving modes (1) Idle switch: ON (2) Idle switch: OFF	08	ON  OFF
Water thermosensor	Open or short circuit	Maintains constant 20°C [68°F] command	09	ON  OFF
Intake air thermosensor	Open or short circuit	Maintains constant 20°C [68°F] command	10	ON  OFF
Throttle sensor	Open or short circuit	Maintains constant command of throttle valve fully open	12	ON  OFF
Atmospheric pressure sensor (in ECU)	Open or short circuit	Maintains constant command of sea level pressure	14	ON  OFF
Oxygen sensor	Sensor output continues less than 0.55V 95 seconds after engine starts (1,500 rpm)	Cancels engine feedback operation	15	ON  OFF
Feedback system	Sensor output continues unchanged 50 seconds after engine exceeds 1,500 rpm	Cancels engine feedback operation	17	ON  OFF

SELF-DIAGNOSIS FUNCTION

F3

Sensor or subsystem	Condition	Fail-safe	Malfunction display	
			Service code no.	Output signal pattern
Fuel pump resistor/relay	Open or short circuit	—	24	ON  OFF 
Solenoid valve (pressure regulator control, low temp.)		—	25	ON  OFF 
Solenoid valve (purge control)		—	26	ON  OFF 
ISC valve		—	34	ON  OFF 
Solenoid valve (pressure regulator control, high temp.)		—	35	ON  OFF 
Solenoid valve (Wastegate)		—	42	ON  OFF 

13E0F3-322

Caution

- If there is more than one failure present, the code numbers will be indicated in numerical order, lowest number first.
- After repairing a failure, turn off the ignition switch, disconnect the negative battery cable, and depress the brake pedal for at least twenty seconds to erase the service code from the ECU memory.


CODE NO.	25 (SOLENOID VALVE — PRESSURE REGULATOR CONTROL) (Low temperature operation)	
STEP	INSPECTION	ACTION
1	Disconnect connector from ECU; is there battery voltage at ECU terminal 2T (G/O) with ignition switch ON?	Yes Check ECU terminal connector for poor connection ⇒ If OK, replace ECU ⇨ page F3-2 ⇒ If not OK, repair or replace connector
		No Go to next step
2	In same condition as in Step 1, is there battery voltage at solenoid valve (PRC low temp.) connector terminal wire (G/O)?	Yes Repair or replace wiring harness (G/O)
		No Go to next step
3	Is solenoid valve (PRC low temp.) OK? ⇨ page F3-43	Yes Check for a short or open circuit in wiring harness (main relay [FUEL INJ relay] — solenoid valve [PRC low temp.])
		No Replace solenoid valve (PRC low temp.)

13E0F3-323

CODE NO.	35 (SOLENOID VALVE — PRESSURE REGULATOR CONTROL) (High temperature operation)	
STEP	INSPECTION	ACTION
1	Disconnect connector from ECU; is there battery voltage at ECU terminal 2Z (G) with ignition switch ON?	Yes Check ECU terminal connector for poor connection ⇒ If OK, replace ECU ⇨ page F3-2 ⇒ If not OK, repair or replace connector
		No Go to next step
2	In same condition as in Step 1, is there battery voltage at solenoid valve (PRC high temp.) connector terminal wire (G)?	Yes Repair or replace wiring harness (G)
		No Go to next step
3	Is solenoid valve (PRC high temp.) OK? ⇨ page F3-43	Yes Check for a short or open circuit in wiring harness (main relay [FUEL INJ relay] — solenoid valve [PRC high temp.])
		No Replace solenoid valve (PRC high temp.)

13E0F3-324

Circuit Diagram



13E0F3-325

TROU
RELAT

INPUT

KNOCK

DIAGN
(TEN TIGNITIO
(STAR)

E/L SIC

P/S PR

A/C SV

NEUTR
SWITCH

STOPPL

ATMOS
SENSO

THROTI

INTAKI

AIRFLC

OXYGE

WATER

DISTR

E/L S
rear

TROUBLESHOOTING GUIDE

RELATIONSHIP CHART

INPUT DEVICE \ OUTPUT DEVICE		INJECTOR		ISC VALVE	SOLENOID VALVE (PURGE CONTROL)	A/C RELAY (A/C CUT-OFF)	CIRCUIT OPENING RELAY	IGNITER (IGNITION TIMING CONTROL)	SOLENOID VALVE (HIGH, LOW TEMP.) (PRESSURE REGULATOR)	WASTEGATE SOLENOID VALVE	FUEL PUMP RESISTOR/RELAY	OVERBOOST WARNING BUZZER	TURBOCHARGE INDICATOR	SELF-DIAGNOSIS CHECKER (MALFUNCTION CODE)	SELF-DIAGNOSIS CHECKER (MONITOR LAMP)
		FUEL INJECTION AMOUNT	FUEL INJECTION TIMING												
KNOCK SENSOR								○						○	
DIAGNOSIS CONNECTOR (TEN TERMINAL)				○				○						○	○
IGNITION SWITCH (START POSITION)		○	○	○		○	○	○	○		○				
E/L SIGNAL*				○											○
P/S PRESSURE SWITCH				○		○									
A/C SWITCH				○		○									○
NEUTRAL AND CLUTCH SWITCHES		○		○	○	○		○	○				○		○
STOPLIGHT SWITCH		○													○
ATMOSPHERIC PRESSURE SENSOR (IN ECU)		○		○	○	○								○	
THROTTLE SENSOR		○	○	○	○	○		○	○					○	○
INTAKE AIR THERMOSENSOR		○		○	○				○					○	
AIRFLOW METER		○	○		○			○			○	○	○	○	
OXYGEN SENSOR		○			○									○	○
WATER THERMOSENSOR		○		○	○		○	○	○					○	
DISTRIBUTOR	G SIGNAL		○											○	
	NE SIGNAL	○	○	○	○	○	○	○		○	○	○	○	○	

13E0F3-326

* E/L SIGNAL: Blower fan control switch second position or higher, electric cooling fan operating, headlights ON, or rear window defroster ON.


DIAGNOSTIC INDEX

No.	TROUBLESHOOTING ITEM		DESCRIPTION	PAGE
1	Will not crank or cranks slowly		Refer to Engine Electrical System	*1
2	Crank normally but will not start	No combustion	Engine cranks at normal speed but shows no sign of firing	F3-22
3		Partial combustion—When engine cold	Engine cranks at normal speed but shows only partial combustion and will not continue to run	*1
4		Partial combustion—After warm-up	Engine cranks at normal speed and shows partial combustion but will not continue running after being hot soaked	F3-25
5	Crank normally but hard to start	Always	Engine cranks at normal speed but requires excessive cranking time before starting	*1
6		When engine cold	Same condition as No. 5 when engine is cold Restarts normally after warm-up	*1
7		After warm-up	Same condition as No. 5 after running and being hot soaked Starts normally when cold	F3-27
8	Rough idle/Engine stalls at idle	Always	Engine stalls or vibrates excessively at idle	F3-29
9		Before warm-up	Engine stalls or vibrates excessively at idle during warm-up	*1
10		After warm-up	Engine runs normally at idle during warm-up but stalls or vibrates excessively after warm-up	F3-31
11		When A/C, P/S, or E/L ON	Engine stalls or vibrates excessively at idle when A/C, P/S, or E/L ON	*1
12	Rough idle/Engine stalls just after starting		Engine stalls or vibrates excessively just after starting (acceleration from idle)	*1
13	High idle speed after warm-up		Idle speed excessively high after warm-up	*1
14	Idle moves up and down/Idle hunts		Engine speeds up and down periodically at idle	F3-33
15	Engine stalls on deceleration		Engine unexpectedly stops running during or after deceleration	F3-35
16	Engine stalls suddenly (intermittent)		Engine intermittently stops running	F3-36
17	Hesitates/Stumbles on acceleration		Flat spot occurs just after accelerator is depressed, or mild jerking occurs during acceleration	*1
18	Surges while cruising		Unexpected change in engine speed that is usually repetitive	*1
19	Lack of power		Performance poor under load when throttle valve is wide open Maximum speed reduced	*2
20	Poor acceleration		Performance poor during acceleration	*2
21	Runs rough during deceleration/Backfire		Engine runs rough during deceleration, and abnormal combustion occurs in exhaust system	*1
22	Knocking		Abnormal combustion accompanied by audible "pinging" noise	*2
23	Fuel odor		Gasoline odor in cabin	*1
24	Exhaust sulfur smell		Exhaust gas has an unusual odor	*1
25	High oil consumption		Oil consumption excessive	*2
26	Poor fuel economy		Fuel economy unsatisfactory	*1
27	A/C does not work		Blower fan operates, but magnetic clutch does not	*1


*1...Refer to 323 Workshop Manual (1203-10-89F).

*2...Refer to 323 4-Wheel Drive Workshop Manual (1229-10-89L).


13E0F3-327



13E0F3-328



13E0F3-329



03U0FX-016

PRECAUTIONS**Fuel Pressure Release and Servicing Fuel System**

Fuel in the fuel system remains under high pressure when the engine is not running.

a) Before disconnecting any fuel line, release the fuel pressure from the fuel system to reduce the possibility of injury or fire as described below.

1. Start the engine.
2. Push the rear seat cushion buttons and remove the cushion.
3. Disconnect the fuel pump connector.
4. After the engine stalls, turn off the ignition switch.
5. Reconnect the fuel pump connector and install the rear seat cushion.

b) Use a rag as protection from fuel spray when disconnecting the fuel hoses.

Plug the hoses after removal.

c) When inspecting the fuel system, use a suitable fuel pressure gauge.

Caution

- Install hose clamps to secure the fuel pressure gauge to the fuel filter and the fuel main hose to prevent fuel leakage.

Pinching Hose

When pinching an air hose or a fuel hose with pliers, wrap the hose with a rag to prevent damage.

SYMPTOM TROUBLESHOOTING

2

CRANKS NORMALLY BUT WILL NOT START (NO COMBUSTION)

DESCRIPTION

- Engine cranks at normal speed but shows no sign of firing
- Battery in normal condition
- Throttle valve not held fully open while cranking (dechoke system not operating)
- Fuel in tank

[TROUBLESHOOTING HINTS]

① No spark







- Ignition control malfunction
- Ignition system component malfunction

② No fuel injection

- Fuel pump inoperative
- Injectors inoperative

③ Low fuel line pressure





④ Low engine compression

STEP	INSPECTION	ACTION
1	Is strong blue spark visible at disconnected high-tension lead?	<p>Yes Go to Step 3</p> <p>No Go to Step 2</p>
2	<p>is "00" displayed on Self-Diagnosis Checker with ignition switch ON?</p> <p>SYSTEM SELECT: 1</p>  <p>TEST SW: SELF TEST</p> <p>SELECT SW: A</p>	<p>Yes Check ignition system (Refer to Troubleshooting "Misfire")  Section G</p> <p>No Service Code No. displayed Check for cause (Refer to specified check sequence)  page F3-16</p> <p>"88" flashes Check ECU terminal 1F voltage  page F3-45</p> <p>Voltage: Battery voltage (ignition switch ON)</p> <p>⇒ If OK, replace ECU  page F3-2</p> <p>⇒ If not OK, check wiring (ECU — Self-Diagnosis Checker)</p>
3	<p>Connect diagnosis connector terminals F/P and GND with jumper wire; is fuel pump operating sound heard with ignition switch ON?</p> <p>DIAGNOSIS CONNECTOR</p>  <p>GND</p> <p>F/P</p>	<p>Yes Does engine start in this condition?</p> <p>⇒ If it does, check circuit-opening relay</p> <p>⇒ If it does not, go to Step 5</p> <p>No Go to next step</p>

STEP	
4	Is (G) gr
5	Is be
6	Is (N) tio
7	Is wil
8	Co Gr rex Fu I

TROUBLESHOOTING GUIDE








F3



STEP	INSPECTION		ACTION
4	Is there battery voltage at fuel pump connector (G/R) with ignition switch ON and F/P terminal grounded in diagnosis connector? 	Yes	Check continuity of fuel pump between terminals G/R and B
		No	Check circuit opening relay
5	Is injector operating sound heard while engine is being cranked?	Yes	Go to Step 8
		No	Go to next step
6	Is there battery voltage at injector connector (No.1 (P), No.2 (R), No.3 (V), No.4 (O)) with ignition switch ON? 	Yes	Check ECU terminals 1N, 2A, 2U, and 2V voltages ☞ page F3-45
		No	Go to next step
7	Is there battery voltage at injector resistor (W/R) with ignition switch ON? 	Yes	Check injector resistor ☞ If OK, check for a short circuit in wiring harness (Injector resistor—Injector) ☞ If not OK, replace injector resistor
		No	Check for open circuit in wiring harness (Main relay (FUEL INJ relay)—Injector resistor)
8	Connect diagnosis connector terminals F/P and GND with jumper wire; is fuel line pressure correct with ignition switch ON? Fuel Line pressure: 265—314 kPa (2.7—3.2 kgf/cm ² , 38—46 psi) 	Yes	Go to next step
		No	Low pressure Check fuel line pressure while pinching fuel return hose ☞ If pressure quickly increases, check pressure regulator ☞ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure High pressure Check if fuel return hose is clogged or restricted ☞ If it is not, replace pressure regulator ☞ If it is, repair or replace it ☞ page F3-3

STEP	INSPECTION	ACTION	
9	Is engine compression correct? <input type="checkbox"/> Section B2 Engine compression: 1059 kPa (10.8 kgf/cm ² , 152 psi)-300 rpm	Yes	Go to next step
		No	Check engine condition <input type="checkbox"/> Section B2 • Worn piston, piston rings or cylinder wall • Damaged cylinder head gasket • Damaged or warped cylinder head • Improper valve seating • Valve sticking in guide
10	Are all spark plugs OK? <input type="checkbox"/> Section G • Wear and carbon buildup • Plug gap • Damage	Yes	Go to next step
		No	Clean, adjust
11	Try known good ECU: does condition improve? <input type="checkbox"/> page F3-2		










13E0F3-330



4	
DESCRIPTION	
TROL.	
① Air	
• F.	
(C)	
• Inj	
STEP	
1	
2	
3	
4	

4 CRANKS NORMALLY BUT WILL NOT START (PARTIAL COMBUSTION) — AFTER WARM-UP			
DESCRIPTION	<ul style="list-style-type: none"> • Engine cranks at normal speed and shows partial combustion but will not continue running after being hot soaked • Battery in normal condition • Engine starts normally when cold 		
	[TROUBLESHOOTING HINTS] ① Air/Fuel mixture too rich <ul style="list-style-type: none"> • Fuel injection control malfunction (correction for coolant temperature) • Injector fuel leakage ② Vaporlock <ul style="list-style-type: none"> • Fuel pressure not held in fuel line after engine is stopped • Pressure regulator control system malfunction 		
STEP	INSPECTION		ACTION
1	Warm up engine to normal operating temperature and stop it. Connect diagnosis connector terminals F/P and GND with jumper wire for 3 minutes with ignition switch ON; does engine start? 	Yes	Change to another brand of fuel
		No	Go to next step
2	Remove vacuum hose from pressure regulator (port A) and plug it; does engine start? 	Yes	Check pressure regulator control system (high temperature operation)  page F3-43
		No	Go to next step
3	Remove both vacuum hoses from pressure regulator (ports A and B) and plug them; does engine start? 	Yes	Check pressure regulator control system (low temperature operation)  page F3-43
		No	Go to next step
4	Connect diagnosis connector terminals F/P and GND with jumper wire; is fuel line pressure correct with ignition switch ON? Fuel line pressure: 265—314 kPa (2.7—3.2 kgf/cm², 38—46 psi) 	Yes	Go to next step
		No	Low pressure Check fuel line pressure while pinching fuel return hose ⇒ If pressure quickly increases, check pressure regulator ⇒ If pressure gradually increases, check fuel line and filter for clogging If hose is not clogged, check fuel pump maximum pressure High pressure Check if fuel return hose is clogged or restricted ⇒ If it is not, replace pressure regulator ⇒ If it is, repair or replace it  page F3-3

STEP	INSPECTION		ACTION
5	In same condition as in Step 2, is fuel line pressure held after ignition switch is turned OFF? Fuel line pressure: More than 147 kPa (1.5 kgf/cm², 21 psi) for 5 min.	Yes	Go to Step 8
		No	Go to Step 7
6	In same condition as in Step 3, is fuel line pressure held after ignition switch is turned OFF? Fuel line pressure: More than 147 kPa (1.5 kgf/cm², 21 psi) for 5 min.	Yes	Go to Step 8
		No	Go to next step
7	Plug both vacuum ports of pressure regulator; is fuel line pressure held after ignition switch is turned OFF? Fuel line pressure: More than 147 kPa (1.5 kgf/cm², 21 psi) for 5 min.	Yes	Replace pressure regulator ⇒ page F3-3
		No	Check fuel pump hold pressure ⇒ If OK, check injector for fuel leakage ⇒ If not OK, replace fuel pump ⇒ page F3-42 ⇒ page F3-3
8	Disconnect water thermosensor connector; does engine start? 	Yes	Check water thermosensor ⇒ If OK, check connections of water thermosensor and ECU 2Q terminal ⇒ If not OK, replace water thermosensor ⇒ page F3-13
		No	Go to next step
9	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON? SYSTEM SELECT: 1 	Yes	Go to next step
		No	Service Code No. displayed Check for cause (Refer to specified check sequence) ⇒ page F3-16
			"88" flashes Check ECU terminal 1F voltage ⇒ page F3-45 Voltage: Battery voltage (Ignition switch ON) ⇒ If OK, replace ECU ⇒ If not OK, check wiring (ECU — Self-Diagnosis Checker) ⇒ page F3-2
10	Are if ECU terminal voltages are OK? (especially 1C, 2D, and 2Q) ⇒ page F3-45	Yes	Go to next step
		No	Check for cause
11	Try known good ECU; does condition improve? ⇒ page F3-2	Yes	Replace ECU ⇒ page F3-2
		No	Change to another brand of fuel

13E0F3-331

7	CRANKS NORMALLY BUT HARD TO START — AFTER WARM-UP		
DESCRIP- TION	<ul style="list-style-type: none"> • Engine cranks at normal speed but requires excessive cranking time before starting after running and being hot soaked • Battery in normal condition • Engine starts normally when cold • Engine runs normally at idle (If idle condition is not OK, refer to "Rough idle" [Nos. 8—12]) 		
[TROUBLESHOOTING HINTS]			
① Air/Fuel mixture too rich		② Vaporlock	
<ul style="list-style-type: none"> • Fuel injection control malfunction • Injector fuel leakage 		<ul style="list-style-type: none"> • Fuel pressure not held in fuel line after engine is stopped • Pressure regulator control system malfunction 	
STEP	INSPECTION		ACTION
1	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON?	Yes	Go to next step
	SYSTEM SELECT: 1 	No	Service Code No. displayed Check for cause (Refer to specified check sequence)  page F3-16 "88" flashes Check ECU terminal 1F voltage  page F3-45 Voltage: Battery voltage (ignition switch ON) ⇨ If OK, replace ECU  page F3-2 ⇨ If not OK, check wiring (ECU — Self-Diagnosis Checker)
2	Remove vacuum hose from pressure regulator (port A) and plug it; does engine start normally?	Yes	Check pressure regulator control system (high temperature operation)  page F3-43
		No	Go to next step
3	Remove both vacuum hoses from pressure regulator (ports A and B) and plug them; does engine start normally?	Yes	Check pressure regulator control system (low temperature operation)  page F3-43
		No	Go to next step
4	Are ECU terminal voltages OK (especially 1C, 2D, 2Q and 2T)?  page F3-45	Yes	Go to next step
		No	Check for cause

STEP	INSPECTION	ACTION	
5	Run engine at idle; is fuel line pressure held after ignition switch is turned OFF? Fuel line pressure: More than 147 kPa (1.5 kgf/cm², 21 psi) for 5 min.  INSTALL CLAMPS	Yes	Go to next step
		No	Plug both vacuum ports of pressure regulator; and check if fuel line pressure is held after ignition switch is turned OFF ⇨ If it is, replace pressure regulator ⇨ page F3-3 ⇨ If it is not, check fuel pump hold pressure If fuel pump is OK, check injectors for fuel leakage ⇨ page F3-42
6	Warm up engine to normal operating temperature and stop it Connect diagnosis connector terminals F/P and GND with jumper wire for 3 minutes with ignition switch ON; does engine start easily?  DIAGNOSIS CONNECTOR GND F/P	Yes	Change to another brand of fuel
		No	Go to next step
7	Try known good ECU; does condition improve? ⇨ page F3-3	Yes	Replace ECU ⇨ page F3-3
		No	Change to another brand of fuel

13E0F3-332

8	DESC
① A	TION
② O	
③ L	
STEP	
1	
2	
3	
4	
5	
6	
7	

8

ROUGH IDLE/ENGINE STALLS AT IDLE — ALWAYS

DESCRIPTION • Engine starts normally but stalls or vibrates excessively at idle in every condition

[TROUBLESHOOTING HINTS]

① Air/Fuel mixture too lean

- Air leakage
- Fuel injection control malfunction
- Low fuel line pressure

② One or more injectors clogged or not operating

③ Low intake air amount









④ Incorrect idle-speed



- Idle-speed misadjustment
- Idle-speed control malfunction

⑤ One or more spark plugs not firing

⑥ Low engine compression


⑦ Airflow meter stuck


STEP	INSPECTION	ACTION
1	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON? SYSTEM SELECT: 1 	<p>Yes Go to next step</p> <p>No Service Code No. displayed Check for cause (Refer to specified check sequence)  page F3-16</p> <p>"88" flashes Check ECU terminal 1F voltage  page F3-45</p> <p>Voltage: Battery voltage (ignition switch ON)</p> <p>⇒ If OK, replace ECU  page F3-2 ⇒ If not OK, check wiring (ECU — Self-Diagnosis Checker)</p>
2	Are ECU terminal voltages OK (especially 2D, 2O, and 2Q)?  page F3-45	<p>Yes Go to next step</p> <p>No Check for cause</p>
3	Disconnect each high-tension lead at idle; does engine speed decrease equally at each cylinder?	<p>Yes Go to Step 9</p> <p>No Go to next step</p>
4	Is injector operating sound heard at idle?	<p>Yes Go to Step 7</p> <p>No Stop engine and go to next step</p>
5	Is there battery voltage at each injector connector (No.1 (P), No.2 (R), No.3 (V), No.4 (O)) with ignition switch ON? INJECTOR CONNECTOR 	<p>Yes Check if injector resistance is OK  page F3-41</p> <p>Resistance: Approx. 2.11Ω (at 20°C (68°F))</p> <p>⇒ If it is, check wiring (ECU — Injector) ⇒ If it is not, replace injector</p> <p>No Go to next step</p>
6	Is there battery voltage at injector resistor (W/R) with ignition switch ON?	<p>Yes Check injector resistor</p> <p>⇒ If OK, check for short circuit in wiring (Injector resistor—Injector) ⇒ If not OK, replace injector resistor</p> <p>No Check for open circuit in wiring (Main relay (FUEL INJ relay)—Injector resistor)</p>
7	Is strong blue spark visible at each disconnected high-tension lead? AIRFLOW METER 	<p>Yes Go to next step</p> <p>No Check high-tension lead</p> <p>⇒ If OK, check distributor cap and rotor ⇒ If not OK, replace high-tension lead</p>

STEP	INSPECTION	ACTION	
8	Are spark plugs OK? <input checked="" type="checkbox"/> Section G • Wear and carbon build up • Plug gap • Damage	Yes	Check for correct engine compression ⇒ If OK, replace injector ⇒ If not OK, check for cause <input checked="" type="checkbox"/> Section B2
		No	Clean, adjust
9	Is fuel line pressure correct at idle? Fuel line pressure: 265—314 kPa [2.7—3.2 kgf/cm², 38—48 psi] (Two vacuum hoses to pressure regulator disconnected) 304—392 kPa [3.1—4.0 kgf/cm², 44—57 psi] (Upper vacuum hose to pressure regulator disconnected) INSTALL CLAMPS 	Yes	Go to next step
		No	Low pressure Check fuel line pressure while pinching fuel return hose ⇒ If pressure quickly increases, check pressure regulator ⇒ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure
10	Does airflow meter move smoothly from fully closed to fully open when it is manually inspected? 	Yes	Go to next step
		No	Repair or replace
11	Is there air leakage at intake air system components?	Yes	Repair or replace
		No	Go to next step
12	Is engine compression correct? <input checked="" type="checkbox"/> Section B2 Engine compression: 1059 kPa [10.8 kgf/cm², 152 psi]-300 rpm	Yes	Go to next step
		No	Check for cause <input checked="" type="checkbox"/> Section B2
13	Connect System Selector to diagnosis connector and set Test Switch to SELF TEST; is ignition timing correct at Idle after warm-up? Ignition timing (BTDC): 10 ± 1°	Yes	Try known good ECU; does condition improve? <input checked="" type="checkbox"/> page F3-3
		No	Adjust ignition timing

13E0F3-333

10	DESCR TION
1	① Idle ② Air • A • L
STEP	
1	
2	
3	
4	
5	

10	ROUGH IDLE/ENGINE STALLS AT IDLE — AFTER WARM-UP		
DESCRIPTION	• Engine runs normally at idle during warm-up but engine stalls or vibrates excessively after warm		
[TROUBLESHOOTING HINTS]			
<div>① Idle-speed control system malfunction</div> <div>② Air/Fuel mixture too lean<ul style="list-style-type: none">• Air leakage• Low fuel line pressure</div> <div>③ Air/Fuel mixture too rich<ul style="list-style-type: none">• Fuel injection control malfunction (correction for coolant temperature)</div> <div>④ Poor ignition</div> <div>⑤ Low engine compression</div>			
STEP	INSPECTION		ACTION
1	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON?	Yes	Go to next step
	<div>SYSTEM SELECT: 1</div> <div></div> <div>TEST SW: SELF TEST</div> <div>SELECT SW: A</div>	No	<div>Service Code No. displayed Check for cause (Refer to specified check sequence) ☞ page F3-16</div> <div>"88" flashes Check ECU terminal 1F voltage ☞ page F3-45</div> <div>Voltage: Battery voltage (ignition switch ON) ⇒ If OK, replace ECU ☞ page F3-3 ⇒ If not OK, check wiring (ECU — Self-Diagnosis Checker)</div>
2	Are ECU terminal voltages OK (especially 2D, 2O, and 2Q)? ☞ page F3-45	Yes	Go to next step
		No	Check for cause
3	Disconnect each high-tension lead at idle; does engine speed decrease equally at each cylinder?	Yes	Go to next step
		No	Go to Step 9
4	Is intake manifold vacuum correct at idle? Vacuum: More than 450 mmHg (17.7 inHg)	Yes	Go to next step
		No	Check for air leakage of intake air system components
5	Is air cleaner element clean?	Yes	Go to next step
		No	Replace air cleaner element

STEP	INSPECTION	ACTION	
6	Is fuel line pressure correct at idle? Fuel line pressure: 265—314 kPa (2.7—3.2 kgf/cm², 38—46 psi) (Two vacuums hose to pressure regulator disconnected) 304—392 kPa (3.1—4.0 kgf/cm², 44—57 psi) (Upper vacuum hose to pressure regulator disconnected) INSTALL CLAMPS 	Yes	Go to next step
		No	Low pressure Check fuel line pressure while pinching fuel return hose ⇒ If pressure quickly increases, check pressure regulator ⇒ If pressure gradually increases, check for clogging between fuel pump and pressure regulator If hose is not clogged, check fuel pump maximum pressure
7	Connect System Selector to diagnosis connector and set Test Switch to SELF TEST; is ignition timing at idle correct after warm-up? Ignition timing (BTDC): 10 ± 1°	Yes	Go to next step
		No	Adjust ignition system
8	Disconnect water thermosensor connector; does engine condition improve?	Yes	Replace water thermosensor
		No	Try known good ECU: does condition improve? ☞ page F3-13
9	Is injector operating sound heard at idle?	Yes	Go to next step
		No	Check if injector resistance is OK ☞ page F3-42 Resistance: Approx. 2.11Ω (at 20°C (68°F)) ⇒ If it is, check wiring (ECU — Injector) ⇒ If it is not, replace injector
10	Is engine compression correct? ☞ Section G Engine compression: 1059 kPa (10.8 kgf/cm², 152 psi)-300 rpm	Yes	Go to next step
		No	Check engine ☞ Section B2
11	Is strong blue spark visible at each disconnected high-tension lead?	Yes	Go to next step
		No	Check high-tension lead ☞ Section G ⇒ If OK, check distributor cap and rotor ⇒ If not OK, replace high-tension lead
12	Are spark plugs OK? ☞ Section G • Wear and carbon build up • Plug gap • Damage	Yes	Try known good ECU: does condition improve? ☞ page F3-3
		No	Clean, adjust

13E0F3-334

14	
DESCRIPTION	
(TROU	
① Idle	
② Air I	
③ Fuel	
• Pro	
④ Pow	
STEP	
1	
2	Is
3	In
4	Is
5	Ar
6	Cx
	ar
	tin
	lg



14









IDLE MOVES UP AND DOWN/IDLE HUNTS

DESCRIPTION • Engine speeds up and down periodically at idle

[TROUBLESHOOTING HINTS]







- ① Idle switch (in throttle sensor) OFF at idle
- ② Air leakage
- ③ Fuel injection amount inconstant
 - Poor contact point inside airflow meter
- ④ Poor ignition

STEP	INSPECTION		ACTION
1	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON? SYSTEM SELECT: 1 	Yes	Go to next step
		No	Service Code No. displayed Check for cause (Refer to specified check sequence) ➤ page F3-16
			"88" flashes Check ECU terminal 1F voltage ➤ page F3-45 Voltage: Battery voltage (ignition switch ON) ➤ If OK, replace ECU ➤ page F3-3 ➤ If not OK, check wiring (ECU — Self-Diagnosis Checker)
2	Is intake manifold vacuum correct at idle? Intake manifold vacuum: More than 450 mmHg (17.7 inHg)	Yes	Go to next step
		No	Low vacuum Check for air leakage at intake air system
3	Is air cleaner element clean?	Yes	Go to next step
		No	Replace air cleaner element
4	Disconnect each high-tension lead at idle; does engine speed decrease equally at each cylinder?	Yes	Go to next step
		No	Go to Step 8
5	Are ECU terminal voltages OK? (especially 2D, 2Q, 2O) ➤ page F3-45	Yes	Go to next step
		No	Check for cause
6	Connect System Selector to diagnosis connector and set Test Switch to SELF TEST; is ignition timing at idle correct after warm-up? Ignition timing (BTDC): 10 ± 1° 	Yes	Go to next step
		No	Adjust ignition timing

STEP	INSPECTION	ACTION	
7	Is airflow meter OK?	Yes	Go to Step 14
		No	Replace airflow meter
8	Is injector operating sound heard at idle?	Yes	Go to Step 11
		No	Step engine and go to next step
9	Is there battery voltage at injector connector (No. 1 (P), No. 2 (R), No. 3 (V), No. 4 (O)) with ignition switch ON? 	Yes	Is injector resistance OK?  page F3-42 Resistance: Approx. 2.11Ω (at 20°C [68°F]) ⇒ If it is, check wiring (ECU — Injector) ⇒ If it is not, replace injector
		No	Go to next step
10	Is there battery voltage at injector resistor (W/R) wire with ignition switch ON? 	Yes	Check injector resistor ⇒ If OK, check for short circuit in wiring (Injector resistor—Injector) ⇒ If not OK, replace injector resistor
		No	Check for open circuit in wiring (Main relay (FUEL INJ relay)—Injector resistor)
11	Is there strong blue spark visible at each disconnected high-tension lead? 	Yes	Go to next step
		No	Check high-tension lead ⇒ If OK, check distributor cap and rotor ⇒ If not OK, replace high-tension lead
12	Are spark plugs OK?  Section G • Wear and carbon build up • Plug gap • Damage	Yes	Is engine compression correct?  Section B2 Engine compression: 1059 kPa [10.8 kgf/cm², 152 psi]-300 rpm ⇒ If OK, go to next step ⇒ If not OK, check for cause  Section B2
		No	Clean, adjust
13	Check for injector leakage	Yes	Replace injector
		No	Go to next step
14	Try known good ECU; does condition improve?  page F3-45		


13E0F3-335

15	
DESCRIP- TION	
[TROUBLE Engine sp ① Idle-sp ② Fuel-cu	
STEP	
1	Is id idle
2	Is th with SYS
3	Does ignit coil SYS
4	Are (esp
5	Che • I • I • I • I • I • I • I

15		ENGINE STALLS ON DECELERATION	
DESCRIPTION		<ul style="list-style-type: none"> • Engine unexpectedly stops running during or after deceleration • Idle condition normal 	
[TROUBLESHOOTING HINTS]		Engine speed drops too much when releasing accelerator ① Idle-speed misadjustment ② Fuel-cut control malfunction ③ Loose connector disconnected by force of deceleration	
STEP	INSPECTION	ACTION	
1	Is idle condition normal? Idle speed: 800 ± 50 rpm (In neutral)	Yes	Go to next step
		No	Adjust or perform Troubleshooting, Nos. 8—11 "ROUGH IDLE" (Refer to Workshop Manual (1203-10-89F))
2	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON? SYSTEM SELECT: 1 	Yes	Go to next step
		No	Service Code No. displayed Check for cause (Refer to specified check sequence)  page F3-16
		No	"88" flashes Check ECU terminal 1F voltage  page F3-45 Voltage: Battery voltage (ignition switch ON) ⇒ If OK, replace ECU  page F3-3 ⇒ If not OK, check wiring (ECU — Self-Diagnosis Checker)
3	Does Self-Diagnosis Checker Monitor Lamp with ignition switch ON show that switches operate correctly? SYSTEM SELECT: 1 	Yes	Go to next step
		No	Lamp not ON or OFF with specified switch Check for cause (Refer to specified check sequence)
4	Are ECU terminal voltages OK? (especially 1V, 2D, 2O, 2U, 2V, and 2Q)  page F3-45	Yes	Go to next step
		No	Check for cause
5	Check for poor connection of following parts <ul style="list-style-type: none"> • Ignition coil • Igniter • Distributor • High-tension lead • Injector • Injector resistor • Circuit-opening relay • ECU 	Yes	Repair or replace
		No	Go to next step

STEP	INSPECTION	ACTION
6	Is dashpot correctly adjusted?	Yes Go to next step
	Dashpot set speed: Approx. 3,500 rpm No	Adjust dashpot
7	Try known good ECU; does condition improve? ☞ page F3-3	

13E0F3-336

16		ENGINE STALLS SUDDENLY (INTERMITTENT)	
DESCRIP- TION		<ul style="list-style-type: none">• Engine intermittently stops running• Before stalling, engine condition is OK	
[TROUBLESHOOTING HINTS] ① Intermittently no spark or no fuel injection caused by vehicle vibration, acceleration, or deceleration • Poor connection in wiring harness			
STEP	INSPECTION	ACTION	
1	Is "00" displayed on Self-Diagnosis Checker with ignition switch ON?	Yes	Go to next step
		No	Service Code No. displayed Check for cause (Refer to specified check sequence) ☞ page F3-16 Note • When checking wiring harness and connectors, tap, move, and wiggle suspect sensor and/or harness to recreate problem "88" flashes Check ECU terminal 1F voltage ☞ page F3-45 Voltage: Battery voltage (ignition switch ON) ⇒ If OK, replace ECU ⇒ If not OK, check wiring (ECU — Self-Diagnosis Checker)
2	Check for poor connection of following parts • Ignition coil • Igniter • Distributor • High-tension lead • Injector • Injector resistor • Circuit-opening relay • ECU	Yes	Repair or replace
		No	Go to next step
3	Are ECU terminal voltages OK? (especially 1B, 2A, 2B, and 2C) ☞ page F3-45 Note • When checking voltages, tap, move, and wiggle harness and connector to recreate problem	Yes	Go to Troubleshooting No. 2 "CRANKS NORMALLY BUT WILL NOT START (NO COMBUSTION)" ☞ page F3-20
		No	Check for cause

13E0F3-337

TU
TUR
RénC.
•1. Di
2. Ra
3. Re
4. Dr
5. Re
6. Ins

7.8-1


TURBOCHARGER CONTROL SYSTEM

TURBOCHARGER Removal / Installation

Caution

- Be careful of the following points after turbocharger removal.
 - Do not carry the turbocharger by the actuator rod or actuator hose.
 - Do not drop the turbocharger.
 - Set the turbocharger down with the turbine shaft horizontal.
 - Cover the intake, exhaust, and oil passages to prevent dirt or other material from entering the turbocharger.
 - Use the specified new studs when installing the turbocharger.

1. Disconnect the negative battery cable.
2. Raise the vehicle and support it on safety stands.
3. Remove the undercover.
4. Drain the engine coolant.
5. Remove in the order shown in the figure, referring to **Removal Note**.
6. Install in the reverse order of removal, referring to **Installation Note**.




1. Radiator
2. Insulator
3. Air hose, and air pipe
4. Oxygen sensor connector
5. Front exhaust pipe

6. Water hose
 7. Oil pipe
 8. Exhaust manifold and turbocharger
- Removal Note below
Installation Note below

13E0F3-339

INTER
Remo


1. Rem
2. Rem
3. Insta



13E0F3-340

Removal Note**Exhaust manifold and turbocharger**

1. Remove the exhaust manifold and the turbocharger as an assembly.
2. Separate the turbocharger assembly from the exhaust manifold.



13E0F3-341

Installation Note**Exhaust manifold and turbocharger**

1. Remove all old gaskets and sealant.
2. Install new gaskets.
3. Supply **25 cc (1.5 cu in)** of oil through the oil passage of the turbocharger.
4. Mount the turbocharger assembly to the exhaust manifold.
5. Install the turbocharger and the exhaust manifold assembly to the engine and loosely tighten the nuts.
6. Install the bracket and the front exhaust pipe, and tighten the turbocharger mounting nuts.

WASTEGATE SOLENOID VALVE**Caution**


- The wastegate solenoid valve must be replaced with the turbocharger, it cannot be replaced by itself.

Inspection

1. Disconnect the connector.
2. Measure the resistance of the solenoid valve.

Resistance: 35—45 Ω (at 20°C (68°F))

3. If not as specified, replace the wastegate solenoid valve and turbocharger as an assembly, if necessary.
(Refer to page F3-37.)




13E0F3-342

INTERCOOLER


Removal / Installation

1. Remove the front bumper. (Refer to Section S.)
2. Remove in the order shown in the figure.
3. Install in the reverse order of removal.




1. Air hose


2. Intercooler



13E0F3-344



13E0F3-345



13E0F3-346

FUEL SYSTEM

FUEL PUMP

Inspection

Fuel pump operation

1. Connect the diagnosis connector F/P and GND terminals by using a jumper wire.
2. Remove the fuel filler cap.
3. Turn ON the ignition switch.
4. Listen at the filler inlet for the operational sound of the fuel pump.
5. Install the fuel filler cap.
6. If no sound is heard, measure the voltage between the fuel pump connector (G/R) to a ground.

Voltage: Battery voltage

7. If not as specified, check the circuit opening relay and circuit.
8. If as specified, check for continuity between fuel pump connector (G/R) and (B).
9. If there is continuity, replace the fuel pump.
10. If there is no continuity, repair the ground circuit.

FUEL PUMP RESISTOR/RELAY

System Operation


1. Remove the rear seat cushion.
2. Measure the voltage at the fuel pump connector terminal A (G/R).

Voltage


Cranking	Battery voltage
Ignition switch ON	0V

3. If not as specified, perform the following inspections, and repair or replace as necessary.


- Fuel pump resistor/relay resistance (Refer to page F3-41.)
- ECU 11 terminal voltage (Refer to page F3-45.)
- Wiring harness and connector




13E0F3-347



13E0F3-348



13E0F3-364



13E0F3-348

Inspection

1. Disconnect the resistor/relay connector.
2. Ground the fuel pump resistor relay terminal D.
3. Apply battery voltage and check for continuity as shown.

Terminal C	Continuity between A and B
Battery voltage applied	No
0V	Yes

4. Measure the resistance between terminals E and F.

Resistance : 0.38—0.42Ω (at 20°C (68°F))

PRESSURE REGULATOR**Inspection****Fuel line pressure****Warning**

- Before performing the following operation, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page F3-21.)

1. Disconnect the negative battery terminal.
2. Connect a fuel pressure gauge between the fuel filter and the fuel main hose. (Install clamps as shown.)
3. Connect the negative battery terminal.
4. Start the engine and run it at idle.
5. Measure the fuel line pressure.

Fuel line pressure:

206—255 kPa (2.1—2.6 kgf/cm², 30—37 psi)

6. Disconnect the upper vacuum hose from the pressure regulator and measure the fuel line pressure.

Fuel line pressure:

304—392 kPa (3.1—4.0 kgf/cm², 44—57 psi)

INJECTOR**Inspection****Injector resistance**

1. Disconnect the injector harness.
2. Measure resistance of the injector.

Resistance: 1—3 Ω (at 20°C (68°F))

3. If not as specified, replace the injector.

Volume Test

1. Remove the injectors and delivery pipe assembly with the connectors connected.
2. Affix the injectors to the delivery pipe by using wire.

Warning

- Be extremely careful when working with fuel. Always work away from sparks and open flames.

Caution

- Affix the injectors firmly to the delivery pipe so that they do not move.

3. Turn the ignition switch ON and ground the F/P terminal of the diagnosis connector.
4. Test the individual injectors by following the procedure outlined in the chart below.

Test injector no.	Disconnect injector connector no.	Ground ECU terminal
1	3	2U
2	4	2V
3	1	2U
4	2	2V

5. Check the injection volume by using a graduated container.

Injection volume:

105—151 cc (6.40—9.22 cu in)/15 sec.


6. If the injection volume is not as specified, replace the injector.

INJECTOR RESISTOR**Inspection**


1. Disconnect the injector harness.
2. Measure resistance of the injector resistor.

Injector	Measured terminals	Resistance
No.1	①—⑤	6 Ω (at 20°C (68°F))
No.2	②—⑤	
No.3	③—⑤	
No.4	④—⑤	


3. If not as specified, replace the injector resistor.




13E0F3-349



13E0F3-350



13E0F3-351



13E0F3-352

SOLENOID
(PRC LOW)HIGH
TENSION
LEADSOLENOID
(PRC HIGH)

BATTERY


PRESSURE REGULATOR CONTROL SYSTEM

SOLENOID VALVE (PRESSURE REGULATOR CONTROL)


Inspection

On-vehicle


1. Start the engine and run it at idle (cold engine).
2. Disconnect the vacuum hoses from the pressure regulator, and verify that vacuum is felt at each hose.
3. Ground the solenoid valve terminal wire (G/O...low temp. and G...high temp.) by using a jumper wire, and verify that no vacuum is felt.
4. If vacuum is not as specified, check the solenoid valve.




13E0F3-353




13E0F3-354



13E0F3-355



13E0F3-356






13E0F3-357

Solenoid Valve (high and low temp.)



1. Disconnect the vacuum hose from the solenoid valve and the vacuum pipe.
2. Blow through the solenoid valve from port A.
3. Verify that air flows from port B.
4. Disconnect the solenoid valve connector.
5. Connect **battery voltage** and a ground to the terminals of the solenoid valve.
6. Blow through the solenoid valve from port A.
7. Verify that air flows from the valve air filter.
8. If not as specified, replace the solenoid valve.


CONTROL SYSTEM

PREPARATION
SST


49 9200 162 Engine Signal Monitor		For inspection of ECU	49 G018 903 Adapter harness		For inspection of ECU
49 G018 904 Sheet		For inspection of ECU			

13E0F3-357






93G0F3-787



13E0F3-358



13E0F3-359

ENGINE CONTROL UNIT (ECU)**Inspection**

1. Disconnect the ECU connectors.
2. Connect the **SSTs** (Engine Signal Monitor and Adapter) to the ECU as shown.
3. Place the **SST** (Sheet) on the Engine Signal Monitor.
4. Measure the voltage at each terminal.
(Refer to pages F3-46 to F3-53.)
5. If any ECU terminal voltage is incorrect, check the related input or output devices and wiring. If no problem is found, replace the ECU. (Refer to page F3-2.)

Caution

- Never apply voltage to terminals A and B of the SST.

Terminal voltage
Reference date

V_B: Battery voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
1A	—	—	Battery	Constant	V _B	For backup
1B	○		Main relay (FUEL INJ relay)	Ignition switch OFF	0V	—
				ON	V _B	
1C	○		Ignition switch (START)	While cranking	Approx. 10V	—
				Ignition switch ON	0V	
1D		○	Self-Diagnosis Checker (monitor lamp)	Test switch at SELF TEST Lamp illuminated for 3 sec. after ignition switch OFF→ON	Approx. 5V	With Self- Diagnosis Check- er and System Selector
				Lamp not illuminated after 3 sec.	V _B	
				Test switch at O ₂ MONITOR with engine idling Monitor lamp illuminated	Approx. 5V	
				Test switch at O ₂ MONITOR with engine idling Monitor lamp not illuminated	V _B	
1E	—	—	—	—	—	—
1F		○	Self-Diagnosis Checker (service code)	Buzzer sounded for 3 sec. after ignition switch OFF→ON	Below 2.5V	•With Self- Diagnosis Checker and System Selector •With System Selector test switch at SELF TEST
				Buzzer not sounded after 3 sec.	V _B	
				Buzzer sounded	Below 2.5V	
				Buzzer not sounded	V _B	
1G		○	Igniter	Ignition switch ON	0V	—
				Idle	Approx. 0.2V	
1H		○	Solenoid valve (wastegate)	Ignition switch ON	V _B	—
				Idle	Approx. 2V	
1I		○	Fuel pump resistor/relay	While cranking	Approx. 10V	—
				Idle	Below 1.5V	
1J		○	A/C relay	Ignition switch ON	V _B	—
				A/C switch ON at idle	Below 2.5V	
				A/C switch OFF at idle	V _B	
1K	○		Diagnosis connector (TEN terminal)	System Selector test switch at O ₂ MONITOR	V _B	—
				System Selector test switch at SELF TEST	Below 1.0V	
1L	—	—	—	—	—	—
1M	—	—	—	—	—	—

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

Va: Battery voltage

Incorrect voltage		Possible cause
Always 0V		<ul style="list-style-type: none"> ROOM 10A fuse burned Open circuit in wiring from ROOM 10A fuse to ECU terminal 1A
Always 0V		<ul style="list-style-type: none"> Main relay malfunction Open or short circuit in wiring from main relay to ECU terminal 1B
Always 0V (starter turns)		<ul style="list-style-type: none"> Open or short circuit in wiring from ignition switch to ECU terminal 1C
Always 0V		<ul style="list-style-type: none"> Main relay (FUEL INJ relay) malfunction Open circuit in wiring from main relay to diagnosis connector terminal +B Open or short circuit in wiring from diagnosis connector terminal MEN to ECU terminal 1D
Always VB		<ul style="list-style-type: none"> Poor connection at ECU connector ECU malfunction
Always approx. 5V		<ul style="list-style-type: none"> ECU malfunction
—		—
Always below 2.5V	No display on Self-Diagnosis Checker	<ul style="list-style-type: none"> Main relay (FUEL INJ relay) malfunction Open circuit in wiring from main relay to diagnosis connector terminal +B
	"88" displayed and buzzer sounds continuously	<ul style="list-style-type: none"> Open or short circuit in wiring from diagnosis connector terminal FEN to ECU terminal 1F
Always VB		<ul style="list-style-type: none"> Poor connection at ECU connector ECU malfunction
Always 0V		<ul style="list-style-type: none"> Short circuit in wiring from igniter to ECU terminal 1G
Always 0V or VB		<ul style="list-style-type: none"> Refer to Code No.42 Troubleshooting (Refer to 323 4-Wheel Drive Workshop Manual (1229-10-89L))
Always VB		<ul style="list-style-type: none"> Fuel pump resistor/relay malfunction
Always 0V		<ul style="list-style-type: none"> Open or short circuit in wiring from ECU terminal 1I to fuel pump resistor/relay
Always below 2.5V	A/C does not operate	<ul style="list-style-type: none"> A/C relay malfunction Open circuit in wiring from ignition switch to A/C relay Open circuit in wiring from A/C relay to ECU terminal 1J
	A/C switch OFF but A/C operates	<ul style="list-style-type: none"> Short circuit in wiring from A/C relay to ECU terminal 1J ECU malfunction
Always VB		<ul style="list-style-type: none"> Poor connection at ECU connector ECU malfunction
Always below 1.0V		<ul style="list-style-type: none"> Short circuit in wiring from diagnosis connector terminal TEN to ECU terminal 1K
Always VB		<ul style="list-style-type: none"> Open circuit in wiring from diagnosis connector terminal TEN to ECU terminal 1K Open circuit in wiring from diagnosis connector terminal GND to ground
—		—
—		—

13E0F3-360

V_B: Battery voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
1N	○		Throttle sensor (idle switch)	Accelerator pedal released	Below 1.0V	Ignition switch ON
				Accelerator pedal depressed	V _B	
1O	○		Foglight relay	Foglight switch ON	V _B	—
				Foglight switch OFF	0V	
1P	○		P/S pressure switch	Ignition switch ON	V _B	—
				P/S pressure switch ON at idle	Below 1.0V	
				P/S pressure switch OFF at idle	V _B	
1Q	○		A/C switch	A/C switch ON	Below 2.5V	Ignition switch ON and blower motor ON
				A/C switch OFF	V _B	
1R	○		Electric cooling fan switch	Fan operating (coolant temperature over 97°C [207°F] or diagnosis connector terminal TFA grounded)	Below 1.0V	—
				Fan not operating (idle)	V _B	
1S	○		Blower control switch	Blower control switch OFF or 1st position	V _B	Ignition switch ON
				Blower control switch 2nd or higher position	Below 1.0V	
1T	○		Rear window defroster switch	Rear window defroster OFF	Below 1.0V	Ignition switch ON
				Rear window defroster ON	V _B	
1U	○		Headlight switch	Headlights ON	V _B	—
				Headlights OFF	Below 1.0V	
1V	○		Neutral/Clutch switches	Neutral position or clutch pedal depressed	Below 1.0V	—
				Others	V _B	

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

Always

Always

Always

Always

Always

Always

Always

Always

Always

(electric

Always

Always

Always

1.0V

Always

Always

Always

CONTROL SYSTEM

F3

V_B: Battery voltage

Incorrect voltage		Possible cause
Always below 1.0V		<ul style="list-style-type: none"> • Throttle sensor misadjustment • Short circuit in wiring from throttle sensor to ECU terminal 1N • ECU malfunction
Always V _B		<ul style="list-style-type: none"> • Throttle sensor misadjustment • Open circuit in wiring from throttle sensor to ECU terminal 1N • Open circuit in wiring from throttle sensor to ECU terminal 2D
Always V _B (foglight switch OK)		<ul style="list-style-type: none"> • Foglight relay malfunction
Always below 1.0V		<ul style="list-style-type: none"> • Foglight relay malfunction
Always below 1.0V		<ul style="list-style-type: none"> • P/S pressure switch malfunction • Short circuit in wiring from P/S pressure switch to ECU terminal 1P • ECU malfunction
Always V _B		<ul style="list-style-type: none"> • P/S pressure switch malfunction • Open circuit in wiring from P/S pressure switch to ECU terminal 1P • Open circuit in wiring from P/S pressure switch to ground
Always below 2.5V (blower fan OK)		<ul style="list-style-type: none"> • A/C switch malfunction • Short circuit in wiring from A/C switch to ECU terminal 1Q • Poor connection at ECU connector • ECU malfunction
Always V _B (blower fan OK)		<ul style="list-style-type: none"> • A/C switch malfunction • Open circuit in wiring from A/C switch to ECU terminal 1Q • Open circuit in wiring from A/C switch to blower control switch
Always below 1.0V (electric cooling fan OK)		<ul style="list-style-type: none"> • Open or short circuit in wiring from fan relay to ECU terminal 1R • ECU malfunction
Always below 1.0V (blower fan OK)		<ul style="list-style-type: none"> • Short circuit in wiring from blower control switch to ECU terminal 1S • Poor connection at ECU connector • ECU malfunction
Always V _B (blower fan OK)		<ul style="list-style-type: none"> • Open circuit in wiring from blower control switch to ECU terminal 1S
Always below 1.0V	Illumination lamp ON when rear window defroster switch ON	<ul style="list-style-type: none"> • Open or short circuit in wiring from rear window defroster switch to ECU terminal 1T
	Illumination lamp never ON	<ul style="list-style-type: none"> • Open circuit in wiring from ignition switch to rear window defroster switch • Rear window defroster switch malfunction
Always below 1.0V (headlights OK)		<ul style="list-style-type: none"> • Open or short circuit in wiring from headlight relay to ECU terminal 1U
Always below 1.0V		<ul style="list-style-type: none"> • Neutral switch malfunction • Clutch switch malfunction • Short circuit in wiring from ECU terminal 1V to neutral or clutch switch
Always V _B		<ul style="list-style-type: none"> • Neutral switch malfunction • Clutch switch malfunction • Open circuit in wiring from ECU terminal 1V to neutral or clutch switch • Poor connection at ECU connector

13E0F3-361

V_B: Battery voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
2A	—	—	Ground (injector)	Constant	0V	—
2B	—	—	Ground (output)	Constant	0V	—
2C	—	—	Ground (CPU)	Constant	0V	—
2D	—	—	Ground (input)	Constant	0V	—
2E	○		Distributor (NE-signal)	Ignition switch ON	0V or 5V	—
				Idle	Approx. 2V	
2F	—	—	—	—	—	—
2G	○		Distributor (G signal)	Ignition switch ON	0V or 5V	—
				Idle	Approx. 1.5V	
2H	—	—	—	—	—	—
2I	—	—	—	—	—	—
2J	○		Knock control unit	Idle	Approx. 4.0V	—
2K	○		Throttle sensor/ Airflow meter	Constant	4.5—5.5V	—
2L	○		Speedometer sensor	Ignition switch ON	0 or 5V	—
2M	○		Throttle sensor	Accelerator pedal released	Approx. 0.5V	—
				Accelerator pedal fully depressed	Approx. 4.0V	
2N	○		Oxygen sensor	Ignition switch ON	0V	—
				Idle (cold engine)	0V	
				Idle (after warm-up)	0—1.0V	
				Increasing engine speed (after warm-up)	0.5—1.0V	
				Deceleration	0—0.4V	
2O	○		Airflow meter	Ignition switch ON	Approx. 3.8V	—
				Idle	Approx. 3.0V	
2P	○		Intake air thermosensor	Ambient air temperature 20°C (68°F)	Approx. 2.5V	In airflow meter
2Q	○		Water thermosensor	Engine coolant temperature 20°C (68°F)	Approx. 2.5V	—
				After warm-up	Below 0.5V	
2R		○	Turbocharge indicator	Ignition switch ON	V _B	—

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

CONTROL SYSTEM

F3

Vb: Battery voltage

Incorrect voltage	Possible cause
Above 0V	<ul style="list-style-type: none"> Poor contact at ground terminal Open circuit in wiring from ECU to ground
Always approx. 0V or approx. 2V	<ul style="list-style-type: none"> Refer to Code No. 02 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
—	—
Always approx. 0V or approx. 1.5V	<ul style="list-style-type: none"> Refer to Code No. 03 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
—	—
—	—
Always 0V	<ul style="list-style-type: none"> Refer to Code No. 05 Troubleshooting (Refer to 323 4-Wheel drive Workshop Manual (1229-10-89L))
Always 0V	<ul style="list-style-type: none"> Short circuit in wiring from ECU terminal 2K to throttle sensor, or airflow meter Poor connection at ECU connector ECU malfunction
Below 4.5V or above 5.5V	<ul style="list-style-type: none"> ECU malfunction
—	<ul style="list-style-type: none"> Refer to section T
Always 0V	<ul style="list-style-type: none"> Throttle sensor malfunction Short circuit in wiring from ECU terminal 2M to throttle sensor Poor connection at ECU connector ECU malfunction
Always approx. 5V	<ul style="list-style-type: none"> Throttle sensor misadjustment Open circuit in wiring from ECU terminal 2D to throttle sensor
Always constant	<ul style="list-style-type: none"> Open circuit in wiring from ECU terminal 2M to throttle sensor Open circuit in wiring from ECU terminal 2K to throttle sensor Open circuit in wiring from ECU terminal 2D to throttle sensor
Always above 1V	<ul style="list-style-type: none"> Throttle sensor misadjustment
Always 0V (after warm-up)	<ul style="list-style-type: none"> Refer to Code No. 15 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always approx. 1V (after warm-up)	<ul style="list-style-type: none"> Refer to Code No. 17 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always 0V or approx. 5V	<ul style="list-style-type: none"> Refer to Code No. 08 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always 0V or approx. 5V	<ul style="list-style-type: none"> Refer to Code No. 10 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always 0V or approx. 5V	<ul style="list-style-type: none"> Refer to Code No. 09 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always 0V	<ul style="list-style-type: none"> Indicator broken Open or short circuit in wiring from ECU 2R to ignition switch

13E0F3-362

V_B: Battery voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
2S		○	Overboost warning buzzer	Ignition switch ON	V _B	—
2T		○	Solenoid valve (PRC low temp.)	180 sec. after engine started with coolant temperature is above 90°C (194°F) and intake air temperature is between 40°C (104°F) and 50°C (122°F)	Below 1.5V	No-load engine condition
				Other condition at idle	V _B	
2U		○	Injector (Nos. 1, 3)	Ignition switch ON	V _B	* Engine Signal Monitor: Green and red lamps flash
				Idle	V _B *	
				Engine speed above 2,000 rpm during deceleration (after warm-up)	V _B	
2V		○	Injector (Nos. 2, 4)	Ignition switch ON	V _B	
				Idle	V _B *	
				Engine speed above 2,000 rpm during deceleration (after warm-up)	V _B	
2W		○	ISC valve	Ignition switch ON	Approx. 7V	—
				Idle	Approx. 9V	
2X		○	Solenoid valve (purge control)	Ignition switch ON	V _B	—
				Idle	V _B	
2Y		○	Circuit-opening relay	Ignition switch ON	V _B	—
				Idle	Below 1.0V	
2Z		○	Solenoid valve (PRC high temp.)	210 sec. after engine started with coolant temperature above 90°C (194°F) and intake air temperature above 50°C (122°F)	Below 1.5V	No-load engine condition
				Other condition at idle	V _B	

Always

Always

Always

Always

Always

Always

Always

Always

Always

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

CONTROL SYSTEM

F3

Vb: Battery voltage

Incorrect voltage	Possible cause
Always 0V	<ul style="list-style-type: none"> • Open or short circuit in wiring from ECU terminal 2S to buzzer
Always 0V or Vb	<ul style="list-style-type: none"> • Refer to Code No.25 Troubleshooting (Refer to page F3-18)
Always 0V	<ul style="list-style-type: none"> • Main relay (FUEL INJ relay) malfunction • Open or short circuit in wiring from injector to ECU terminal 2U or 2V
Always Vb	<ul style="list-style-type: none"> • ECU malfunction
Always 0V or Vb	<ul style="list-style-type: none"> • Refer to Code No.34 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always 0V or Vb	<ul style="list-style-type: none"> • Refer to Code No.26 Troubleshooting (Refer to 323 Workshop Manual (1203-10-89F))
Always 0V	<ul style="list-style-type: none"> • Open or short circuit in wiring from ECU terminal 2Y to relay
Always 0V or Vb	<ul style="list-style-type: none"> • Refer to Code No. 35 Troubleshooting (Refer to page F3-18)

13E0F3-363

G

ENGINE ELECTRICAL SYSTEM

FEATURES

OUTLINE.....	G- 2
SPECIFICATIONS.....	G- 2

SERVICE

SUPPLEMENTAL SERVICE INFORMATION..	G- 2
------------------------------------	------

13E0GX-301

G

OUTLINE

SPECIFICATIONS

Item		Engine	BP DOHC
Battery	Voltage	V	12
	Type and capacity	(20-hour rate)	55D23L (60Ah)
Dark current		mA	Max. 20
Alternator	Type		A-C
	Output	V-A	12.70
	Regulator type		Transistorized (built-in IC regulator)
	Regulated voltage	V	14.1—14.7
	Brush length mm [in]	Standard	21.5 [0.846]
		Minimum	8.0 [0.315]
	Drive belt deflection mm [in]/98 N 10 kgf, 22 lbf	New	5.5—7.0 [0.22—0.27]
		Used	6.0—7.5 [0.24—0.29]
	Limit	8.0 [0.31]	
Starter	Type		Direct
	Output	V-kW	12.0.65
	Brush length mm [in]	Standard	17 [0.67]
		Minimum	11.5 [0.453]
Distributor spark advance			Electronic spark advance (ESA)
Ignition timing (TEN terminal of diagnosis connector grounded)			BTDC 10 ± 1°
Ignition coil	Resistance (at 20°C [68°F])	Primary coil winding	0.81—0.99 Ω
		Secondary coil winding	10—16 kΩ
Spark plug	NGK		BKR6EVX 11 ⁺ BKR5EVX 11 BKR7EVX 11
	NIPPONDENSO		K20PR-TP11 ⁺ K16PR-TP11 K22PR-TP11
	Plug gap	mm [in]	1.0—1.1 [0.039—0.043]
Firing order			1—3—4—2

*Standard plug

13E0GX-302

SUPPLEMENTAL SERVICE INFORMATION

The following points shown in this section are changed in comparison with 323 Workshop Manual (1203-10-89F) and 323 Workshop Manual Supplement (1275-10-91C).

- **Alternator**
Specifications
- **Spark plug**
Specifications

- **Starter**
Specifications

13E0GX-303

H

CLUTCH

FEATURES

OUTLINE.....	H- 2
OUTLINE OF CONSTRUCTION	H- 2
SPECIFICATIONS	H- 2

13E0HX-301

H

OUTLINE

OUTLINE OF CONSTRUCTION

- A hydraulic clutch control mechanism is used.
- The basic construction is the same as the previous 323 BP DOHC turbo models, except that the thickness of clutch disc.

13E0HX-302

SPECIFICATIONS

Model/Engine/Transaxle			323 GT-R	Other 323 4WD
			BP DOHC turbo	
			G25MX-R (G5MX-R)	
Item				
Clutch control			Hydraulic	
Clutch cover	Type		Diaphragm spring	
	Set load	N {kgf, lbf}	5,494 {560, 1,232}	
Clutch disc	Outer diameter	mm {in}	230 {9.05}	
	Inner diameter	mm {in}	155 {6.10}	
	Thickness	Pressure plate side mm {in}	3.5 {0.14}	3.2 {0.13}
		Flywheel side mm {in}	3.5 {0.14}	3.2 {0.13}
Clutch pedal	Type		Suspended	
	Pedal ratio		6.55	
	Full stroke	mm {in}	135 {5.31}	
	Height (With carpet)	mm {in}	196—204 {7.72—8.03}	
Clutch master cylinder	Inner diameter	mm {in}	15.87 {0.625}	
Clutch release cylinder	Inner diameter	mm {in}	19.05 {0.750}	
Clutch fluid			SAE J1703 or FMVSS116 DOT-3	

13E0HX-303

MANUAL TRANSAXLE AND TRANSFER UNIT (G25MX-R)

FEATURES

OUTLINE	J3- 2
OUTLINE OF CONSTRUCTION	J3- 2
SPECIFICATIONS	J3- 2

13E0J3-301

OUTLINE

OUTLINE OF CONSTRUCTION

- The 323 GT-R is added to the 323 BP DOHC turbo model lineup.
- All GT-R models are equipped with the G25MX-R (G5MX-R) manual transaxle and transfer unit.
- The transaxle and transfer unit is the same as in the 323 BP DOHC turbo models, except that the speedometer gear ratio is changed.

Note

- Transaxle code is as shown.

G2 5 M X - R

Shift control type..... ex.) R: Remote control
 Drive type ex.) X: 4-wheel drive
 Transaxle type..... ex.) M: Manual transaxle
 Transaxle speed ex.) 5: 5-speed
 Transaxle model ex.) G2: G2-type

13E0J3-302

SPECIFICATIONS

Transaxle and Transfer Unit

Model/Engine		323 GT-R	Other 323 4WD
Item		BP DOHC turbo	
Transaxle control		Floor shift	
Synchronmesh system	Forward	Synchronmesh	
	Reverse	Selective sliding and synchronmesh	
Gear ratio	1st	3.454	
	2nd	1.833	
	3rd	1.310	
	4th	0.970	
	5th	0.717	
	Reverse	3.166	
Final gear ratio		4.214	
Speedometer gear ratio		1.045	1.000
Center differential	Type	Planetary carrier	
	Number of ring gear teeth	Outer	59
		Inner	75
	Number of pinion gear teeth	Outer	14
		Inner	14
	Number of sun gear teeth	Pinion gear side	43
		Idler gear side	43
	Number of idler gear teeth		37
Oil	Grade		API service GL-4
	Viscosity	ATF Dexron®II or M-III	
		SAE 75W-90	
	Capacity	L [US qt, Imp qt]	

13E0J3-303

Transfer Carrier

Number of teeth	Ring gear		37
	Pinion gear		11
Oil	Grade		API service GL-5
	Viscosity	Above -18°C [0°F]	SAE 90
		Below -18°C [0°F]	SAE 80W
	Capacity	L [US qt, Imp qt]	

13E0J3-304

FRONT AND REAR AXLES

INDEX M- 2

FEATURES

OUTLINE M- 3
OUTLINE OF CONSTRUCTION M- 3
SPECIFICATIONS..... M- 3

SERVICE


SUPPLEMENTAL SERVICE INFORMATION.. M- 4
FRONT AXLE M- 5
PREPARATION..... M- 5
WHEEL HUB, STEERING KNUCKLE..... M- 6
REAR AXLE M-11
PREPARATION..... M-11
WHEEL HUB, KNUCKLE M-12

13EOMX 301

M

INDEX

INDEX



13E0MX-302

1. Front axle

Wheel hub, steering knuckle

Removal / Inspection /

Installation page M- 6

Disassembly / Inspection /

Assembly page M- 8

2. Rear axle

Wheel hub, knuckle

Removal / Inspection /

Installation page M-12

Disassembly / Inspection /

Assembly page M-14

OUT

OUTL

- Title
- Bec
- (1)
- (2)
- (3)
- An
- (Re

SPEC

Front
Joint
Length
Shaft
Rear
Joint
Length
Shaft
Front
Bear
Rear
Bear
Rear
Redu
Differ
Differ
Num
Fluid

OUTLINE

OUTLINE OF CONSTRUCTION

- The construction and operation of the front and rear axles are basically the same as previous models.
- Because of the use of a high power engine, the following parts are modified to improve rigidity.
 - (1) Larger front and rear bearings are used.
 - (2) Larger front and rear knuckles are used.
 - (3) A five-stud wheel hub is used.
- An ice scraper is newly installed on the rear knuckle to prevent ice from building up on the brake caliper. (Refer to page M-14.)

13E0MX-303

SPECIFICATIONS

Item		Specifications
Front driveshaft		
Joint type	Inside	Double offset joint
	Outside	Bell joint
Length of joint (between center of joint) mm [in]	Right	392 [15.4]
	Left	306 [0.83]
Shaft diameter	mm [in]	21.0 [0.83]
Rear driveshaft		
Joint type	Inside	Double offset joint
	Outside	Bell joint
Length of joint (between center of joint) mm [in]	Right	519.5 [20.5]
	Left	489.5 [19.3]
Shaft diameter	mm [in]	21.0 [0.83]
Joint shaft		
Length of joint	mm [in]	357.2 [14.1]
Shaft diameter	mm [in]	21.0 [0.83]
Front axle		
Bearing play axial direction	mm [in]	0.05 [0.002]
Rear axle		
Bearing play axial direction	mm [in]	0.05 [0.002]
Rear differential (viscous limited slip differential)		
Reduction gear		Hypoid gear
Differential gear		Straight bevel gear
Differential ratio		3.909
Number of teeth	Ring gear	43
	Drive pinion gear	11
Fluid	Grade	API Service GL-5
	Viscosity	Above -18°C [0°F]
		SAE 90
	Below -18°C [0°F]	SAE 80W
	Capacity	L [US qt, Imp qt]
		0.65 [0.69, 0.57]

13E0MX-304

M

SUPPLEMENTAL SERVICE INFORMATION

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with Mazda 323 Workshop Manuals (1206-10-89F) and (1229-10-89L).

Front axle

- Removal / Inspection / Installation
- Disassembly / Inspection / Assembly

Rear axle

- Removal / Inspection / Installation
- Disassembly / Inspection / Assembly

13E0MX-306

FRO

PRE
SST

49 (0

Pulle

49 G

Pulle

49 G

Attach
(Part
49 Ci

49 FO

Install
bearr

49 FO

Attach
(Part
49 FO

49 FO

Attach
68 &
(Part
49 FO

49 GO















Install

FRONT AXLE

M

FRONT AXLE

PREPARATION SST *

49 0118 850C Puller, ball joint 	For removal of tie rod end	49 F026 103 Puller, wheel hub 	For disassembly of wheel bearing
49 G033 1A1 Puller, wheel hub 	For disassembly and assembly of wheel hub	49 G033 102 Handle (Part of 49 G033 1A1) 	For removal of front wheel hub
49 G033 105 Attachment A (Part of 49 G033 1A1) 	For removal of front wheel hub	49 G033 107 Installer, dust cover 	For installation of dust cover
49 F027 0A1 Installer set, bearing 	For installation of bearing	49 G030 797 Handle (Part of 49 G030 795) 	For removal of wheel bearing
49 F027 005 Attachment 62 (Part of 49 F027 0A1) 	For removal of wheel bearing	49 F027 004 Attachment 80 (Part of 49 F027 0A1) 	For installation of wheel bearing
49 F027 009 Attachment 68 & 77 (Part of 49 F027 0A1) 	For installation of dust cover	49 V001 795 Installer, oil seal 	For installation of oil seal
49 G030 795 Installer, oil seal 	For installation of wheel bearing	49 H027 002 Remover, bearing 	For removal of wheel bearing

13EOMX-306

M

M

FRONT AXLE

WHEEL HUB, STEERING KNUCKLE


Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.

Caution


- Loosely tighten the shock absorber bolts. Lower the vehicle and tighten the bolts to the specified torque with the vehicle unladen.

4. Adjust the front wheel alignment.



- | | |
|--|-----------|
| 1. Wheel hub nut | |
| 2. Wheel and tire | |
| 3. Locknut | |
| Removal Note | page M-7 |
| Installation Note | page M-7 |
| 4. Brake caliper assembly | |
| Service | Section P |
| 5. Disc plate | |
| Inspection | Section P |
| 6. ABS wheel speed sensor (if equipped) | |
| 7. Tie rod end | |
| Removal Note | page M-7 |
| Installation Note | page M-7 |
| 8. Lower ball joint | |
| 9. Steering knuckle, wheel hub, and dust cover | |
| Inspect wheel hub for cracks and damage | |
| Inspect knuckle spindle for cracks and damage | |
| Inspect dust cover for damage and distortion | |
| Disassembly / Inspection / Assembly | page M-8 |

FRONT AXLE

M


13E0MX-308

Removal note Locknut

Caution

- Do not damage the drive shaft.
- Do not reuse the locknut.

1. Raise the staked portion of the locknut using a chisel.
2. Lock the hub by applying the brakes.
3. Remove the locknut.




13E0MX-309

Tie rod end

Caution

- Do not damage the dust boot.

Loosen the nut and disconnect the tie rod end by using the SST.



13E0MX-310

Installation note Tie rod end


Caution

- Do not damage the dust boot.

Install the nut and secure it with the new cotter pin.

Tightening torque:

43—56 N·m (4.3—5.8 kgf·m, 31—41 ft·lbf)



13E0MX-311

Locknut

Install a new locknut and stake it, as shown.

Tightening torque: 236—318 N·m

(24.0—32.5 kgf·m, 174—235 ft·lbf)


M

M

FRONT AXLE

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




13E0MX-312

- | | |
|----------------------------------|----------------------------------|
| 1. Oil seal | 5. Dust cover |
| Assembly Note page M-10 | Disassembly Note page M- 9 |
| 2. Front wheel hub assembly | Assembly Note page M-10 |
| Disassembly Note below | |
| Assembly Note page M-10 | 6. Steering knuckle |
| 3. Retaining ring | 7. Hub bolt |
| 4. Wheel bearing | Disassembly Note page M- 9 |
| Disassembly Note page M- 9 | Assembly Note page M- 9 |
| Assembly Note page M-10 | |

Disassembly note


Front wheel hub assembly

1. Remove the front wheel hub assembly by using the SST.



13E0MX-313


2. Make an opening between the wheel hub and the bearing race to allow for use of the SST.




13E0MX-314

FRONT AXLE


M




13E0MX-315




13E0MX-316



13E0MX-317



13E0MX-318



13E0MX-319

3. Press out the bearing race by using the **SST**.

Wheel bearing

Caution

- Do not reuse the wheel bearing.

Remove the wheel bearing by using the **SST**.

Dust cover

Caution

- Do not remove the dust cover if not necessary.
- Do not reuse the dust cover if removed.

1. Mark the dust cover and steering knuckle for proper reassembly.
2. Remove the dust cover by using a chisel.

Hub bolt

Caution

- Do not remove the hub bolts if not necessary.
- Do not reuse the hub bolts if removed.

Remove the hub bolts by using a press.

Assembly note


Hub bolt

Press in new hub bolts.


M

M


FRONT AXLE




13E0MX-320




13E0MX-321



13E0MX-322



13E0MX-323



13E0MX-324

Dust cover

1. Mark the new dust cover as the one removed.

2. Align the marks of the new dust cover and the steering knuckle.
3. Install the dust cover by using a steel plate and the SST.

Wheel bearing

Install the new wheel bearing by using the SST.

Front wheel hub assembly

1. Install the front wheel hub assembly by using the SST.
2. Verify that the wheel hub rotates smoothly.

Oil seal

Caution

- Use a new oil seal, and apply grease to the lip of the seal.
- Install the oil seal flush with the steering knuckle.

Install the new oil seal by using the SST.

REA

PREP SST*

49 F02
Puller

49 G03
Handle
(Part of
49 G03)

49 F02
Attach
(Part of
49 F02)

49 F02
Attach
68 & 7
(Part of
49 F02)

49 F02
Installer
bearing

49 G03
Installer














49 G03
Installer
cover

REAR AXLE

M

REAR AXLE

PREPARATION SST*

49 F026 103 Puller, wheel hub 	For removal of wheel bearing	49 G033 105 Attachment A (Part of 49 G033 1A1) 	For removal of wheel hub
49 G033 102 Handle (Part of 49 G033 1A1) 	For removal of wheel hub	49 G030 797 Handle (Part of 49 G030 795) 	For removal of wheel bearing
49 F027 005 Attachment 62 (Part of 49 F027 0A1) 	For removal of wheel bearing	49 F027 004 Attachment 72 (Part of 49 F027 0A1) 	For installation of wheel bearing
49 F027 009 Attachment 68 & 77 (Part of 49 F027 0A1) 	For installation of wheel bearing	49 V001 795 Installer, oil seal 	For installation of oil seal
49 F027 0A1 Installer set, bearing 	For installation of wheel bearing	49 G033 1A1 Puller, wheel hub 	For removal of wheel hub
49 G030 795 Installer, oil seal 	For installation of wheel bearing	49 H027 002 Remover, bearing 	For removal of wheel hub
49 G033 107 Installer, dust cover 	For installation of dust cover		

13E0MX-325

M

REAR AXLE

WHEEL HUB, KNUCKLE


Removal / Inspection / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.

Caution

- Loosely tighten the shock absorber bolts. Lower the vehicle and tighten the bolts to the specified torque with the vehicle unladen.

4. Adjust the rear wheel alignment.



1. Wheel and tire

2. Locknut

Removal Note page M-13

Installation Note page M-13

3. Brake caliper assembly

Service Section P

4. Disc plate

Service Section P

5. ABS wheel speed sensor (if equipped)

6. Wheel hub, knuckle

Disassembly / Inspection /


Assembly page M-14

Inspect wheel hub and knuckle for damage or cracks


Inspect dust cover for damage or deformation

REAR AXLE

M



13E0MX-308



13E0MX-327

Removal note Locknut

Caution

- Do not damage the drive shaft.
- Do not reuse the locknut.

1. Raise the staked portion of the locknut using a chisel.
2. Lock the hub by applying the brakes.
3. Remove the locknut.

Installation note


Locknut

Install a new locknut and stake it, as shown.

Tightening torque: 236—318 N·m
[24.0—32.5 kgf·m, 174—235 ft·lbf]

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




1. Oil seal
Assembly Note page M-17
2. Rear wheel hub assembly
Disassembly Note below
Assembly Note page M-16
3. Retaining ring
Disassembly Note page M-15
Assembly Note page M-16
4. Wheel bearing
Disassembly Note page M-15
Assembly Note page M-16

5. Dust cover
Disassembly Note page M-15
Assembly Note page M-16
6. Knuckle
Disassembly Note page M-15
Assembly Note page M-16
7. Hub bolt
Disassembly Note page M-15
Assembly Note page M-16
8. Ice scraper
Disassembly Note page M-15


Disassembly note**Rear wheel hub assembly**

1. Remove the front wheel hub assembly by using the **SST**.



13E0MX-329


2. Make an opening between the wheel hub and the bearing race to allow for use of the **SST**.




13E0MX-314

REAR AXLE


M




13E0MX-315




13E0MX-330



13E0MX-317



13E0MX-331



13E0MX-318

3. Press out the bearing race by using the **SST**.

Wheel bearing

Remove the wheel bearing by using the **SST**.

Dust cover

Caution

- Do not remove the dust cover if not necessary.
- Do not reuse the dust cover if removed.

1. Mark the dust cover and steering knuckle for proper reassembly.
2. Remove the dust cover by using a chisel.

Ice scraper

Caution

- Do not remove the ice scraper if not necessary.
- If it is removed, use a new bolt applied specified thread locking compound.


Hub bolt

Caution

- Do not remove the hub bolts if not necessary.
- Do not reuse the hub bolts if removed.

Remove the hub bolts by using a press.


REAR AXLE



13E0MX-319

Assembly note**Hub bolt**


Press in new hub bolts.



13E0MX-320


Dust cover

1. Mark the new dust cover as the one removed.



13E0MX-332


2. Align the marks of the new dust cover and the knuckle.
3. Install the dust cover by using a steel plate and the SST.



13E0MX-333

Wheel bearing

Using the SST, install the new wheel bearing.




13E0MX-323

Rear wheel hub assembly

1. Install the rear wheel hub assembly by using the SST.
2. Verify that the wheel hub rotates smoothly.

REAR AXLE

M



13E0MX-324

Oil seal

Caution

- Use a new oil seal, and apply grease to the lip of the seal.
- Install the oil seal flush with the knuckle.

Install the new oil seal by using the **SST**.

N

STEERING SYSTEM

FEATURES

OUTLINE.....	N- 2
OUTLINE OF CONSTRUCTION	N- 2
SPECIFICATIONS.....	N- 2

13EONX-301

N

N

OUTLINE

OUTLINE

OUTLINE OF CONSTRUCTION

- Engine speed sensing power steering (ESPS) is standard equipment for all models. The construction and operation are basically the same as for previous models.
- The lock-to-lock specification of the steering wheel is reduced from 2.76 to 2.51.

13E0NX-302

SPECIFICATIONS

Item		Specifications
Steering wheel	Outer diameter mm [in]	370 [14.57]
	Lock-to-lock turns	2.51
Steering shaft and joint	Type	Collapsible
	Joint type	2-cross joint
	Tilt stroke mm [in]	30 [1.18]
Steering gear	Type	Rack-and-pinion
	Gear ratio	∞ (infinite)
	Rack stroke mm [in]	121 [4.76]
Power steering fluid	Capacity L (US qt, Imp qt)	0.8 [0.85, 0.70]
	Type	ATF Dexron®II or M-III

Shaded area indicates new specification.

13E0NX-303

BRAKING SYSTEM

INDEX P- 2

FEATURES

OUTLINE P- 3
OUTLINE OF CONSTRUCTION P- 3
SPECIFICATIONS P- 3


SERVICE

SUPPLEMENTAL SERVICE INFORMATION .. P- 4
CONVENTIONAL BRAKE SYSTEM P- 5
PREPARATION P- 5
AIR BLEEDING (WITH ABS) P- 6
POWER BRAKE UNIT P- 8
PROPORTIONING VALVE P- 9
FRONT BRAKE (DISC) P-10
DISC PAD P-11
DISC PLATE P-12
CALIPER P-12
REAR BRAKE (DISC) P-14
DISC PAD P-15
DISC PLATE P-16
CALIPER P-17


13E0PX-301

INDEX

WITHOUT ABS



WITH ABS



13EOPX-302

1. Power brake unit	
Inspection	page P- 8
2. Proportioning valve	
Inspection	page P- 9
3. Front brake (disc)	
Inspection (on-vehicle)	page P-10
Removal / Inspection /	
Installation	page P-10
4. Disc pad	
Replacement	page P-11
5. Disc plate	
Inspection	page P-12

6. Caliper	
Disassembly / Inspection /	
Assembly	page P-12
7. Rear brake (disc)	
Inspection (on-vehicle)	page P-14
8. Disc pad	
Replacement	page P-15
9. Disc plate	
Inspection	page P-16
10. Caliper	
Disassembly / Inspection /	
Assembly	page P-17

OUTL

OUTLIN

- The is
- Howe
- Vehicl

SPECIFI

Brake pa

Master cy

Front disc

Rear disc

Power brak

Braking for

Brake fluid

Parking bra

OUTLINE

P

OUTLINE

OUTLINE OF CONSTRUCTION

- The brake system remains similar to that of the previous model.
- However, because all new models use a higher-horsepower engine, the brake system is enlarged as a whole.
- Vehicles without ABS use a portless-type master cylinder

13E0PX-303

SPECIFICATIONS

Item		Specification
Brake pedal	Type	Suspended
	Pedal lever ratio	4.1
	Max. stroke mm [in]	140 [5.51]
Master cylinder	Type	Tandem
	Cylinder inner diameter mm [in]	Without ABS: 25.4 [1.00] With ABS: 23.8 [0.94]
Front disc brake	Type	Ventilated disc
	Cylinder bore mm [in]	57.2 [2.25]
	Pad dimensions (area x thickness) mm ² [in ²] x mm [in]	5,200 [8.06] x 10 [0.39]
	Disc plate dimensions (outer diameter x thickness) mm [in]	274 x 24 [10.79 x 0.94]
Rear disc brake	Type	Solid disc
	Cylinder bore mm [in]	34.9 [1.37]
	Pad dimensions (area x thickness) mm ² [in ²] x mm [in]	3,200 [4.96] x 8 [0.31]
	Disc plate dimensions (outer diameter x thickness) mm [in]	280 x 10 [11.02 x 0.39]
Power brake unit	Type	Without ABS: Vacuum multiplier With ABS: Hydraulic multiplier
	Diameter (without ABS) mm [in]	188.4 [7.42] + 215.2 [8.47]
Braking force control device	Type	Without ABS: Dual proportioning valve With ABS: Proportioning valve
Brake fluid		FMVSS 116, DOT-3, SAE J1703
Parking brake	Type	Mechanical two-rear-wheel control
	Operation system	Center lever

13E0PX-304

P

P SUPPLEMENTAL SERVICE INFORMATION

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed and added in comparison with Workshop Manuals (1206-10-89F), (1229-10-89L) and (1275-10-91C).

Air bleeding (with ABS)

Power brake unit (SST newly established)

- Inspection (on-vehicle)

Proportioning valve (SST newly established)

- Inspection

Front brake

- Inspection (on-vehicle)
- Removal / Inspection / Installation

Disc pad

- Replacement

Disc plate

- Inspection

Caliper

- Disassembly / Inspection / Assembly

Rear brake

- Inspection (on-vehicle)
- Removal / Inspection / Installation

Disc pad

- Replacement

Disc plate

- Inspection

Caliper

- Disassembly / Inspection / Assembly

13E0PX-305

CON

PREP,
SST

49 025

Wrench

49 U04

Gauge,
pressur
(Part of
49 U04

49 U04

Hose
(Part of
49 U04;

49 0209

Air-out to

49 1250











Puller, tx

CONVENTIONAL BRAKE SYSTEM

P

CONVENTIONAL BRAKE SYSTEM

PREPARATION SST


<p>49 0259 770B</p> <p>Wrench, flare nut</p> 	<p>For removal and installation of brake pipe</p>	<p>49 U043 0A0</p> <p>Gauge set, oil pressure</p> 	<p>For inspection of brake fluid pressure</p>
<p>49 U043 004</p> <p>Gauge, oil pressure (Part of 49 U043 0A0)</p> 	<p>For inspection of brake fluid pressure</p>	<p>49 U043 005</p> <p>Joint (Part of 49 U043 0A0)</p> 	<p>For inspection of brake fluid pressure</p>
<p>49 U043 006</p> <p>Hose (Part of 49 U043 0A0)</p> 	<p>For inspection of brake fluid pressure</p>	<p>49 B043 002</p> <p>Installer, bearing</p> 	<p>For installation of caliper needle bearing</p>
<p>49 0208 701A</p> <p>Air-out tool, boot</p> 	<p>For removal of piston seal</p>	<p>49 FA18 502</p> <p>Wrench, disc brake piston</p> 	<p>For removal and installation of disc caliper piston</p>
<p>49 1258 071</p> <p>Puller, bearing</p> 	<p>For removal of caliper needle bearing</p>	<p>49 0221 600C</p> <p>Expand tool, disc brake</p> 	<p>For installation of brake pads</p>

13E0PX-306


P

P


CONVENTIONAL BRAKE SYSTEM



93G0PX-743



13E0PX-307



13E0PX-308

AIR BLEEDING (WITH ABS)

Front Brakes

1. Fill the fluid reservoir to the MAX line with the specified brake fluid.

Caution

- The brake fluid reservoir must remain 3/4 full during air bleeding.
- Be careful not to spill brake fluid onto a painted surface.
- Use only the specified brake fluid. Do not mix it with any other type.

2. Jack up the vehicle and support it on safety stands.
3. Remove the bleeder cap and attach a vinyl hose to the bleeder screw.
4. Place the other end of the vinyl hose into a clear fluid-filled container.
5. Have an assistant depress the brake pedal a few times, and then hold it depressed.
6. Using the **SST**, loosen the bleeder screw and drain out the fluid and air. Retighten the bleeder screw.


Caution

- The two persons should stay in voice contact with each other.
- Be sure the pedal remains depressed until the air bleed screw is tightened.

7. Repeat Steps 5 and 6 until no air bubbles are seen.
8. Check for correct brake operation.
9. Verify that there is no fluid leakage. Clean away any spilled fluid with rags.
10. After bleeding the air, add brake fluid to the reservoir up to the MAX level.




49 0259




49 0259 7

CONVENTIONAL BRAKE SYSTEM


P



13E0PX-309



13E0PX-310



13E0PX-311

Rear Brakes

1. Fill the fluid reservoir to the MAX mark with the specified brake fluid.
2. With the ignition switch ON, fully depress the brake pedal several times.
3. When the hydraulic-unit pump stops add the specified brake fluid to the reservoir MAX mark if necessary.
If the hydraulic-unit pump continues to run for more than one minute, do the following:

- (1) Jack up the vehicle and support it on safety stands.
- (2) Remove the bleeder cap and attach a vinyl hose to the bleeder screw.
- (3) Insert the other end of the vinyl hose into a clear container.
- (4) Loosen the bleeder screw by using the **SST**.
- (5) With the ignition switch ON, fully depress the brake pedal several times.
- (6) Tighten the bleeder screw and continue with Step 2 of the main procedure.

Caution

- Do not run the hydraulic-unit pump for more than two minutes.
- The brake fluid reservoir must be kept 3/4 full during air bleeding.
- Be careful not to spill brake fluid onto a painted surface.
- Use only the specified brake fluid. Do not mix different brands of fluid.

4. Jack up the vehicle and support it on safety stands.
5. Remove the bleeder cap and attach a vinyl hose to the bleeder screw.
6. Place the other end of the vinyl hose into a clear fluid-filled container.
7. With the ignition switch ON, have an assistant depress the brake pedal several times, and then hold the pedal down.

Caution


- The two people should stay within voice contact of each other.
- Be sure the pedal remains depressed until the bleeder screw is tightened.
- Release the brake pedal intermittently to stop the pump motor.
- Care must be used when opening the rear caliper bleeder screw, because of the high pressure built up from a fully-charged accumulator.

8. Use the **SST** to loosen the bleeder screw to let fluid and air escape. Retighten the bleeder screw by using the **SST**.
9. Repeat Steps 7 and 8 until no air bubbles are seen.
10. Check for correct brake operation.
11. Verify that there is no fluid leakage. Clean away any spilled fluid with rags.
12. After bleeding the air from the brake system, add brake fluid to the reservoir MAX mark.


13E0PX-312

P-7


CONVENTIONAL BRAKE SYSTEM




13E0PX-313




13E0PX-314



16E0PX-051



13E0PX-315



13E0PX-316

POWER BRAKE UNIT

Quick Inspection (On-vehicle)

Power brake unit function check (Method-using tester)

Connect the **SST**, vacuum gauge A, and pedal depression force gauge B as shown in the figure. After bleeding the air from the **SST**, conduct the test as described in the 3 steps below.

Note

- Use commercially available vacuum gauge and pedal depression force gauge.

a) Checking for vacuum loss

Unloaded condition

1. Start the engine.
2. Stop the engine when the vacuum gauge reading reaches **66.7 kPa (500 mmHg, 19.7 inHg)**.
3. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3—66.7 kPa (475—500 mmHg, 18.7—19.7 inHg)**, the unit is operating.

Loaded condition

1. Start the engine.
2. Depress the brake pedal with a force of **196 N (20 kgf, 44 lbf)**.
3. With the brake pedal depressed, stop the engine when the vacuum gauge reading reaches **66.7 kPa (500 mmHg, 19.7 inHg)**.
4. Observe the vacuum gauge for **15 seconds**. If the gauge shows **63.3—66.7 kPa (475—500 mmHg, 18.7—19.7 inHg)**, the unit is operating.

b) Checking for hydraulic pressure

1. If with the engine stopped (vacuum **0 kPa (0 mmHg, 0 inHg)**) the fluid pressure is within specification, the unit is operating.

Pedal force	N {kgf, lbf}	Fluid pressure	kPa {kgf/cm ² , psi}
196	{20, 44}	1080	{11, 156} min.

2. Start the engine. Depress the brake pedal when the vacuum reaches **66.7 kPa (500 mmHg, 19.7 inHg)**. If the fluid pressure is within specification, the unit is operating.

Pedal force	N {kgf, lbf}	Fluid pressure	kPa {kgf/cm ² , psi}
196	{20, 44}	6670	{68, 967} min.

WITHOUT

49 U043

49 U043

WITH ABS

49 U043 0

49 U043 00

REAR BRAKE PRESSURE




kPa {kgf/cm², psi}



MASTER CYLIN

CONVENTIONAL BRAKE SYSTEM

P



PROPORTIONING VALVE

Inspection

1. Connect the SST to the brake pipes with adapters as shown in the figure.

Adapter and flare nut tightening torque:

12.8—21.5 N·m {130—220 kgf·cm, 113—190 in·lbf}

Note

- Disconnect and connect the brake pipes with SST.


2. Bleed the air from the brake system.
3. Depress the brake pedal until the master cylinder pressure equals A; then record rear brake pressure A'.
4. Depress the brake pedal again, apply additional pressure until the pressure equals B; then record pressure B'.

Fluid pressure

	kPa (kgf/cm², psi)			
	A	A'	B	B'
WITHOUT ABS	1960 {20, 284}	1960 {20, 284} ±196 {2, 28}	5880 {60, 853}	2750 {28, 398} ±196 {2, 28}
WITH ABS	1960 {20, 284}	1960 {20, 284} ±196 {2, 28}	5880 {60, 853}	3140 {32, 455} ±294 {3, 42}

P

CONVENTIONAL BRAKE SYSTEM



13E0PX-319

FRONT BRAKE (DISC) Inspection (on-vehicle) Disc pad


1. Jack up the front of the vehicle and support it with safety stands.
2. Remove the wheels.
3. Sight through the caliper inspection hole and inspect the remaining thickness of the pads.

Thickness: 2.0mm (0.08 in) min.

4. Replace the pads as a set (right and left wheels) if either is at or less than the minimum thickness.

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, perform the following.
 - (1) Add fluid and bleed the air.
 - (2) Check for fluid leakage.
 - (3) Depress the pedal a few times, then verify that the brakes do not drag while rotating the wheel by hand.



1. Flexible hose

2. Bolt

3. Caliper

Disassembly / Inspection /

Assembly page P-12

4. Boot

5. V-spring

6. Disc pad

Inspection above

Installation Note page P-11

7. Outer shim

8. Inner shim

9. Guide plate

10. Mounting support

11. Disc plate

Inspection page P-12



49 0221

DISC PAD Replacement

1. Remove
2. Install in

1. Bolt


2. V-spring

3. Disc pad

Installation

CONVENTIONAL BRAKE SYSTEM

P



13E0PX-321

Installation note


Disc pad

Before installing the disc pads, push the piston fully inward by using the SST.

DISC PAD

Replacement

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal, referring to **Installation Note**.



N·m (kgf-m, ft-lbf)


13E0PX-333

- | | |
|-------------|----------------|
| 1. Bolt | 4. Outer shim |
| 2. V-spring | 5. Inner shim |
| 3. Disc pad | 6. Guide plate |


Installation Note above

P

CONVENTIONAL BRAKE SYSTEM



16E0PX-056



13E0PX-322

DISC PLATE Inspection

Disc plate thickness

1. Measure the thickness of the disc plate.

Standard: 24mm (0.94 in)

Minimum: 22mm (0.87 in)

2. If the thickness is not within specification, replace the disc plate.

Disc plate runout

Caution

- There must be no wheel bearing looseness.

1. Measure the runout at the outer edge of the contact surface of the disc pad.


Runout: 0.1mm (0.004 in) max.

2. If the runout is not within specification, repair or replace the disc plate.

CALIPER

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




13E0PX-323

1. Dust seal
Inspect for damage and poor sealing
2. Piston
Disassembly Note..... page P-13
Inspect for wear and rust
3. Piston seal
Disassembly Note..... page P-13
4. Bleeder cap, bleeder screw
Disassembly Note..... page P-13
Assembly Note..... page P-13
5. Caliper body
Inspect for damage, wear and rust

CONVENTIONAL BRAKE SYSTEM

P




13E0PX-324

Disassembly note Piston

Caution

- Blow the compressed air slowly to prevent the piston from popping out.


1. Place a piece of wood in the caliper.
2. Blow compressed air through the pipe hole to force the piston out of the caliper.



16E0PX-070

Piston seal


Remove the piston seal from the caliper by using the SST.



16E0PX-071

Bleeder screw

Loosen the bleeder screw by using the SST.



13E0PX-325

Assembly note

Bleeder screw


Tightening the bleeder screw by using the SST.

Tightening torque:

5.9—8.8 N·m (60—90 kgf·cm, 53—78 in·lbf)

P

CONVENTIONAL BRAKE SYSTEM



16E0PX-073

REAR BRAKE (DISC) Inspection (on-vehicle)


Disc pad

1. Jack up the rear of the vehicle and support it with safety stands.
2. Remove the wheel and tires.
3. Verify the remaining thickness of the pads.

Thickness: 1.0mm [0.04 in] min.

Removal / Inspection / Installation

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. After installation, check the following.
 - (1) Add fluid and bleed the air.
 - (2) Check for fluid leakage.
 - (3) Adjust the parking brake lever stroke.
 - (4) Depress the pedal a few times, then verify that the brakes do not drag while rotating the wheel by hand.



13E0PX-326

1. Parking cable
 2. Connecting bolt
 3. Brake hose
 4. Lock bolt
 5. Caliper
 6. V-spring
- Disassembly / Inspection / Assembly page P-17

7. Disc pad
 8. Outer shim
 9. Inner shim
 10. Guide plate
 11. Bolt
 12. Mounting support
 13. Disc plate
- Installation Note page P-15
Inspection above
Inspection page P-16



49 FA

DISC PAD Replacement


1. Remove
2. Inspect
3. Install in
4. Adjust th

16-

1. Parking t
 2. Clip
 3. Lock bolt
 4. V-spring
 5. Disc pad
- Install

CONVENTIONAL BRAKE SYSTEM

P



13E0PX-327

Installation note


Disc pad

Install the piston with the **SST** by turning it clockwise until it stops.

DISC PAD

Replacement

1. Remove in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Adjust the parking brake lever stroke.



N-m (kgf-m, ft-lb)


13E0PX-334

1. Parking brake cable
2. Clip
3. Lock bolt
4. V-spring
5. Disc pad

6. Outer shim
7. Inner shim
8. Guide plate

Installation Note above

CONVENTIONAL BRAKE SYSTEM



16E0PX-078

DISC PLATE

Inspection

Disc plate thickness

1. Measure the thickness of the disc plate.

Standard: 10mm {0.39 in}

Minimum: 8mm {0.31 in}

2. If the thickness is not within specification, replace the disc plate.

Disc plate runout


Caution

- There must be not wheel bearing looseness.

1. Measure the runout at the outer edge of the contact surface of the disc pad.

Runout: 0.1mm {0.004 in} max.

2. If the runout is not within specification, repair or replace the disc plate.



13E0PX-328

CALIPER

Disassembly

1. Disassembly
2. Inspection
3. Assembly

1. Sleeve
2. Boot
3. Boot
4. Retainer
5. Dust seal
6. Piston
7. Piston seal
8. Snap ring
9. Stopper
10. Adjuster

CONVENTIONAL BRAKE SYSTEM

P


CALIPER

Disassembly / Inspection / Assembly

Caution

- Replace the caliper assembly if a problem is found.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




N·m (kgf·cm, ft·lbf)

13E0PX-329

- | | |
|---------------------------------|-----------------------------------|
| 1. Sleeve | 11. O-ring |
| 2. Boot | 12. Connecting link |
| 3. Boot | Inspect for damage and wear |
| 4. Retaining ring | 13. Return spring |
| 5. Dust seal | 14. Operating lever |
| 6. Piston | 15. Boot |
| Disassembly Note..... page P-18 | 16. Needle bearing |
| Assembly Note..... page P-19 | Disassembly Note..... page P-18 |
| Inspect for wear and rust | Assembly Note..... page P-19 |
| 7. Piston seal | 17. Bleeder screw and rubber cap |
| Disassembly Note..... page P-18 | Disassembly Note..... page P-18 |
| 8. Snap ring | Assembly Note..... page P-18 |
| 9. Stopper | 18. Cable bracket |
| 10. Adjuster spindle | 19. Caliper body |
| Inspect for damage and wear | Inspect for damage, wear and rust |

CONVENTIONAL BRAKE SYSTEM




13E0PX-330

Disassembly note**Piston**

Remove the piston with the SST.

Note


- The piston is removed by turning the SST counter-clockwise.



86U11X-093

Piston seal

Remove the piston seal with the SST.



16E0PX-716


Needle bearing

1. Secure the caliper in a vise.

Caution

- Do not remove the needle bearing if not necessary.
- Insert a soft, protective material (such as copper plates) in the jaws of the vise.


2. Remove the needle bearing from the caliper with the SST.



16E0PX-083

Bleeder screw

Loosen the bleeder screw by using the SST.



13E0PX-331

Assembly note**Bleeder screw**

Tighten the bleed screw by using the SST.

Tightening torque:

5.9—8.8 N·m (60—90 kgf·cm, 53—78 in·lb)




49 B043


BEARING



49 FA18

**Needle bearing**

1. Set the new needle bearing in the caliper with the needle bearing hole facing the caliper cylinder.
2. Press the needle bearing into the caliper with the **SST** until the **SST** bottoms against the caliper.

**Piston**

Assemble the piston with the **SST**.

Note

- The piston is assembled by turning the **SST** clockwise.

WHEELS AND TIRES

FEATURES

OUTLINE.....	Q- 2
SPECIFICATIONS.....	Q- 2

SERVICE

SUPPLEMENTAL SERVICE INFORMATION..	Q- 3
WHEELS AND TIRES.....	Q- 3
WHEEL BALANCE ADJUSTMENT	Q- 3

13E00X-301

OUTLINE

- The standard tire size is increased to 15 inches to improve vehicle performance.
- The spare tire is also increased to 15 inches.
- Five lug disc wheels are fitted.

13E0QX-302

SPECIFICATIONS

Standard Tire

Item			Specifications
Wheel	Size		15x5 1/2J
	Offset	mm [in]	47.5 [1.87]
	Pitch circle diameter	mm [in]	114.3 [5.50]
	Material		Aluminum alloy
Tire	Size		195/50R15 82V
	Air pressure kPa {kgf/cm ² , psi}	Front	235 [2.4, 35] ^{*1} 245 [2.5, 36] ^{*2}
		Rear	215 [2.2, 32] ^{*1} 245 [2.5, 36] ^{*2}

*1...Up to 3 persons

*2...~ Full load


13E0QX-303

Temporary spare tire

Item			Specifications
Wheel	Size		15x4T
	Offset	mm [in]	45 [1.77]
	Pitch circle diameter	mm [in]	114.3 [5.50]
	Material		Steel
	Size		T125/70D15
Tire	Air pressure	kPa {kgf/cm ² , psi}	415 [4.2, 60]

Shaded areas indicates new specifications.

13E0QX-304



Ⓐ OFFSET
Ⓑ PITCH CIRCLE DIAMETER

SUPPL

The foll
ume 2

- Wheels
- Wheel t


BALANCE
WEIGHT

SUPPLEMENTAL SERVICE INFORMATION


The following point in this section is changed in comparison with the Mazda 323 Workshop Manual Volume 2 (1206-10-89F).

- **Wheels and tires**
Wheel balance adjustment

13E0QX-305



13E0QX-306



WHEELS AND TIRES

WHEEL BALANCE ADJUSTMENT

If a wheel becomes unbalanced or if a tire is replaced or repaired, the wheel must be rebalanced to within specification.

Maximum unbalance (at rim edge): 9 g (0.32 oz)

Caution

- Do not use more than two balance weights on the inner or outer side of the wheel.
- One balance weight; max. 60 g (2.1 oz).
- If the total weight exceeds 100 g (3.5 oz) on one side, rebalance after moving the tire around on the rim.
- Attach the balance weights tightly to the wheel.
- Select suitable balance weights for aluminum alloy wheels.

R

SUSPENSION

FEATURES

OUTLINE.....	R- 2
OUTLINE OF CONSTRUCTION	R- 2
SPECIFICATIONS.....	R- 2

13E0RX-301

R

OUTLINE

OUTLINE OF CONSTRUCTION

- The construction and operation of the suspension system are basically the same as for previous models.
- The coil spring and shock absorber specifications are changed.
- The stabilizer specifications are changed.

13E0RX-302

SPECIFICATIONS

Item			Specifications
Front suspension			
Suspension type			Strut
Spring type			Coil spring
Shock absorber	Type		Oil filled
	Damping force N [kgf, lbf] at 0.3 m [12 in]/s	Expansion	1,470 [150, 330]
		Contraction	686 [70, 154]
Stabilizer	Type		Torsion bar
	Diameter	mm [in]	23.0 [0.91]
Front wheel alignment (*Unladen)	Total toe-in	mm [in]	2 ± 3 [0.08 ± 0.12]
		degree	0°12' ± 18'
	Maximum steering	Inner	38° ± 3°
	degree	Outer	30° ± 3°
	Camber angle	degree	-0°45' ± 45'
	Caster angle	degree	2°35' ± 45'
Kingpin angle			12°10'
Rear suspension			
Suspension type			Strut
Spring type			Coil spring
Shock absorber	Type		Oil filled
	Damping force N [kgf, lbf] at 0.3 m [12 in]/s	Expansion	882 [90, 198]
		Contraction	392 [40, 88]
Stabilizer	Type		Torsion bar
	Diameter	mm [in]	19.1 [0.75]
Rear wheel alignment (*Unladen)	Total toe-in	mm [in]	2 ± 3 [0.08 ± 0.12]
		degree	0°12' ± 18'
	Camber angle	degree	-0°20' ± 45'

13E0RX-303

* Fuel tank full; radiator coolant and engine oil at specified levels; and spare tire, jack, and tools in designated positions.

Front Coil Spring Specifications

Type	Identification mark color		Wire diameter mm [in]	Coil center diameter mm [in]	Free length mm [in]	Coil number
	M ^{*1}	A ^{*2}				
With sunroof	Pink	Green	14.5 [0.57]	132.5—158.5 [5.21—6.24]	271.5 [10.69]	3.35
Without sunroof	Light blue	Red	14.4 [0.56]	132.6—158.6 [5.22—6.24]	267.0 [10.51]	3.24

13E0RX-304

Rear Coil Spring Specifications

Type	Identification mark color		Wire diameter mm [in]	Coil center diameter mm [in]	Free length mm [in]	Coil number
	M ^{*1}					
With sunroof		Cream	8.8—12.5 [0.34—0.49]	128.5—131.2 [5.05—5.16]	334 [13.14]	6.19
Without sunroof		Pink	8.9—12.4 [0.35—0.48]	128.6—131.1 [5.06—5.16]	335 [13.18]	6.23

*1 Main identification mark on second coil from bottom.

*2 Auxiliary identification mark on third coil from bottom.

13E0RX-305

Shaded areas indicate new specifications

BODY

INDEX S- 2

FEATURES


OUTLINE	S- 3
OUTLINE OF CONSTRUCTION.....	S- 3
BONNET BULGE	S- 3
RADIATOR GRILLE	S- 4
FRONT BUMPER	S- 4
REAR SKIRT.....	S- 5
WHEEL ARCH MOLDING.....	S- 5

SERVICE

SUPPLEMENTAL SERVICE INFORMATION ..	S- 6
BONNET BULGE	S- 7
COMPONENTS	S- 7
FRONT BUMPER.....	S- 8
COMPONENTS.....	S- 8
REAR SKIRT.....	S-10
COMPONENTS.....	S-10
WHEEL ARCH MOLDING.....	S-11
COMPONENTS.....	S-11

13EOSX-301

INDEX



13E05X-302

1. Bonnet bulge
Removal / Installation page S- 7
2. Front bumper
Removal / Installation page S- 8.
Disassembly / Assembly page S- 9

3. Rear skirt
Removal / Installation page S-10
4. Wheel arch molding
Removal / Installation page S-11

OUTLINE

- The exterior body.

OUTLINE OF

Improved a

Improved co

Improved a

BONNET BUL

- Bonnet bulg
a high-qualit

OUTLINE

- The exterior parts are designed to emphasize the function and appearance of the superbly proportioned body.

OUTLINE OF CONSTRUCTION

13E0SX-303

Improved appearance

- Bonnet bulges are provided in bonnet..... S-3
- A large, body-colored front bumper fascia is adopted..... S-4
- Wheel arch moldings are fitted to fenders..... S-5

Improved cooling efficiency


- Air inlet area of radiator grille is enlarged..... S-4
- Bumper mesh is provided in front bumper S-4

Improved aerodynamics

- Rear skirt is attached under rear bumper..... S-5

13E0SX-304

BONNET BULGE




S

13E0SX-305


- Bonnet bulges are fitted to the bonnet to match the dynamic appearance of the vehicle and to give it a high-quality look.

RADIATOR GRILLE




- The air inlet area of the radiator grille is enlarged for improved cooling efficiency.

FRONT BUMPER




- The large front bumper includes fog lights and bumper mesh to give the vehicle a dynamic appearance.
- Light and rigid polyurethane is used for the bumper fascia.
- The air inlet area is adopted for improved cooling efficiency.

REAR SKI




- The rear ski
- Light and

WHEEL ARC



- Wheel arc


REAR SKIRT



13E05X-308

- The rear skirt is added for improved vehicle aerodynamics.
- Light and rigid polyurethane is used.

WHEEL ARCH MOLDING



13E05X-309

- Wheel arch moldings are fitted to the front and rear fenders to give the vehicle an aggressive look.

S

SUPPLEMENTAL SERVICE INFORMATION

SUPPLEMENTAL SERVICE INFORMATION

The following points in this section are changed in comparison with 323 Workshop Manual (1229-10-89L).

BONNET BULGE

- Removal / Installation

FRONT BUMPER

- Removal / Installation

REAR SKIRT

- Removal / Installation

WHEEL ARCH MOLDING

- Removal / Installation

13E0SX-310

BONNET

COMPONENTS


1. Removal
2. Installation



1. Bonnet

BONNET BULGE**COMPONENTS****Removal / Installation**

1. Removal in the order shown in the figure.
2. Install in the reverse order of removal.



1. Bonnet bulge


13E0SX-311

FRONT BUMPER

COMPONENTS

Removal / Installation

1. Removal in the order shown in the figure.
2. Install in the reverse order of removal.



1. Radiator grille
2. Front combination light
3. Headlight

4. Front bumper
- Disassembly / Assembly page S-9


N-m (kgf-m, ft-lbf)
13E0SX-312

Disassembly
1. Disassembly
2. Assembly

1. Fog lights
2. Bumper reinforcement
3. Bumper mounting

Disassembly / Assembly

1. Disassemble in the order shown in the figure.
2. Assemble in the reverse order of disassembly.



1. Fog lights
2. Bumper reinforcement
3. Bumper mesh

4. Hook cover
5. Bumper fascia

13E0SX-313

REAR SKIRT


COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.

Note

- Remove the rear bumper to remove and install the rear skirt.



1. Rear skirt

2. Rear bumper

13E0SX-314

WHEEL

COMPONENTS

Removal /

1. Remove i
2. Install in t


1. Front whe
- Remov.
- Installat

WHEEL ARCH MOLDING

COMPONENTS

Removal / Installation

1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Install in the reverse order of removal, referring to **Installation Note**.



13E05X 315

1. Front wheel arch molding

Removal Note..... page S-12

Installation Note..... page S-13

2. Rear wheel arch molding

Removal Note..... page S-12

Installation Note..... page S-14

S

WHEEL ARCH MOLDING


Removal Note

Front wheel arch molding

The front wheel arch moldings are attached to the body with adhesive and clips as shown in the figure. To remove the molding, pull it forward to unhook the pin and clips, taking care not to damage them.

Note

- If the molding is difficult to remove, soften the adhesive by using a hot air blower.




13E0SX-316

Rear wheel arch molding


The rear wheel arch moldings are attached to the body with adhesive, double-coated adhesive tape, and fasteners. To remove the molding, first remove the fasteners, then pull the molding forward to unhook the pin, taking care not to damage it.

Note


- If the molding is difficult to remove, soften the adhesive and adhesive tape by using a hot air blower.




13E0SX-317




13E0SX-318



13E0SX-319



13E0SX-320



13E0SX-321

Installation Note

Front wheel arch molding

1. Remove the original adhesive from the molding mounting surface of the body.

Caution

- Do not damage the surrounding painted area.

Note

- If the adhesive is difficult to remove, soften it by using a hot air blower.

2. Clean and degrease the molding mounting surface of the body and the bonding area of the molding.
3. Apply primer to the bonding area of the molding and allow it to dry for **approximately 30 minutes**.

Caution


- Keep the area free of dirt, moisture, and grease.
- Do not touch the primed surfaces.

4. Apply urethane adhesive to the bonding area of the molding.


Caution

- The application range of urethane adhesive at each point should be **approximately 5 mm (0.2 in) wide and 60 mm (2.4 in) long**. Do not apply excessive adhesive.


5. Align the molding to the body with the pin and clips, and then install it.
6. Lightly press on the molding to obtain good adherence.



13E0SX-322



13E0SX-323



13E0SX-324

Rear wheel arch molding

1. Remove the original adhesive from the molding mounting surface of the body.

Caution

- Do not damage the surrounding painted area.

Note

- If the adhesive is difficult to remove, soften it by using a hot air blower.

2. Clean and degrease the molding mounting surface of the body and the bonding area of the molding.
3. Apply primer to the bonding area of the molding and allow it to dry for **approximately 30 minutes**.

Caution

- Keep the area free of dirt, moisture, and grease.
- Do not touch the primed surfaces.

4. Apply strips of double-coated adhesive tape to the bonding area of the molding.


Note

- Use 40 mm {1.6 in} lengths of tape.

5. Apply urethane adhesive to the bonding area of the molding.

Caution

- The application range of urethane adhesive should be **approximately 5 mm {0.2 in} wide and 60 mm {2.4 in} long**. Do not apply excessive adhesive.



13E0SX-325

6. Peel the protection paper from the double-coated adhesive tape.
7. Align the molding to the body with the pin, and then install it.
8. Lightly press on the molding to obtain good adherence.
9. Install the fasteners.

BODY ELECTRICAL SYSTEM

INDEX T- 2

FEATURES


OUTLINE T- 3
FEATURES T- 3
LIGHTING SYSTEM T- 3
SPECIFICATIONS T- 3

SERVICE

SUPPLEMENTAL SERVICE
INFORMATION T- 4
EXTERIOR LIGHTING SYSTEM T- 4
FRONT FOG LIGHT T- 4

13E0TX:301

INDEX



1. Front fog light
Removal / Installation page T-4

13E0TX-3C2

OUTLINE

FEATURES

To improv

To improv

LIGHTING

SPECIFIC

Front fog li

OUTLINE

FEATURES


To improve marketability

To improve visibility

Front fog lights are used

13E0TX-303

LIGHTING SYSTEM



T

13E0TX-304

SPECIFICATIONS

Item	Wattage (w)
Front fog light	55 x 2

T SUPPLEMENTAL SERVICE INFORMATION, EXTERIOR LIGHTING SYSTEM

SUPPLEMENTAL SERVICE INFORMATION

The following points shown in this section are changed in comparison with 323 Workshop manual supplement (1229-10-89L) and 323 Workshop manual supplement (1275-10-91C).

Front fog light

- Removal / Installation


13E0TX-305

EXTERIOR LIGHTING SYSTEM

FRONT FOG LIGHT

Removal / Installation

1. Remove in the order shown in the figure.
2. Install in the reverse order of removal.



13E0TX-306

1. Radiator grille
2. Front combination light
3. Headlight

4. Front bumper
5. Front fog light

TECHNICAL DATA

ENGINE.....	TD- 2
LUBRICATION SYSTEM.....	TD- 4
COOLING SYSTEM.....	TD- 5
FUEL AND EMISSION CONTROL SYSTEMS.....	TD- 6
ENGINE ELECTRICAL SYSTEM.....	TD- 7
CLUTCH.....	TD- 7
MANUAL TRANSAXLE AND TRANSFER....	TD- 8
PROPELLER SHAFT.....	TD-10
FRONT AND REAR AXLES.....	TD-10
STEERING SYSTEM.....	TD-11
BRAKING SYSTEM.....	TD-11
WHEELS AND TIRES.....	TD-12
SUSPENSION.....	TD-13
BODY ELECTRICAL SYSTEM.....	TD-14
STANDARD BOLT AND NUT TIGHTENING TORQUE.....	TD-14

13ETDX-301

ENGINE (BP DOHC turbo)

Item		Engine	BP DOHC turbo
Type			Gasoline, 4-cycle
Cylinder arrangement and number			In-line 4-cylinders
Combustion chamber			Pentroof
Valve system			DOHC, belt-driven 16 valves
Bore x Stroke		mm {in}	83.0 x 85.0 {3.27 x 3.35}
Total piston displacement		cm ³ {cu in}	1,839 {112.2}
Compression ratio			8.2
Compression pressure kPa {kgf/cm ² , psi}-rpm	Standard		1,127 {11.5, 164}-300
	Minimum		785 {8.0, 114}-300
	Maximum difference between each cylinder		196 {2.0, 28}
Valve timing	IN	Open BTDC	2°
		Close ABDC	51°
	EX	Open BBDC	59°
		Close ATDC	8°
Valve clearance	mm {in}	IN	0: Maintenance-free
		EX	0: Maintenance-free
Cylinder head			
Height		mm {in}	133.8—134.0 {5.268—5.276}
Distortion		mm {in}	0.10 {0.004} max.
Grinding		mm {in}	0.10 {0.004} max.
Cylinder head-to-HLA clearance	mm {in}	Standard	0.025—0.066 {0.0010—0.0026}
		Maximum	0.18 {0.0071}
Valve and valve guide			
Valve head diameter	mm {in}	IN	32.9—33.1 {1.295—1.303}
		EX	27.85—28.15 {1.096—1.108}
Valve head margin thickness	mm {in}	IN	0.85—1.35 {0.0335—0.0531}
		EX	0.925—1.475 {0.0364—0.0581}
Valve face angle		IN	45°
		EX	45°
Valve length	IN	Standard	101.34 {3.990}
		Minimum	100.84 {3.970}
	EX	Standard	101.44 {3.994}
		Minimum	100.94 {3.974}
Valve stem diameter	mm {in}	IN	5.970—5.985 {0.2350—0.2356}
		EX	5.965—5.980 {0.2348—0.2354}
Guide inner diameter		mm {in}	6.01—6.03 {0.2366—0.2374}
Valve stem-to-guide clearance	mm {in}	IN	0.025—0.060 {0.0010—0.0024}
		EX	0.030—0.065 {0.0012—0.0026}
		Maximum	0.20 {0.008}
Guide projection (Height "A")	mm {in}	IN	18.3—18.9 {0.720—0.744}
		EX	18.3—18.9 {0.720—0.744}
Valve seat			
Seat angle		IN	45°
		EX	45°
Seat contact width	mm {in}	IN	0.8—1.4 {0.031—0.055}
		EX	0.8—1.4 {0.031—0.055}
Seat sinking	IN	Standard	44.55—45.45 {1.7539—1.7894}
		Maximum	46.5 {1.831}
	EX	Standard	44.55—45.45 {1.7539—1.7894}
		Maximum	46.5 {1.831}
Valve spring			
Free length	mm {in}	Standard	46.26 {1.821}
		Minimum N {kgf, lbf}/mm {in}	224—253 {22.8—25.8, 50—57}/39.5 {1.555}
Out-of-square		mm {in}	1.62 {0.064} max.

Item
Camshaft
Cam height
Journal diam
Camshaft bea
Camshaft run
Camshaft enc
Cylinder blo
Height
Distortion
Grinding
Cylinder bore
Cylinder bore
Piston
Piston diam
Measured at
bore axis and
{0.433 in} to
groove
Piston to cyl
Piston ring
Thickness
End gap (Me
Ring groove
Piston ring-c
Piston pin
Diameter
Piston-to-pist
Connecting
Connecting
Length (Cen
Bending
Small end b
Big end bor
Big end wid
Connecting
Crankshaft
Crankshaft r

Item		Engine	BP DOHC turbo
Camshaft			
Cam height	mm {in}	IN	Standard
			44.094 {1.7360}
	EX	Wear limit	43.894 {1.7281}
		Standard	44.603 {1.7560}
		Wear limit	44.403 {1.7481}
Journal diameter	mm {in}	Standard (No.1—No.5)	25.940—25.965 {1.0213—1.0222}
		Out-of-round	0.05 {0.002} max.
Camshaft bearing oil clearance	mm {in}	Standard (No.1—No.5)	0.035—0.081 {0.0014—0.0032}
		Maximum	0.15 {0.006}
Camshaft runout	mm {in}		0.03 {0.0012} max.
Camshaft end play	mm {in}	Standard	0.07—0.19 {0.0028—0.0075}
		Maximum	0.2 {0.008}
Cylinder block			
Height	mm {in}		221.5 {8.720}
Distortion	mm {in}		0.15 {0.006} max.
Grinding	mm {in}		0.20 {0.008} max.
Cylinder bore diameter	mm {in}	Standard size	83.006—83.013 {3.2679—3.2682}
		0.25 {0.010} oversize	83.256—83.263 {3.2778—3.2781}
		0.50 {0.020} oversize	83.506—83.513 {3.2876—3.2879}
Cylinder bore taper and out-of-round	mm {in}		0.019 {0.0007} max.
Piston			
Piston diameter Measured at 90° to pin bore axis and 11.0mm {0.433 in} below oil ring groove	mm {in}	Standard size	82.954—82.974 {3.2659—3.2667}
		0.25 {0.010} oversize	83.211—83.217 {3.2760—3.2763}
		0.50 {0.020} oversize	83.461—83.467 {3.2859—3.2861}
Piston to cylinder clearance	mm {in}	Standard	0.039—0.052 {0.0015—0.0020}
		Maximum	0.15 {0.006}
Piston ring			
Thickness	mm {in}	Top	1.470—1.495 {0.0579—0.0589}
		Second	1.47—1.49 {0.0579—0.0587}
End gap (Measured in the cylinder)	mm {in}	Top	0.15—0.30 {0.006—0.012}
		Second	0.35—0.50 {0.014—0.019}
		Oil (rail)	0.20—0.70 {0.008—0.028}
		Maximum	1.0 {0.039}
Ring groove width in piston	mm {in}	Top	1.520—1.535 {0.0598—0.0604}
		Second	1.52—1.54 {0.0598—0.0606}
		Oil	3.02—3.04 {0.1189—0.1197}
Piston ring-to-ring groove clearance	mm {in}	Top	0.025—0.065 {0.0010—0.0026}
		Second	0.03—0.07 {0.0012—0.0028}
		Maximum	0.15 {0.006}
Piston pin			
Diameter	mm {in}		19.987—19.993 {0.7869—0.7871}
Piston-to-piston pin clearance	mm {in}		−0.005—0.013 {−0.0002—0.0005}
Connecting rod bush-to-piston pin clearance	mm {in}		0.010—0.027 {0.0004—0.0011}
Connecting rod and connecting rod bearing			
Length (Center to center)	mm {in}		132.85—132.95 {5.230—5.234}
Bending	mm {in}		0.075 {0.0030} max./50 {1.97}
Small end bore (Bush inner diameter)	mm {in}		20.003—20.014 {0.7875—0.7880}
Big end bore	mm {in}		48.000—48.016 {1.8898—1.8904}
Big end width	mm {in}		21.838—21.890 {0.8598—0.8618}
Connecting rod side clearance	mm {in}	Standard	0.110—0.262 {0.0043—0.0103}
		Maximum	0.30 {0.012}
Crankshaft			
Crankshaft runout	mm {in}		0.04 {0.0016} max.

TD

Item		Engine	BP DOHC turbo
Main journal diameter mm [in]	Standard size	Standard	49.938—49.956 [1.9661—1.9668]
		Minimum	49.904 [1.9647]
	0.25 [0.010] undersize	Standard	49.704—49.708 [1.9568—1.9570]
		Minimum	49.652 [1.9548]
	0.50 [0.020] undersize	Standard	49.454—49.458 [1.9470—1.9472]
		Minimum	49.402 [1.9450]
0.75 [0.030] undersize	Standard	49.204—49.208 [1.9372—1.9373]	
	Minimum	49.152 [1.9351]	
Main journal taper and out-of-round		mm [in]	0.05 [0.020] max.
Crankpin diameter mm [in]	Standard size	Standard	44.940—44.956 [1.7693—1.7699]
		Minimum	44.908 [1.7680]
	0.25 [0.010] undersize	Standard	44.690—44.706 [1.7594—1.7601]
		Minimum	44.658 [1.7582]
	0.50 [0.020] undersize	Standard	44.440—44.456 [1.7496—1.7502]
		Minimum	44.408 [1.7483]
0.75 [0.030] undersize	Standard	44.190—44.206 [1.7398—1.7404]	
	Minimum	44.158 [1.7385]	
Crankpin taper and out-of-round		mm [in]	0.05 [0.020] max.
Main bearing			
Main journal bearing oil clearance		Standard	0.018—0.036 [0.0007—0.0014]
mm [in]		Maximum	0.10 [0.004]
Available undersized bearing		mm [in]	0.25 [0.010], 0.50 [0.020], 0.75 [0.030]
Crankpin bearing			
Crankpin bearing oil clearance		Standard	0.028—0.068 [0.0011—0.0027]
mm [in]		Maximum	0.10 [0.004]
Available undersized bearing		mm [in]	0.25 [0.010], 0.50 [0.020], 0.75 [0.030]
Thrust bearing			
Crankshaft end play		Standard	0.080—0.282 [0.0031—0.0111]
mm [in]		Maximum	0.30 [0.0118]
Bearing width	Standard size		2.500—2.550 [0.0984—0.1004]
	0.25 [0.010] oversize		2.625—2.675 [0.1033—0.1053]
	0.50 [0.020] oversize		2.750—2.800 [0.1083—0.1102]
	0.75 [0.030] oversize		2.875—2.925 [0.1132—0.1152]
Timing belt			
Belt deflection		mm [in]/98 N [10 kgf, 22 lbf]	9.0—11.5 [0.35—0.45]

LUBRICATION SYSTEM

Item		Engine	BP DOHC turbo
Lubricating method			Force-fed
Oil pump			
Type			Trochoid gear
Relief pressure		kPa [kgf/cm ² , psi]	343—441 [3.5—4.5, 50—64]
Regulated pressure		kPa [kgf/cm ² , psi]-rpm	294—392 [3.0—4.0, 43—57]-3,000
Inner rotor tooth tip to outer rotor clearance	mm [in]	Standard	0.02—0.16 [0.0008—0.0063]
		Maximum	0.20 [0.0078]
Outer rotor to body clearance	mm [in]	Standard	0.09—0.18 [0.0035—0.0071]
		Maximum	0.22 [0.0087]
Side clearance	mm [in]	Standard	0.03—0.11 [0.0012—0.0043]
		Maximum	0.14 [0.0055]
Oil filter			
Type			Full-flow, paper element
Relief pressure differential		kPa [kgf/cm ² , psi]	78—118 [0.8—1.2, 11—17]

Item	
Engine oil	
Capacity	L [U]
Grade	
Viscosity number	A
	D
	A
	E

COOLING SYSTEM

Item	
Cooling method	
Water pump	
Type	
Impeller diameter	
Number of impellers	
Speed ratio	
Water seal type	
Thermostat	
Type	
Opening temperature	
Full-open temperature	
Full-open lift	
Radiator	
Type	
Cap valve opening pressure	
Cooling circuit	
Cooling fan	
Type	
Number of fans	
Outer diameter	
Capacity	
Current	
Water thermostat	
OFF—ON	
Radiator thermostat	
OFF—ON	
Coolant	
Capacity	
Antifreeze concentration	

Item		Engine	BP DOHC turbo
Engine oil			
Capacity L (US qt, Imp qt)	Total (dry engine)		4.0 (4.2, 3.5)
	Oil pan		3.6 (3.8, 3.2)
	Oil filter		0.17 (0.18, 0.15)
Grade			API Service SD, SE, SF or SG
Viscosity number	Above 30°C (86°F)		SAE 40
	0°C—40°C (32°F—104°F)		SAE 30
	−10°C—20°C (14°F—68°F)		SAE 20W-20
	Above −10°C (14°F)		SAE 20W-40 or 20W-50
	−25°C—30°C (−13°F—86°F)		SAE 10W-30
	Above −25°C (−13°F)		SAE 10W-40 or 10W-50
	Below 0°C (32°F)		SAE 5W-30
	Below −20°C (−4°F)		SAE 5W-20

COOLING SYSTEM

Item		Engine	BP DOHC turbo
Cooling method			Water-cooled, forced circulation
Water pump			
Type			Centrifugal, V-belt driven
Impeller diameter	mm (in)		75 (2.95)
Number of impeller blades			6
Speed ratio			1 : 1.05
Water seal type			Unified mechanical seal
Thermostat			
Type			Wax, two-stage
Opening temperature	°C (°F)		Main: 86.5—89.5 (188—193) Sub: 83.5—86.5 (182—188)
Full-open temperature	°C (°F)		100 (212)
Full-open lift	mm (in)		Main: 8.0 (0.31) min. Sub: 1.5 (0.06) min.
Radiator			
Type			Corrugated fin
Cap valve opening pressure	kPa (kgf/cm ² , psi)		74—103 (0.75—1.05, 11—15)
Cooling circuit checking pressure	kPa (kgf/cm ² , psi)		103 (1.05, 15)
Cooling fan			
Type			Electric
Number of blades			5
Outer diameter	mm (in)		340 (13.4)
Capacity	W-V		160-12
Current	A		Hi: 13.3 + 10% max., Lo: 8.8 + 10% max.
Water thermostwitch			
OFF→ON	°C (°F)		97 (207)
Radiator thermostwitch			
OFF→ON	°C (°F)		105 (221)
Coolant			
Capacity	L (US qt, Imp qt)		6.0 (6.3, 5.3)
Antifreeze solution	Coolant protection		Specific gravity at 20°C (68°F)
	Above −16°C (3°F)		1.054
	Above −26°C (−15°F)		1.066
	Above −40°C (−40°F)		1.078

TD

FUEL AND EMISSION CONTROL SYSTEMS

Item		Engine	BP DOHC turbo
Idle speed		rpm	800 ± 50
Ignition timing*		BTDC	10 ± 1°
Fuel pump			
Maximum output pressure		kPa {kgf/cm ² , psi}	490—736 {5.0—7.5, 71—110}
Transfer pump			
Maximum output pressure		kPa {kgf/cm ² , psi}	39 {0.4, 5.7} or higher
Fuel filter			
Type	Low-pressure side		Nylon element (in fuel pump)
	High-pressure side		Paper element
Pressure regulator			
Regulating pressure	Low	kPa {kgf/cm ² , psi}	265—314 {2.7—3.2, 38—46}
	High	kPa {kgf/cm ² , psi}	304—392 {3.1—4.0, 44—57}
Injector			
Type		Low-ohmic	
Type of drive		Electromechanical	
Resistance		Ω	Approx. 2.11 Ω [at 20°C {68°F}]
Injector resistor			
Resistance/injector		Ω	6 [at 20°C {68°F}]
Idle-speed control (ISC) valve			
Type		Rotary	
Resistance		Ω	11—13 [at 20°C {68°F}]
Solenoid valve (purge control)			
Resistance		Ω	23—27 [at 20°C {68°F}]
Solenoid valve (wastegate)			
Resistance		Ω	33—39 [at 20°C {68°F}]
Solenoid valve (PRC)			
Resistance	Low temp.	Ω	33—39 [at 20°C {68°F}]
	High temp.	Ω	33—39 [at 20°C {68°F}]
Water thermosensor			
Resistance	kΩ	-20°C { -4°F }	14.6—17.8
		20°C { 68°F }	2.21—2.69
		40°C {104°F }	1.0—1.3
		80°C {176°F }	0.29—0.35
Airflow meter			
Resistance	E2↔Vs	Fully closed	20—600
		Fully open	20—1,000
	E2↔Vc		200—400
	E2↔THAA (intake air thermosensor)	-20°C { -4°F }	13,600—18,400
		20°C { 68°F }	2,210—2,690
		60°C {140°F }	493—667
	E1↔Fc	Fully closed	∞
Fully open		0	
Oxygen sensor (ceramic heater coil)			
Resistance		Ω	Approx. 6 [at 20°C {68°F}]
Fuel tank			
Capacity		L {US gal, Imp gal}	60 {15.9, 13.2}
Air cleaner			
Element type		Oil permeated	
Fuel			
Specification		Unleaded premium (RON 95 or higher)	

* TEN terminal of diagnosis connector grounded.

ENGINE EL

Item
Battery
Dark current*
Alternator
Starter
Distributor sp
Ignition timing (TEN terminal)
Ignition coil
Spark plug

*1 Dark current

*2 Standard pl

ENGINE ELECTRICAL SYSTEM

Item			Engine	BP DOHC turbo
Battery	Voltage		V	12
	Type and capacity (20-hour rate)			55D23L (60Ah)
Dark current ^{*1}			mA	Max. 20.0
Alternator	Type			A.C.
	Output		V-A	12-70
	Regulator type			Transistorized (built-in IC regulator)
	Regulated voltage		V	14.1—14.7
	Brush length	mm [in]	Standard	21.5 [0.846]
			Minimum	8.0 [0.32]
	Drive belt deflection	98 N {10 kgf, 22 lbf} mm [in]	New	5.5—7.0 [0.22—0.27]
			Used	6.0—7.5 [0.24—0.29]
Limit			8.0 [0.31]	
Starter	Type			Direct
	Output		V-kW	12-0.85
	Brush length	mm [in]	Standard	17 [0.67]
			Minimum	11.5 [0.46]
Distributor spark advance				Electronic spark advance (ESA)
Ignition timing (TEN terminal of diagnosis connector grounded)			BTDC	10 ± 1°
Ignition coil	Resistance (at 20°C {68°F})	Primary coil winding		0.81—0.99Ω
		Secondary coil winding		10—16 kΩ
Spark plug	Type	NGK		BKR6EVX11 ^{*2} / BKR5EVX11 BKR7EVX11
		NIPPONDENSO		K20PR-TP11 ^{*2} / K16PR-TP11 K22PR-TP11
	Plug gap		mm [in]	1.0—1.1 [0.039—0.043]
	Firing order			1—3—4—2

*1 Dark current is the constant flow of current while the ignition switch is OFF. (i.e., engine control unit, EC-AT control unit, audio, etc.)

*2 Standard plug

CLUTCH

Engine/Transaxle		BP DOHC turbo
Item		G25MX-R (G5MX-R)
Clutch control		Hydraulic
Clutch pedal		
Type		Suspended
Pedal ratio	mm [in]	6.55
Full stroke	mm [in]	135 [5.31]
Height (With carpet)	mm [in]	196—204 [7.72—8.03]
Free play	mm [in]	5.5—17.4 [0.22—0.69]
Distance to carpet when clutch fully disengaged	mm [in] Minimum	41.0 [1.61]
Flywheel		
Runout limit	mm [in]	0.200 [0.0079]
Clutch disc		
Type		Single dry plate
Runout limit	mm [in]	0.700 [0.0276]
Wear limit	mm [in]	0.3 [0.012] from rivet head
Outer diameter	mm [in]	230 [9.05]
Inner diameter	mm [in]	155 [6.10]
Facing thickness	mm [in] Flywheel side	3.5 [0.14]
	Pressure plate side	3.5 [0.14]
Clutch cover		
Type		Diaphragm spring
Set load	N [kgf, lbf]	5,494 [560, 1,232]
Clutch fluid		
Type		SAE J1703 or FMVSS116 DOT-3

MANUAL TRANSAXLE AND TRANSFER

Engine		BP DOHC turbo
Item		G25MX-R (G5MX-R)
Specification		
Transaxle type		Floor shift
Transaxle control		Cable
Transaxle shift control		
Syncromesh system		Forward: Syncromesh Reverse: Selective sliding and syncromesh
Gear ratio	1st	3.454
	2nd	1.833
	3rd	1.310
	4th	0.970
	5th	0.717
	Reverse	3.166
Final gear ratio		4.214
Speedometer gear ratio (Driven gear/drive gear)		1.045 (23/22)
Oil	Grade	API service GL-4
	Viscosity	All-season: ATF Dexron®II or M-III Above -18°C (0°F): SAE 75W-90
	Capacity L [US qt, Imp qt]	2.6 [2.7, 2.2]
Runout		
Primary shaft gear runout		mm [in] 0.050 [0.0020]
Secondary shaft gear runout		mm [in] 0.015 [0.0006]
Clearance		
1st (Gear inner dia. -shaft outer dia)		mm [in] 0.030—0.080 [0.0012—0.0031]
2nd (Gear inner dia. -shaft outer dia)		mm [in] 0.030—0.080 [0.0012—0.0031]
3rd (Gear inner dia. -shaft outer dia)		mm [in] 0.030—0.080 [0.0012—0.0031]
4th (Gear inner dia. -shaft outer dia)		mm [in] 0.030—0.080 [0.0012—0.0031]
5th (Gear inner dia. -shaft outer dia)		mm [in] 0.030—0.080 [0.0012—0.0031]

Item		Engine	BP DOHC turbo
1-2 shift fork and reverse gear mm (in)	Standard		0.10—0.45 {0.004—0.018}
	Wear limit		0.95 {0.037}
3-4 shift fork and clutch hub sleeve mm (in)	Standard		0.10—0.40 {0.004—0.016}
	Wear limit		0.90 {0.035}
5th shift fork and clutch hub sleeve mm (in)	Standard		0.10—0.36 {0.004—0.014}
	Wear limit		0.86 {0.034}
Reverse idle gear and reverse lever mm (in)	Standard		0.10—0.35 {0.004—0.014}
	Wear limit		0.85 {0.033}
Thrust clearance			
1st gear mm (in)	Standard		0.05—0.28 {0.002—0.011}
	Limit		0.33 {0.013}
2nd gear mm (in)	Standard		0.18—0.46 {0.007—0.018}
	Limit		0.51 {0.020}
3rd gear mm (in)	Standard		0.05—0.20 {0.002—0.008}
	Limit		0.25 {0.010}
4th gear mm (in)	Standard		0.17—0.37 {0.007—0.015}
	Limit		0.42 {0.017}
5th gear mm (in)	Standard		0.100—0.220 {0.0039—0.0087}
	Limit		0.270 {0.0106}
Primary shaft gear mm (in)	Standard		0—0.05 {0—0.002}
	Adjustment shims		0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028}
Secondary shaft gear mm (in)	Standard		0.03—0.08 {0.001—0.003}
	Adjustment shims		0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028}
Center differential			
Type		Planetary carrier	
Number of ring gear teeth	Outer		59
	Inner		75
Number of pinion gear teeth	Outer		14
	Inner		14
Number of sun gear teeth	Pinion gear side		43
	Idle gear side		43
Number of idle-gear teeth			37
Bearing preload Nm {kgf-cm, inlbf}			3.0—3.9 {30—40, 27—34}
Bearing preload adjustment shim mm (in)			0.10 {0.004}, 0.20 {0.008}, 0.25 {0.010}, 0.30 {0.012}, 0.35 {0.014}, 0.40 {0.016}, 0.45 {0.018}, 0.50 {0.020}, 0.55 {0.022}, 0.60 {0.024}, 0.65 {0.026}, 0.70 {0.028}, 0.75 {0.030}, 0.80 {0.031}, 0.85 {0.033}, 0.90 {0.035}, 0.95 {0.037}, 1.00 {0.039}, 1.05 {0.041}, 1.10 {0.043}, 1.15 {0.045}, 1.20 {0.047}
End play of ring gear mm (in)			0.15—0.30 {0.006—0.012}
Ring gear end play adjustment washer mm (in)			1.20 {0.047}, 1.35 {0.053}, 1.50 {0.059}, 1.65 {0.065}, 1.80 {0.071}
End play of sun gear mm (in)			0.100—0.300 {0.0039—0.0118}
Sun gear adjustment washer mm (in)			3.5 {0.138}, 3.7 {0.146}, 3.9 {0.154}, 4.1 {0.161}, 4.3 {0.169}
Transfer Carrier			
Final gear reduction ratio			4.214
Number of teeth	Ring gear		37
	Pinion gear		11
Oil	Type		API: GL-5 Above -18°C {0°F}: SAE 90 Below -18°C {0°F}: SAE 80W
	Capacity L {US qt, Imp qt}		0.5 {0.53, 0.44}

TD

Item		Engine	BP DOHC turbo
Note			
Synchronizer ring outer diameter mm [in]	1st and 2nd		67.7 [2.665]
	3rd and 4th		67.7 [2.665]
	5th and reverse		55.7 [2.192]
Synchronizer key dimension mm [in]	1st and 2nd	① 19.0 [0.748], ② 4.3 [0.17], ③ 5.0 [0.20]	
	3rd and 4th	① 17.0 [0.669], ② 4.3 [0.17], ③ 5.0 [0.20]	
	5th and reverse	① 17.0 [0.669], ② 4.3 [0.17], ③ 5.0 [0.20]	

PROPELLER SHAFT

Item		Engine/Transaxle Model	BP DOHC turbo G25MX-R (G5MX-R)
Length mm [in]	Front		834.3 [32.85]
	Center		584 [22.99]
	Rear		437 [17.20]
Outer diameter mm [in]	Front		75 [2.95]
	Center		57 [2.24]
	Rear		57 [2.24]

FRONT AND REAR AXLES

Item		Specifications
Front driveshaft		
Joint type	Inside	Double offset joint
	Outside	Bell joint
Length of joint (between center of joint) mm [in]	Right	392 [15.4]
	Left	306 [0.83]
Shaft diameter	mm [in]	21.0 [0.83]
Rear driveshaft		
Joint type	Inside	Double offset joint
	Outside	Bell joint
Length of joint (between center of joint) mm [in]	Right	519.5 [20.5]
	Left	489.5 [19.3]
Shaft diameter	mm [in]	21.0 [0.83]
Joint shaft		
Length of joint		357.2 [14.1]
Shaft diameter		21.0 [0.83]
Front axle		
Bearing play axial direction	mm [in]	0.050 [0.002]
Rear axle		
Bearing play axial direction	mm [in]	0.050 [0.002]
Rear differential (viscous limited slip differential)		
Reduction gear		Hypoid gear
Differential gear		Straight bevel gear
Differential ratio		3.909
Number of teeth	Ring gear	43
	Drive pinion gear	11
Fluid	Grade	API Service GL-5
	Viscosity	SAE 90
		SAE 80W
	Capacity L [US qt, Imp qt]	0.65 [0.69, 0.57]

STEERING SY

Steering wheel	
Outer diameter	
Free play	
Operation force	
Lock-to-lock	
Steering gear	
Type	
Steering gear ratio	
Backlash between	
Pinion preload	Preload
Distance between	
Rack stroke	
Lubricant type	
Oil capacity	
Drive belt	
Deflection with	

BRAKING SY

Brake type
Brake pedal
Height
Free play
Reserve travel
Clearance when
Master cylinder
Master cylinder
Front disc brake
Type
Thickness of pad
Thickness of disc
Runout of disc
Cylinder bore
Rear brake (disc)
Type
Thickness of pad
Thickness of disc
Runout of disc
Cylinder bore
Parking brake
Type
Parking brake lever
When lever is

STEERING SYSTEM

Item		Specifications
Steering wheel		
Outer diameter	mm [in]	370 [14.57]
Free play	mm [in]	0—30 [0—1.18]
Operation force	N [kgf, lbf]	29 [3.0, 6.6] or less
Lock-to-lock		2.51
Steering gear		
Type		Rack and pinion
Steering gear ratio		Infinite (∞)
Backlash between rack and pinion	mm [in]	0 [0]
Pinion preload	Nm [kgf·cm, inlbf]	1.0—1.3 [10—14, 8.7—12.1]
	Preload measured by torque wrench	
	kgf [lbf]	1.0—1.4 [2.2—3.08]
	Preload measured by pull scale with attachment	
Distance between left and right brackets	mm [in]	258 [10.16]
Rack stroke	mm [in]	121 [4.76]
Lubricant type		ATF Dexron®II or M-III
Oil capacity	L [US qt, Imp qt]	0.8 [0.85, 0.70]
Drive belt		
Deflection with force of 98 N [10 kgf, 22 lbf]	mm [in]	New belt: 8—9 [0.31—0.35] Used belt: 9—10 [0.35—0.39]

BRAKING SYSTEM

Item			Without ABS	With ABS
Brake type			Front disc, Rear disc	
Brake pedal				
Height	mm [in]	203—206 [7.99—8.11]		
Free play	mm [in]	4—7 [0.16—0.28]		12—15 [0.47—0.59]
Reserve travel	mm [in]	70 [2.76] min		
Clearance when pedal depressed at 589 N [60 kgf, 132 lbf]				
Master cylinder				
Master cylinder	Type	Tandem		
	Bore diameter	mm [in]	25.4 [1.00]	23.8 [0.94]
Front disc brake				
Type			Ventilated	
Thickness of pad	mm [in]	Standard	10 [0.39]	
		Minimum	2 [0.08]	
Thickness of disc plate	mm [in]	Standard	24 [0.94]	
		Minimum	22 [0.79]	
Runout of disc plate	mm [in]	0.1 [0.004]		
Cylinder bore	mm [in]	57.2 [2.25]		
Rear brake (disc)				
Type			Solid	
Thickness of pad	mm [in]	Standard	8.0 [0.31]	
		Minimum	1 [0.04]	
Thickness of disc plate	mm [in]	Standard	10 [0.39]	
		Minimum	8 [0.31]	
Runout of disc plate	mm [in]	0.1 [0.004]		
Cylinder bore	mm [in]	34.9 [1.37]		
Parking brake				
Type			Mechanical two-rear-wheel control	
Parking brake lever notches		5—7		
When lever is pulled at 98N [10 kgf, 22 lbf]				

Item	Without ABS	With ABS
Power brake unit		
Diameter mm [in]	188.4 {7.42} + 215.2 {8.47}	—
Fluid pressure per treading force kPa [kgf/cm ² , psi]/N [kgf, lbf]	More than 1,080 {11.156}/ 196 {20.44} at 0 kPa [mmHg, inHg] More than 8,730 {89.1270} /196 {20.44} at 66.7 {500, 19.7} kPa [mmHg, inHg]	—
Rear wheel hydraulic control system		
Type	Dual proportioning valve	Proportioning valve
Switching point (Master cylinder pressure) kPa [kgf/cm ² , psi]	1,960 {20, 284}	

WHEELS AND TIRES

Item		Type	Standard	Temporary Spare
Wheel	Size		5 1/2-JJx15	4-Tx15
	Offset mm [in]		47.5 {1.87}	45 {1.77}
	Pitch circle diameter mm [in]		114.3 {4.50}	
	Material		Aluminum alloy	Steel
Tire	Size		195/50R15 82V	T125/70D15
	Air pressure kPa [kgf/cm ² , psi]	Front	*1200 {2.4, 35} *245 {2.5, 36}	412 {4.2, 60}
		Rear	*1216 {2.2, 32} *245 {2.5, 36}	
Wheel and tire	Runout limit mm [in]	Horizontal	2.0 {0.079}	2.5 {0.098}
		Vertical	1.5 {0.059}	2.0 {0.079}
	Unbalance g [oz]		9 {0.31}	—

*1... Up to 3 persons

*2... — Full load

SUSPENSION

Front suspension
Suspension type
Spring type
Shock absorber
Stabilizer
Front wheel alignment (*Unladen)
Rear suspension
Suspension type
Spring type
Shock absorber
Stabilizer
Rear wheel alignment (*Unladen)

* Fuel tank full

Coil Spring

Item	Front	Rear
Width	With	With
Width	With	With

*1 Main idler

*2 Auxiliary

SUSPENSION

Item			Specifications
Front suspension			
Suspension type			Strut
Spring type			Coil spring
Shock absorber	Type		Oil
	Damping force N (kgf, lbf) at 0.3 m/s	Extended	1,470 (150, 330)
		Compressed	686 (70, 154)
Stabilizer	Type		Torsion bar
	Diameter mm (in)		23.0 (0.91)
Front wheel alignment (* Unladen)	Total toe-in	mm (in)	2 ± 3 (0.08 \pm 0.12)
		degree	$0^{\circ}12' \pm 18'$
	Turning angle	Inner	$38^{\circ} \pm 3^{\circ}$
		Outer	$30^{\circ} \pm 3^{\circ}$
	Camber angle	degree	$-0^{\circ}45' \pm 45'$
	Caster angle	degree	$2^{\circ}35' \pm 45'$
	Kingpin angle	degree	$12^{\circ}10'$
Rear suspension			
Suspension type			Strut
Spring type			Coil spring
Shock absorber	Type		Oil
	Damping force N (kgf, lbf) at 0.3 m/s	Extended	882 (90, 198)
		Compressed	392 (40, 88)
Stabilizer	Type		Torsion bar
	Diameter mm (in)		19.1 (0.75)
Rear wheel alignment (* Unladen)	Total toe-in	mm (in)	2 ± 3 (0.08 \pm 0.12)
		degree	$0^{\circ}12' \pm 18'$
	Camber angle	degree	$-0^{\circ}20' \pm 45'$

* Fuel tank full, radiator coolant and engine oil at specified levels; and spare tire, jack, and tools in designated positions.

Coil Spring Specifications

Item		Wire diameter mm (in)	Coil center diameter mm (in)	Free length mm (in)	Coil number	Identification mark color	
						M ^{*1}	A ^{*2}
Front	With sunroof	14.5 (0.57)	132.5—158.5 (5.22—6.24)	271.5 (10.69)	3.35	Pink	Green
	Without sunroof	14.4 (0.56)	132.6—158.6 (5.22—6.24)	267.0 (10.51)	3.24	Light blue	Red
Rear	With sunroof	8.8—12.5 (0.34—0.49)	128.5—131.2 (5.05—5.17)	334 (13.15)	6.19	Cream	—
	Without sunroof	8.9—12.4 (0.35—0.48)	128.6—131.1 (5.06—5.16)	335 (13.19)	6.23	Pink	—

*¹ Main identification mark color: Indicated on second coil from bottom.

*² Auxiliary identification mark color: Indicated on third coil from bottom.

BODY ELECTRICAL SYSTEM

Item			Specifications (W)	
			ECE	Swiss
Exterior lamps	Headlight		60/55	
	Front fog light		55	
	Front turn signal light		21	
	Parking light		5	
	Front side turn light		5	
	Stop/Tailight		21/5	
	Tailight (3HB)		5	
	Rear turn single light		21	
	Back-up light		21	
	License plate light		5	
	Flash-to-pass light		55 (Austria)	—
	Running light		55 (Sweden, Norway, Iceland)	
	Rear fog light		21	
Interior lamps	Interior and spot lamp	Interior	10	
		Spot	6	
	Interior lamp		10	
	Spot lamp (in overhead console)		8	
	Cargo compartment lamp		5	
Indicator and warning lamps	High beam		3.4	
	Turn light		3.4	
	Brake		3	
	Hold		3	
	Charge		3	
	Oil pressure		3	
	Washer		3	
	Turbo		3	
	Fuel		3	
	Rear fog		3	
	ABS		3	
	Parking brake		3	
	Illumination		3.4	
	Rear		3	
	Diff. lock		3	

STANDARD BOLT AND NUT TIGHTENING TORQUE

Diameter mm (in)	Pitch mm (in)	4T			6T			8T		
		N-m	m-kp	ft-lb	N-m	m-kp	ft-lb	N-m	m-kp	ft-lb
6 {0.236}	1 {0.039}	4.2—6.2	0.43—0.63	3.1—4.6	6.9—9.8	0.7—1.0	5.0—7.2	7.8—11.8	0.8—1.2	5.8—8.8
8 {0.315}	1.25 {0.049}	9.8—14.7	1.0—1.5	7.2—10.8	16—23	1.6—2.3	12—17	18—26	1.8—2.7	13—20
10 {0.394}	1.25 {0.049}	20—28	2.0—2.9	14—21	31—46	3.2—4.7	23—34	36—54	3.7—5.5	27—40
12 {0.472}	1.5 {0.059}	34—50	3.5—5.1	25—37	55—80	5.6—8.2	41—59	63—93	6.4—9.5	46—69
14 {0.551}	1.5 {0.059}	—	—	—	75—103	7.7—10.5	56—76	102—137	10—14	75—101
16 {0.630}	1.5 {0.059}	—	—	—	116—157	12—16	85—116	156—211	16—22	115—156
18 {0.709}	1.5 {0.059}	—	—	—	167—225	17—23	123—166	221—299	23—31	163—221
20 {0.787}	1.5 {0.059}	—	—	—	231—314	24—32	171—231	308—417	31—43	227—307
22 {0.866}	1.5 {0.059}	—	—	—	314—423	32—43	231—312	417—564	43—58	307—416
24 {0.945}	1.5 {0.059}	—	—	—	475—546	41—56	298—403	536—726	55—74	396—536

SPECIAL TOOLS

GENERAL INFORMATION	ST- 2
ENGINE	ST- 3
CLUTCH AND MANUAL TRANSAXLE	ST- 4
FRONT AND REAR AXLES	ST- 5
STEERING	ST- 6
BRAKING	ST- 8
FRONT AND REAR SUSPENSION	ST- 9
CHECKER AND OTHER EQUIPMENT	ST-10

13ESTX-301

GENERAL INFORMATION

The letters A and B in the priority column indicate the degree of importance of each tool.

A.....Indispensable

The tools ranked A in this list are indispensable for performing operations satisfactorily, easily, safely, and efficiently. It is, therefore, advisable that all service shops have these tools.

B.....Selective

The tools in this list are not as necessary as tools ranked A, but all service shops should have these tools to perform repairs more easily and more efficiently.

Note

- When ordering tool sets that consist of several tools, check the List in the Parts Catalogue to make sure that some tools are not duplicated in other sets you may already have. If they are, instead of ordering the set, order only those new tools that are needed.
- There are new SST explanations in this tool chart.
These tools are indicated by "NEW SST" in description column.

13ESTX-302

ENGINE

TOOL
& DESC

49 0107

Engine

49 L010

Hanger
engine

49 063

Arm. v
lifter

49 B0

Pivot

49 S1

Remo
seal







49 B1







Brake

SPECIAL TOOLS

ST

ENGINE

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0107 680A Engine stand	A	
49 L010 1A0 Hanger set, engine stand	A	
49 0636 100A Arm, valve spring lifter	A	
49 B012 0A2 Pivot	A	
49 S120 170 Remover, valve seal	A	
49 E011 1A0 Brake, ring gear	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 L012 0A0 Installer set, valve seal & valve guide	A	
49 B012 005 Remover & installer, valve guide	A	
49 0221 061A Remover & installer, piston pin	A	
49 D011 102 Lock tool, crankshaft	A	
49 G014 001 Wrench, oil filter	A	
49 9200 145 Adapter, radiator cap tester	A	

ST

CLUTCH AND MANUAL TRANSAXLE

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G017 5A0 Engine support	A	
49 SE01 310A Clutch disc centering tool	A	
49 G019 0A0 Hanger, transaxle	A	
49 0839 425C Puller set, bearing	A	
49 G030 380C Shim selector set	A	
49 S120 710 Holder, coupling flange	A	
49 G030 370 Removing plate	A	
49 F401 330B Installer set, bearing	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0636 145 Puller, fan pulley boss	A	
49 G030 795 Installer, oil seal	A	
49 G017 1A0 Remover set, bearing	A	
49 B027 003 Attachment M	A	
49 W032 2A0 Remover set, bearing	A	
49 G030 440 Holder, primary shaft	A	
49 G030 338 Attachment E	A	
49 M005 561 Hanger, differential carrier	A	

CLUTCH

TOOL NUMBER
& DESCRIPTION

49 FT01 3A0
Remover, fan pulley boss

49 0710 5A0
Puller, bearing

49 8531 1A0
Drive pinion model

49 0727 1A0
Gauge, pinion bearing

49 0259 1A0
Adjusting wrench, bearing






FRONT





TOOL
& DESCRIPTION

49 F02 1A0
Attachment



49 G03 1A0
Attachment



CLUTCH AND MANUAL TRANSAXLE (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 FT01 361 Remover, bearing	A	
49 0710 520 Puller, bearing	A	
49 8531 565 Drive pinion model	A	
49 0727 570 Gauge body, pinion height	A	
49 0259 720 Adjustment wrench, side bearing	B	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 B027 001 Holder, diff. side gear	A	
49 B027 002A Preload adaptor	A	
49 8531 555 Gauge block	A	
49 B017 102 Preload adapter	A	
—	—	—

FRONT AND REAR AXLES





TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 F027 004 Attachment $\phi 80$	A	
49 G033 105 Attachment A	A	





TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 N027 001 Gauge block	A	
49 G033 102 Handle	A	

ST




SPECIAL TOOLS




FRONT AND REAR AXLES (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
9 F027 005 Attachment $\phi 62$	A	
9 F027 009 Attachment 68 and $\phi 77$	A	
9 V001 795 Installer, oil seal	A	
9 B001 795 Installer, oil seal	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 H034 201 Support block	A	
49 H027 002 Remover, bearing	A	
49 F026 103 Puller, wheel hub	A	
49 F026 102 Installer, bearing	A	

STEERING









TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0180 510B Attachment preload	B	
49 0118 850C Puller, ball joint	A	
49 1243 785 Installer, dust boot	A	









TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G033 108 Adapter, caster camber gauge	A	
49 H032 301 Wrench (Power steering)	A	
49 1232 670A Gauge set, power steering	A	

STEERING

TOOL NUMBER & DESCRIPTION
49 H002 671 Adapter (Power steering)
49 B032 310 Remover, bearing & oil (Power steering)
49 B032 320 Protector for rod seal
49 B032 330 Holder, power steering pump (Power steering)
49 B032 340 Protector, outer boot
49 B032 350 Wrench, power (Power steering)
49 B032 360 Adapter (Power steering)
49 G032 370 House (Power steering)




STEERING (CONT'D)



TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 H002 671 Adapter (Power steering)	A	
49 B032 317 Remover, bearing & oil seal (Power steering)	B	
49 B032 324 Protector body, rod seal	A	
49 B032 305 Holder, power steering pump (Power steering)	A	
49 B032 326 Protector, outer box	A	
49 B032 306 Wrench, plug (Power steering)	A	
49 B032 321 Adapter (Power steering)	A	
49 G032 317 House (Power steering)	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 B032 304 Adapter (Power steering)	A	
49 B032 309 Installer body, pinion seal (Power steering)	A	
49 B032 312 Protector, slipper seal (Power steering)	A	
49 B032 314 Slipper seal former (Power steering)	A	
49 B032 323 Remover body, rod seal	A	
49 B032 316 Support block, plug (Power steering)	A	
49 B032 327 Wrench, outer box	A	
49 B032 315 Installer, oil seal (Power steering)	A	





ST





STEERING (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 B032 310 Protector, pinion seal (Power steering)	A	
49 B032 311 Protector, slipper seal (Power steering)	A	
49 B032 325 Guide, rod seal	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 B032 320 Wrench (Power steering)	A	
49 F032 303 Handle (Power steering)	A	
—	—	—

BRAKING

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0259 770B Wrench, flare nut	A	
49 0221 600C Expand tool, disc brake	B	
49 0208 701A Air out tool, boot	B	
49 FA18 602 Wrench, disc brake piston	B	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 B043 001 Adjust gauge	A	
49 B043 002 Installer, bearing	A	
49 B043 003 Turning, lock tool	A	
49 U043 0A0 Gauge set, oil pressure	A	






BRAKING





TOOL & DESC
49 1285 Puller, needle
49 B066 Harness
49 B066 Oil pres gauge
49 L040 Setting retainer
49 B043 Socket

FRONT



TOOL & DES
49 B000 Replac rubber
49 8000 Installe dust b



BRAKING (CONT'D)

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 1285 071 Puller, needle bearing	A	
49 B066 001 Harness (ABS)	A	
49 B066 0A0 Oil pressure gauge (ABS)	A	
49 L043 001 Setting tool, retainer	A	
49 B043 004 Socket wrench	A	







TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G025 001 Installer, sensor rotor	A	
49 L043 002 Setting tool, retainer	A	
49 L043 003 Setting tool, retainer	A	
49 L043 004 Protector	A	
—	—	—






FRONT AND REAR SUSPENSION

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 B034 2A0A Replacer set, rubber bush	A	
49 B038 785 Installer, dust boot	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G034 1A0 Compressor, coil spring	A	
49 B034 201 Support block	B	

CHECKER AND OTHER EQUIPMENT


TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 0187 280 Gauge, oil pressure	A	
49 0839 285 Checker, fuel & thermometer	A	
49 0305 870A Tool set, window	A	
49 H018 9A1 Checker, self-diagnosis	A	
49 B019 9A0 System selector	A	
49 9200 162 Monitor, engine signal	A	

TOOL NUMBER & DESCRIPTION	PRIORITY	ILLUSTRATION
49 G018 903 Adapter harness	A	
49 G018 904 Sheet	A	
49 F018 002 Igniter checker	A	
49 N018 001 Adapter harness	A	
49 D066 801A Removing tool	A	

Mazda 323 4WD

Wiring Diagram

JMZ BG8392



1122-50-5000

MAZDA

Europe(LHD)

SYSTEM INDEX

ENGINE-RELATED SYSTEMS

STARTING SYSTEM.....	24
CHARGING SYSTEM.....	26
ENGINE CONTROL SYSTEM.....	28
COOLING FAN SYSTEM.....	36

CHASSIS-RELATED SYSTEMS

ANTI-LOCK BRAKE SYSTEM.....	82
-----------------------------	----

INSTRUMENT CLUSTER-RELATED SYSTEMS

INSTRUMENT CLUSTER & WARNING LAMPS.....	38
---	----

BODY-RELATED SYSTEMS

WINDSHIELD WIPER & WASHER.....	40
HEADLIGHT CLEANER.....	40
REAR WIPER & WASHER.....	42
HORNS.....	60
REAR WINDOW DEFROSTER.....	64
SOUND WARNING SYSTEM.....	66
POWER WINDOWS.....	74
POWER DOOR LOCK.....	76
POWER OUTSIDE MIRRORS.....	78
SLIDING SUNROOF.....	80
SEAT WARMERS.....	84

INTERIOR LIGHTING SYSTEMS

IG KEY CYLINDER LAMP.....	66
INTERIOR & SPOT LAMPS.....	66
COURTESY LAMPS.....	68
TRUNK COMPARTMENT LAMP.....	68
ILLUMINATION LAMPS.....	70

EXTERIOR LIGHTING SYSTEMS

HEADLIGHTS	
EXCEPT F.R.GERMANY.....	44
F.R.GERMANY.....	46
HEADLIGHT LEVELING SYSTEM.....	46
TAILLIGHTS	
EXCEPT F.R.GERMANY.....	48
F.R.GERMANY.....	50
LICENSE PLATE LIGHTS	
EXCEPT F.R.GERMANY.....	48
F.R.GERMANY.....	50
POSITION LIGHTS	
EXCEPT F.R.GERMANY.....	44
F.R.GERMANY.....	50
FRONT & REAR FOG LIGHTS.....	52
TURN & HAZARD FLASHER LIGHTS.....	54
STOPLIGHTS	
F.R.GERMANY.....	56
EXCEPT F.R.GERMANY.....	58
BACK-UP LIGHTS.....	60

AIR CONDITIONING-RELATED SYSTEMS

HEATER.....	62
-------------	----

ACCESSORIES

CIGARETTE LIGHTER.....	64
DIGITAL CLOCK.....	64
AUDIO SYSTEM.....	72

OTHER

DIAGNOSIS CONNECTOR.....	86
--------------------------	----

Mazda **323** **4WD**

Wiring Diagram **Europe (LHD)**

FOREWORD

This wiring diagram incorporates the wiring schematics of the basic vehicle and available optional equipment. Actual vehicle wiring may vary slightly depending on optional equipment or local specifications, or both. All information in this booklet is based on information available at the time of printing. Mazda Motor Corporation reserves the right to make changes without previous notice.

Mazda Motor Corporation
HIROSHIMA, JAPAN

APPLICATION:

This manual is applicable to vehicles beginning with the Vehicle Identification Numbers(VIN) shown on the following page.

CONTENTS

**GENERAL
INFORMATION**

GI

GROUND POINT

Y

**ELECTRICAL WIRING
SCHEMATIC**

W

**SYSTEM CIRCUIT
DIAGRAM/
CONNECTOR LOCATIONS**

A~

COMMON CONNECTORS

X

**JOINT BOX
COMPLETE WIRING
SYSTEM**

JE

PARTS LOCATION

PL

INDEX

PI

**VEHICLE IDENTIFICATION NUMBERS (VIN)
(CHASSIS NUMBER)**

JMZ BG83J200 500001~

WIRING COLOR CODE

Color	Code	Color	Code
Blue	L	Natural	N
Black	B	Orange	O
Brown	BR	Pink	P
Dark Blue	DL	Red	R
Dark Green	DG	Purple	PU
Green	G	Tan	T
Gray	GY	White	W
Light Blue	LB	Yellow	Y
Light Green	LG	Violet	V

GENERAL INFORMATION

GI

Wiring Diagrams

Contents of wiring diagrams	2
Using wiring diagrams	2

Reading Wiring Diagrams


Ground points	3
System circuit diagram/connector diagram	4
Routing diagram	6
Harness symbols	7
Symbols	8
Logic symbols	10
Abbreviations used in this booklet	10

Troubleshooting

Precautions to take when servicing an electrical system	11
Handling connectors	12
Using electrical measuring equipment	13
Measuring voltage	14
Measuring continuity/resistance	15
Finding short circuits	16





Contents of wiring diagrams

- This document comprises the 8 groups shown below. The main components are summarized in the components location diagram at the end of the document.

	GI	General Information	A how-to on using and reading wiring diagrams, using test equipment, checking harnesses and connectors, and finding trouble spots
	Y	Ground points	Ground routes from and to the battery
	W	Electrical wiring schematics	Shows main fuses and other fuses for each system
	A~U	Circuit diagrams for individual systems	Shows circuit and connector diagrams and component and connector location diagrams
	X	Common connectors	Shows connectors common throughout system
	JB	Joint box complete wiring system	Shows internal circuits and connectors
	PL	Parts location	Shows location of major electrical parts
	PI	Index	Gives page number of circuit diagram for each component



Using wiring diagrams

- The use of the wiring diagram depends on its application.

Application	Use	Application	Use
For checking circuits of individual systems	 <p>Open to page with circuit diagram and harness routing to be used and fold out common connector diagram or joint box diagram.</p>	For checking fuse connections	 <p>Open to electrical wiring schematic.</p>
For checking ground circuit of individual systems	 <p>Open to page with ground point diagram and fold out common connector diagram or joint box diagram.</p>	For finding page numbers of systems and components	<p>Parts Index System Index</p>  <p>or</p> <p>Open to parts index or system index.</p>

Ground points

- This shows ground points of the harness.



On circuit diagrams and ground points

The ground connection numbers in system circuit diagrams correspond to those in the ground point diagram.

System circuit diagram/connector diagram

- These diagrams show the circuits for each system, from the power supply to the ground. The power supply side is on the upper part of the page, the ground side on the lower part. The diagrams describe circuits with the ignition switch off.

Below is an explanation of the various points in the diagram.


Indicates operating conditions for switches.

Connector code

The prefix letter indicates the system in which the connector is used.

- JB: Joint box connections
- X: Common connectors
- A: Charging system/starting system connectors
- B: Engine control system connectors
- C: Gauge control system connectors
- D: Wiper system connectors
- E: Lighting system connectors
- F: Signal system connectors
- G: Air-conditioning system connectors
- H: Transmission Control system connectors
- I: Interior lamp system connectors
- J: Audio/radio connectors
- K: Power window/power door lock system connectors
- L: Remote control mirror system connectors
- M: Sliding sunroof system connectors
- N: Power steering/4-wheel steering system connectors
- O: Anti-lock brake system connectors.
- P: Power seat/seat heater system connectors
- Q: Auto cruise control system connectors
- R: Auto adjusting suspension system connectors
- S: Passive shoulder belt control/Airbag system connectors
- T: Others
- Y: Ground connector

IGNITION SYSTEM • ENGINE CONTROL



Ground numbers

A harness ground is represented differently than a unit ground.

Types of grounds	Symbol
Harness 	
Unit 	
Sensor 	


System name

System code

Current symbol

Current flows in the direction of the arrow.

SYSTEM • FUEL INJECTION SYSTEM B-1a



Indicates shielded wire. *

*Shielded wire:
Prevents signal disturbances from electrical interference.
Wire is covered by a metal meshing for grounding.

The number indicates that the circuit continues to the related system diagram.


Connector symbols

● Male and female connectors are represented as follows in the circuit and connector diagrams.

	Circuit diagram symbol	Connector diagram symbol
Male		
Female		

- Like connectors are linked by dashed lines between the connector symbols.
- Connector diagrams show connectors on the harness side. The terminal indicates the view from the harness side.

(Example)



- Colors for connectors except milk-white are given in locations.
- Unused terminals are indicated by *.

Wire color code (harness symbol)

- Two-color wires are indicated by a two-letter symbol. The first indicates the base color of the wire, the second the color of the stripe. For example:

W/R is a white wire with a red strip
BR/Y is a brown wire with a yellow strip

Symbol (Example)	Solid color wire	Striped wire
B (F) Black		
W/R (F) White (base color) Red (stripe)		

- The harness symbol is in () following the harness symbols (refer to GI-7.).


Routing diagram

- The routing diagram shows where electrical components are on the system circuit diagram by call out line and connector symbols.
- Specified values are listed beside the routing diagram or on the following page.

Connector symbol	
Shows the system that uses the connector.	
(Example)	
Connector	Symbol
Joint box	JB-04
Common connectors	X-19
System connectors	I-03

Component name
Shows the names of components in routing diagrams.

Ground symbol
Shows the ground in system diagrams.












Engine control unit terminal (unit side)


Terminal	Input	Output	Connection to	Test condition	Voltage	Remark
1K	○		Ignition Switch	All System Selector test switch "ON"	Approx. 12V	
1N	○		Turntable enable (side panel)	All System Selector test switch "SELF-TEST"	Approx. 0V	Ignition position ON
1O	○		Accelerator pedal depressed	Accelerator pedal depressed	Approx. 12V	
1P	○		Brake pedal depressed	Brake pedal depressed	0V	
1Q	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1R	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1S	○		Brake pedal depressed	Brake pedal depressed	0V	
1T	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1U	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1V	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1W	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1X	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1Y	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
1Z	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2A	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2B	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2C	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2D	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2E	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2F	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2G	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2H	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2J	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2K	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2L	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2M	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2N	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2O	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2P	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2Q	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2R	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2S	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2T	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2U	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2V	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2W	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2X	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2Y	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
2Z	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3A	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3B	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3C	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3D	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3E	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3F	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3G	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3H	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3J	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3K	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3L	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3M	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3N	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3O	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3P	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3Q	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3R	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3S	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3T	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3U	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3V	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3W	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3X	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3Y	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	
3Z	○		Brake pedal depressed	Brake pedal depressed	Approx. 12V	

Specified values






























Shows values for determining whether an electrical component is good.



































HARNESS SYMBOLS

DESCRIPTION OF HARNESS	SYMBOL	DESCRIPTION OF HARNESS	SYMBOL
FRONT HARNESS	(F) 	EMISSION HARNESS	(EM) 
ENGINE HARNESS	(E) 	INJECTOR HARNESS	(INJ) 
INSTRUMENT PANEL HARNESS	(I) 	INTERIOR LAMP HARNESS	(IN) 
REAR HARNESS	(R) 	FLOOR HARNESS	(FR) 
REAR NO.2 HARNESS	(R2)	DOOR NO.1 HARNESS	(DR1) 
REAR NO.3 HARNESS	(R3)	DOOR NO.2 HARNESS	(DR2)











Symbols

Symbol	Meaning	Symbol	Meaning																																																																											
Battery 	<ul style="list-style-type: none"> Generates electricity through chemical reaction. Supplies direct current to circuits. 	Resistance 	<ul style="list-style-type: none"> A resistor with a constant value. Mainly used to protect electrical components in circuits by maintaining rated voltage. 																																																																											
Ground (1) 	<ul style="list-style-type: none"> Connecting point to vehicle body or other ground wire where current flows from positive to negative terminal of battery. Ground (1) indicates a ground point to body through wire harness. Ground (2) indicates point where component is grounded directly to body. 		<ul style="list-style-type: none"> Reading resistance values. <p><Colored></p>																																																																											
Ground (2) 	<p>Remarks</p> <ul style="list-style-type: none"> Current will not flow through a circuit if ground is faulty. 		<p><Colored></p> <table border="1"> <thead> <tr> <th>Color</th><th>No.1</th><th>No.2</th><th>No.3</th><th>No.4</th></tr> <tr> <th></th><th>Resistance values</th><th>Multiplier</th><th>Tolerance</th><th></th></tr> </thead> <tbody> <tr><td>Black</td><td>0</td><td>0</td><td>$\times 10^0$</td><td></td></tr> <tr><td>Brown</td><td>1</td><td>1</td><td>$\times 10^1$</td><td></td></tr> <tr><td>Red</td><td>2</td><td>2</td><td>$\times 10^2$</td><td></td></tr> <tr><td>Orange</td><td>3</td><td>3</td><td>$\times 10^3$</td><td></td></tr> <tr><td>Yellow</td><td>4</td><td>4</td><td>$\times 10^4$</td><td></td></tr> <tr><td>Green</td><td>5</td><td>5</td><td>$\times 10^5$</td><td></td></tr> <tr><td>Blue</td><td>6</td><td>6</td><td>$\times 10^6$</td><td></td></tr> <tr><td>Purple</td><td>7</td><td>7</td><td>$\times 10^7$</td><td></td></tr> <tr><td>Grey</td><td>8</td><td>8</td><td>$\times 10^8$</td><td></td></tr> <tr><td>White</td><td>9</td><td>9</td><td>$\times 10^9$</td><td></td></tr> <tr><td>Gold</td><td></td><td></td><td>$\times 10^{-1}$</td><td>$\pm 5\%$</td></tr> <tr><td>Silver</td><td></td><td></td><td>$\times 10^{-2}$</td><td>$\pm 10\%$</td></tr> <tr><td></td><td></td><td></td><td></td><td>$\pm 20\%$</td></tr> </tbody> </table>	Color	No.1	No.2	No.3	No.4		Resistance values	Multiplier	Tolerance		Black	0	0	$\times 10^0$		Brown	1	1	$\times 10^1$		Red	2	2	$\times 10^2$		Orange	3	3	$\times 10^3$		Yellow	4	4	$\times 10^4$		Green	5	5	$\times 10^5$		Blue	6	6	$\times 10^6$		Purple	7	7	$\times 10^7$		Grey	8	8	$\times 10^8$		White	9	9	$\times 10^9$		Gold			$\times 10^{-1}$	$\pm 5\%$	Silver			$\times 10^{-2}$	$\pm 10\%$					$\pm 20\%$
Color	No.1	No.2	No.3	No.4																																																																										
	Resistance values	Multiplier	Tolerance																																																																											
Black	0	0	$\times 10^0$																																																																											
Brown	1	1	$\times 10^1$																																																																											
Red	2	2	$\times 10^2$																																																																											
Orange	3	3	$\times 10^3$																																																																											
Yellow	4	4	$\times 10^4$																																																																											
Green	5	5	$\times 10^5$																																																																											
Blue	6	6	$\times 10^6$																																																																											
Purple	7	7	$\times 10^7$																																																																											
Grey	8	8	$\times 10^8$																																																																											
White	9	9	$\times 10^9$																																																																											
Gold			$\times 10^{-1}$	$\pm 5\%$																																																																										
Silver			$\times 10^{-2}$	$\pm 10\%$																																																																										
				$\pm 20\%$																																																																										
Fuse (1)  <p>(box)</p>	<ul style="list-style-type: none"> Melts when current flow exceeds that specified for circuit, interrupts current flow. <p>Precautions</p> <ul style="list-style-type: none"> Do not replace with fuses exceeding specified capacity. 		<p><Colored></p>																																																																											
Fuse (2)  <p>(Cartridge)</p>	<p><Blade type></p>  <p><Tube type></p> 		<p><Colored></p>																																																																											
Main fuse/Fusible link 	<p><Cartridge type></p>  <p><Fusible link></p> 		<p><Colored></p>																																																																											
Transistor (1) 	<ul style="list-style-type: none"> Electrical switching component. Turns on when voltage is applied to the base(B). <p>Collector indication mark</p> 		<p><Colored></p>																																																																											
Transistor (2) 	<ul style="list-style-type: none"> Reading code. <p>2 S C 828 A</p> <p>Semiconductor</p> <p>Number of terminals</p> <p>Revision mark</p> <p>A: High-frequency PNP B: Low-frequency PNP C: High-frequency NPN D: Low-frequency NPN</p>		<p><Colored></p>																																																																											
Lamp 	<ul style="list-style-type: none"> Emits light and generates heat when current flows through filament. 		<p><Colored></p>																																																																											
Motor 	<ul style="list-style-type: none"> Converts electrical energy into mechanical energy. 		<p><Colored></p>																																																																											
Pump 	<ul style="list-style-type: none"> Pulls in and discharges gases and liquids. 		<p><Colored></p>																																																																											
Cigarette lighter 	<ul style="list-style-type: none"> Electrical coil that generates heat. 		<p><Colored></p>																																																																											

Symbol	Meaning	Symbol	Meaning									
Horn 	<ul style="list-style-type: none"> Generates sound when current flows. 	Switch (1)  Normally open (NO)	<ul style="list-style-type: none"> Allows or breaks current flow by opening and closing circuits. 									
Speaker 		Switch (2)  Normally closed (NC)										
Heater 	<ul style="list-style-type: none"> Generates heat when current flows. 	Harness  (Not connected)	<ul style="list-style-type: none"> Unconnected intersecting harness. 									
Speed sensor 	<ul style="list-style-type: none"> Movement of magnet in speedometer turns contact within sensor on and off. 	 (Connected)	<ul style="list-style-type: none"> Connected intersecting harness. 									
Ignition switch 	<ul style="list-style-type: none"> Turning ignition key switches circuit to operate various component. 											
Relay (1)  Normally open (NO)	<ul style="list-style-type: none"> Current flowing through coil produces electromagnetic force causing contact to open or close. <table border="1"> <thead> <tr> <th></th><th>No current to coil</th><th>Current to coil</th></tr> </thead> <tbody> <tr> <td>Normally open relay (NO)</td><td>  No flow </td><td>  Flow </td></tr> <tr> <td>Normally closed relay (NC)</td><td>  Flow </td><td>  No flow </td></tr> </tbody> </table>		No current to coil	Current to coil	Normally open relay (NO)	 No flow	 Flow	Normally closed relay (NC)	 Flow	 No flow		
		No current to coil	Current to coil									
Normally open relay (NO)	 No flow	 Flow										
Normally closed relay (NC)	 Flow	 No flow										
Relay (2)  Normally closed (NC)												
Sensor (variable) 	<ul style="list-style-type: none"> Resistance changes with other components operation. 	Diode 	<ul style="list-style-type: none"> Known as a semiconductor rectifier, the diode allows current flow in one direction only. <p>Cathode(K) ——— Anode(A) ———→ Flow of electric current</p> 									
Sensor (thermistor) 	<ul style="list-style-type: none"> Resistance changes with temperature. 	Light-emitting diode (LED) 	<ul style="list-style-type: none"> A diode that lights when current flows. Unlike ordinary bulbs, the diode does not generate heat when it. <p>Cathode(K) ——— Anode(A)</p>  <p>Flow of current</p>									
Capacitor 	<ul style="list-style-type: none"> Component that temporarily stores electrical charge. 											
Solenoid 	<ul style="list-style-type: none"> Current flowing through coil generates electromagnetic force to operate plungers. 	Reference diode (Zener diode) 	<ul style="list-style-type: none"> Allows current to flow in one direction up to a certain voltage; allows current to flow in the other direction once that voltage is exceeded. 									

Logic symbols

Types of logic symbols	Operation	Expressing output	Simple relay circuits
OR 	Input to A or B will produce output at C.	Low electrical potential (L) at A and B → no output (L) at C High electrical potential (H) at A or B → output (H) at C	
AND 	Input to A and B will produce output at C.	High electrical potential (H) at A and B → output (H) at C Low electrical potential (L) at A or B → no output (L) at C	
INV 	No input to A will produce an output at B. An input to A will not produce an output at B.	Low electrical potential (L) at A → no ground (H) B High electrical potential (H) at A → grounds (L) B	
PROCESS 	Simplified representation of complex functions within circuit describes main function. 1. Signal detector for engine control unit, cooling unit, and tachometer. 2. Signal converter for turn and hazard flasher unit and igniter unit.		(Examples) Igniters 


Abbreviations used in this booklet

A	Ampere	ECU	Engine Control Unit	MW	Middle Wave
AAS	Autoadjusting Suspension	EGI	Electronic Gasoline Injection	NC	Normally Closed
ABS	Antilock Brake System	EGR	Exhaust Gas Recirculation	NO	Normally Open
ACC	Accessory	ELEC	Electric	OD	Overdrive
ACCEL	Accelerator	ELR	Emergency Locking Retractor	OFF	Switch Off
ACV	Air Control Valve	ETR	Electronic Tuner	ON	Switch On
ADD	Additional	EXH	Exhaust	P	Power
AE	Acoustic Equilibration	F	Front	PRCV	Pressure Regulator Control
AIS	Air Injection System	FICB	Fast-Idle Cam Breaker		Solenoid Valve
ALL	Automatic Load Leveling	FM	Frequency Modulation	PRG	Purge Solenoid Valve
ALT	Alternator	F/B	Feedback	PTC	Positive Temperature Coefficient
AM	Amplitude Modulation	F/I	Fuel Injector		Heater
AMP	Amplifier	GEN	Generator	P/S	Power Steering
ANT	Antenna	HEAT	Heater	QSS	Quick-Start System
AS	Autostop	HEI	High-Energy Ignition	R	Rear
ASV	Air Supply Valve	HI	High	REC	Recirculation
AT	Automatic transmission	H/D	Heater/Defroster	RF	Right Front
ATP	Atmospheric Pressure	IG	Ignition	RH	Right Hand
ATX	Automatic Transaxle	ILLUMI	Illumination	RPM	Revolutions Per Minute
A/C	Air Conditioner	INT	Intermittent	RR	Right Rear
A/F	Air Fuel	ISC	Idle-Speed Control	SOL	Solenoid
A/R	Auto Reverse	JB	Joint Box	SQ	Squares Per Millimeter
B	Battery	LCD	Liquid Crystal Display	ST	Start
BAC	Bypass Air Control Valve	LF	Left Front	SW	Switch
B/L	Bilevel	LH	Left Hand	TCV	Twin Scroll Turbocharger
CARB	Carburetor	LO	Low		Solenoid Valve
CCT	Circuit	LR	Left Rear	TEMP	Temperature
CIGAR	Cigarette	LW	Low Wave	TICS	Triple Induction Control System
COMBI	Combination	M	Motor	TR	Transistor
CON	Conditioner	MID	Middle	TWS	Total Wiring System
CONT	Control	MIL	Malfunction Indicator Lamp	V	Volt
CPU	Central Processing Unit	MIN	Minute	VENT	Ventilation
CSD	Cold-Start Device	MIX	Mixture	VOL	Volume
DEF	Defroster	MPX	Multiplex	VRIS	Variable Resonance Induction
DOHC	Double-Overhead Camshaft	MT	Manual Transmission		System
ECPS	Electronically Controlled Power Steering	MTR	Mechanical Tuning Radio	W	Watt(s)
		MTX	Manual Transaxle		


Precautions to take when servicing an electrical system

- Note the following items when servicing the electrical system.
- Do not alter the wiring or electrical equipment in any way; this may damage the vehicle or cause a fire from short-circuiting a circuit or overloading it.

- The negative (-) battery cable must be removed first and installed last.



- Do not replace with fuses exceeding specified capacity.




Caution

- Be sure that the ignition and other switches are off before disconnecting or connecting the battery cables.
- Failure to do so may damage the semiconductor components.


Caution

- Replacing a fuse with one of a larger capacity than designated may damage components or cause a fire.


- Secure harnesses with provided clamps to take up slack.



- Tape areas of the harness that may rub or bump against sharp edges to protect it from damage.




- When mounting components, be sure the harness is not caught or damaged.






Caution

- Clamp all harnesses near vibrating components (for example, the engine) to remove slack and to prevent contact resulting from vibration.

- Do not handle electrical components roughly or drop them.























- Disconnect heat-sensitive parts (for example, relays and ECU) when performing maintenance (such as welding) where temperatures may exceed 80°C (176°F).














Handling connectors

Caution

- Be sure to grasp the connectors, not the wires, when disconnecting them.


Connector removal		Checking connector contacts	Checking for loose terminals	Replacing terminals
Push type		 <p>Caution Improperly engaged connectors will cause poor terminal contact.</p>	 <p>Caution A loose terminal will cause poor terminal contact.</p>	<p><CPU connector></p>  <ol style="list-style-type: none"> 1. Raise the rear cover. 2. Lift the tab with a thin piece of metal and remove the terminal.
				<p><General connector></p>  <p>Lift the tab with a thin piece of metal and remove the terminal.</p>
				
				
				
				
				
				
Pull-up type		<p>When using a matching male terminal, make sure there is no looseness in the female terminal.</p>	 <p>Make sure the terminals are not pushed out of the connector when engaged.</p>	<p><Round connectors></p>  <ol style="list-style-type: none"> 1. Raise the cover. 2. Lift the terminal to remove it. 3. Make sure the terminal is securely mounted in the connector when installing.
				
				
				
Spring type			<p>Pull lightly on individual wires to check that they are secured in the terminal.</p>	<p><Common ground connectors></p>  <ol style="list-style-type: none"> 1. Raise the cover. 2. Remove A. 3. Lift the tab with a thin piece of metal and remove the terminal.

Using electrical measuring equipment

Equipment	Use	Operation	Handling precautions
Test lamp 	Test to find open or shorted circuits.	<ul style="list-style-type: none"> ● Connect the test lamp between the circuit being measured and a ground. ● The lamp will light if the circuit is energized to the point tested. 	<ul style="list-style-type: none"> ● Test lamps use 12V 1.4W or 3.4W bulbs or light-emitting diodes (LEDs). Using a large-capacity bulb may damage the CPU.
Jumper wire 	Used to create a temporary circuit.	<ul style="list-style-type: none"> ● Connect the jumper wire between the terminals of a circuit to bypass a switch. 	<ul style="list-style-type: none"> ● Do not connect the jumper wire from the power source line to a ground; this may cause burning or other damage to harnesses or electronic components.
Voltmeter 	Used for measuring the voltage of a circuit to find possible opens or shorts.	<ul style="list-style-type: none"> ● Connect the positive (+) probe to the point where voltage is to be measured and the negative (-) probe to a ground. 	<ul style="list-style-type: none"> ● Connect the voltmeter in parallel with the circuit. ● Set the range to the desired voltage. ● Use the service hole when measuring the voltage at the diagnosis connector.  <ul style="list-style-type: none"> ● Tie a thin wire to the positive (+) probe to access narrow terminals.
Ohmmeter 	Used to find opens and shorts in the circuit, to confirm continuity and to measure resistance.	<ul style="list-style-type: none"> ● Zero the ohmmeter. ● Verify that voltage is not applied to the circuit. ● Connect the probes between two points in a circuit. 	<ul style="list-style-type: none"> ● Zero the meter after switching to the measuring range. ● Before using the ohmmeter, make sure the ignition switch is off or the negative (-) battery cable is disconnected to prevent burning or otherwise damaging the ohmmeter.
Ammeter 	Used to check alternator output, current supplied to the starter, and dark current within a circuit. Note Dark current is the constant flow of current while the ignition switch is OFF.	<ul style="list-style-type: none"> ● Connect the ammeter in series with the circuit by touching the positive (+) probe to the power-side terminal and the negative (-) probe to the ground-side terminal. 	<ul style="list-style-type: none"> ● Set the range to the desired amperage. ● Connect the ammeter in series with the circuit. The ammeter may be burned or otherwise damaged if it is connected in parallel.

Measuring voltage

Checks




1. Connect a voltmeter or test lamp to the measuring points.

Measuring points	Circuit operation (normal)			
	Ignition switch: OFF	Ignition switch: ON		
		Thermo switch: OFF	Thermo switch: ON	
(A)	0V X	12V ⬤	12V ⬤	
(B)	0V X	12V ⬤	0V X	
(C)	0V X	0V X	0V X	
(D)	12V ⬤	12V ⬤	12V ⬤	
(E)	0V X	0V X	12V ⬤	
(F)	0V X	0V X	0V X	

⬤ : Test lamp ON
X : Test lamp OFF


Precautions during checks

Measuring voltage of connectors



A voltmeter probe may momentarily connect a terminal when inserted into the connector and give an erroneous reading when checking for improperly engaged connectors, poor terminal contacts, or loose terminals.


Measuring voltage of ground



Touch the voltmeter probe to the ground wire when checking the ground circuit.

Measuring continuity/resistance

Checking switches




Touch the ohmmeter probes to the switch terminals to check continuity.

Caution

Verify the operating state of the switch before checking continuity because readings vary accordingly.

Checking diodes




Note

The negative (-) probe of the ohmmeter is connected to the positive terminal of the internal ohmmeter battery, the positive (+) probe to the negative terminal of the battery.

Continuity is checked according to the direction of the positive (+) and negative (-) probes of the ohmmeter in the circuit containing the diode.

Connection	Continuity
	Yes
	No

Checking sensors and solenoid valves




Connect the ohmmeter probes to the sensor or solenoid valve terminals to check resistance.

Caution

Verify the operating state of the sensor before checking resistance because readings vary accordingly.

Checking condensers





1. Short between the terminals with a jumper wire to discharge the capacitor.
2. Set the ohmmeter range to $\times 10k \Omega$ and connect it to the capacitor terminals.
3. The capacitor is good if the needle of the ohmmeter swings once and returns to its original position.




Finding short circuits

Shorts occur between the power (positive) and ground (negative) sides of a circuit. Therefore, finding a short circuit requires determining how the circuit is routed.

Circuits not connected to control unit

	Examples		Finding short circuit
	Short location	Symptom	
	Short (A)	<ul style="list-style-type: none"> Fuse melts. 	<ol style="list-style-type: none"> 1. Remove the fuse and main fuse of the circuit. 2. Disconnect all connectors of electrical components in the circuit. 3. Attach a voltmeter or test lamp to the fuse box and reconnect each connector, beginning nearest the power source. 4. Check the voltmeter reading or test lamp as the connectors are connected. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> A short has occurred where the voltmeter reading changes or the test lamp comes on. </div>
	Short (B)	<ul style="list-style-type: none"> Main fuse melts. 	
	Short (C)	<ul style="list-style-type: none"> The motor operates regardless of whether the thermo-switch is ON or OFF when the ignition switch is ON. The fuse is not melted. 	
	Short (D)	<ul style="list-style-type: none"> The main fuse melts when the ignition switch and thermo-switch are ON and the relay is operating. 	

Circuits connected to control unit

	Examples		Finding short circuit
	Short location	Symptom	
	Short (A)	<ul style="list-style-type: none"> Fuse melts. 	<ol style="list-style-type: none"> 1. Remove the fuse and main fuse of the circuit. 2. Disconnect all connectors of electrical components in the circuit. 3. Attach a voltmeter or test lamp to the fuse box and reconnect each connector, beginning nearest to the power source. 4. Check the voltmeter reading or test lamp as the connectors are connected. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> A short has occurred where the voltmeter reading changes or the test lamp comes on. </div>
	Short (B)	<ul style="list-style-type: none"> Solenoid A operates when the ignition switch is ON. 	
	Short (C)	<ul style="list-style-type: none"> The CPU transistor burns out when the ignition switch is turned ON. 	
	Short (D)	<ul style="list-style-type: none"> The CPU thinks the switch is ON because the same conditions exist as when the switch is ON. 	
	Short (E)	<ul style="list-style-type: none"> The CPU senses the sensor to be 0 Ω because the same conditions exist as when the resistance value is 0 Ω. The CPU equipped with the self-diagnosis function outputs the code. 	<ol style="list-style-type: none"> 1. Attach the test lamp or voltmeter to the CPU connector. 2. Connect to the switch/sensor connector. 3. Check the voltmeter reading or test lamp. <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> A short has occurred where the voltmeter reads 0V or the test lamp goes out. </div>


This page left intentionally blank

Y


■ GROUND POINTS

WIRING ORDER INTO JOINT CONNECTOR MAY BE CHANGED


JC-01 JOINT CONNECTOR (F)




JC-02 JOINT CONNECTOR (F)




JC-03 JOINT CONNECTOR (F)





JC-04 JOINT CONNECTOR (EM)




JC-06 JOINT CONNECTOR (EM)



JC-09 JOINT CONNECTOR (R)



Y




Y

W-1

EXCEPT F.R.GERMANY ELECTRICAL WIRING SCHEMATIC

— CURRENT FROM BATTERY
 - - - CURRENT FROM IG1, IG2
 - - - CURRENT FROM ACC
 — OTHERS




F.R.GERMANY

ELECTRICAL WIRING SCHEMATIC

— CURRENT FROM BATTERY
 - - - CURRENT FROM IG1, IG2
 — CURRENT FROM ACC
 — OTHERS

W-2



This page left intentionally blank

SYSTEM CIRCUIT DIAGRAM/ CONNECTOR LOCATIONS

ENGINE-RELATED SYSTEMS

STARTING SYSTEM.....	24
CHARGING SYSTEM.....	26
ENGINE CONTROL SYSTEM.....	28
COOLING FAN SYSTEM.....	36

CHASSIS-RELATED SYSTEMS

ANTI-LOCK BRAKE SYSTEM.....	82
-----------------------------	----

INSTRUMENT CLUSTER-RELATED SYSTEMS

INSTRUMENT CLUSTER & WARNING LAMPS.....	38
---	----

BODY-RELATED SYSTEMS

WINDSHIELD WIPER & WASHER.....	40
HEADLIGHT CLEANER.....	40
REAR WIPER & WASHER.....	42
HORNS.....	60
REAR WINDOW DEFROSTER.....	64
SOUND WARNING SYSTEM.....	66
POWER WINDOWS.....	74
POWER DOOR LOCK.....	76
POWER OUTSIDE MIRRORS.....	78
SLIDING SUNROOF.....	80
SEAT WARMERS.....	84

INTERIOR LIGHTING SYSTEMS

IG KEY CYLINDER LAMP.....	66
INTERIOR & SPOT LAMPS.....	66
COURTESY LAMPS.....	68
TRUNK COMPARTMENT LAMP.....	68
ILLUMINATION LAMPS.....	70

EXTERIOR LIGHTING SYSTEMS

HEADLIGHTS	
EXCEPT F.R.GERMANY.....	44
F.R.GERMANY.....	46
HEADLIGHT LEVELING SYSTEM.....	46
TAILLIGHTS	
EXCEPT F.R.GERMANY.....	48
F.R.GERMANY.....	50
LICENSE PLATE LIGHTS	
EXCEPT F.R.GERMANY.....	48
F.R.GERMANY.....	50
POSITION LIGHTS	
EXCEPT F.R.GERMANY.....	44
F.R.GERMANY.....	50
FRONT & REAR FOG LIGHTS.....	52
TURN & HAZARD FLASHER LIGHTS.....	54
STOPLIGHTS	
F.R.GERMANY.....	56
EXCEPT F.R.GERMANY.....	58
BACK-UP LIGHTS.....	60

AIR CONDITIONING-RELATED SYSTEMS

HEATER.....	62
-------------	----

ACCESSORIES


CIGARETTE LIGHTER.....	64
DIGITAL CLOCK.....	64
AUDIO SYSTEM.....	72

OTHER

DIAGNOSIS CONNECTOR.....	86
--------------------------	----

A~




A-1 ■ STARTING SYSTEM




A-01 STARTER (E)



A-1



A-2 ■ CHARGING SYSTEM




A-03 ALTERNATOR (E)




A-04 ALTERNATOR (E)



A-2



B-1a ■ ENGINE CONTROL SYSTEM (1/3)



B1-01 ENGINE CONTROL UNIT (EM)

1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
R/B	O/L	G/B	G	*	G/Y	L	G/W	*	V	L/R
BR/Y	B/L	B/G	L/Y	R/W	*	L/B	O/B	W/B	W/Y	W/R
1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A
LG	L/O	Y	R/Y	L/W	R	LG/W	LG/R	*	Y/L	P/B	B/LG	B/O
G	W/L	Y/B	G/O	W	R/B	R/L	G/R	R/Y	*	*	B/BF	B/O
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B

01-02 MAIN RELAY (E)
(FUEL INJ)

W/G	B/W
W/R	B

B1-03 CIRCUIT OPENING RELAY (EM)


V	G	B/P
E	*	LG

81-04 FUEL PUMP (R)

	G/R				B	
*	L	W/R	B/G	*	X	


81-05 IGNITER (EM)

91-06 CONDENSER (EM)

B1-07 IGNITION COIL (EM)B1-08 OXYGEN SENSOR (FM)B1-26 FUEL PUMP UNIT (B)


B/W	B
Y/L	L/Y

B1-27 TRANSFER PUMP (R)


Y/L			L/Y
B	*	L	Y

B1-28 FUEL PUMP RELAY (EM)

B-1a




B-1b ■ ENGINE CONTROL SYSTEM (2/3)




B1-01 ENGINE CONTROL UNIT (EM)

1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A	2Y	2W	2U	2S	2Q	2O	2M	2K	2I	2G	2E	2C	2A
R/B	O/L	G/B	G	*	L/G/Y	L	G/W	*	V	L/R	L/G	L/D	Y	R/Y	L/W	R	L/G/W	G/R	*	Y/L	P/B	B/LG	B/D
BR/Y	B/L	B/G	L/Y	R/W	*	L/B	O/B	W/B	W/Y	W/R	G	W/L	Y/B	G/D	W	R/B	R/L	G/R	R/Y	*	*	B/BR	B/O
1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B	2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B

B1-09 DISTRIBUTOR (EM)




B1-11 ISC VALVE (EM)




B1-12 SOLENOID VALVE (PURGE CONTROL) (EM)




B1-14 SOLENOID VALVE (PRC LOW TEMP) (EM)




B1-15 INJECTOR NO.1 (INJ)




B1-16 INJECTOR NO.3 (INJ)




B1-17 INJECTOR NO.2 (INJ)




B1-18 INJECTOR NO.4 (INJ)



B1-19 WATER THERMOSENSOR (INJ)




B1-24 KNOCK CONTROL UNIT (EM)



B1-25 KNOCK SENSOR (EM)




B1-29 SOLENOID VALVE (WASTEGATE) (EM)




B1-30 INJECTOR RESISTOR (EM)




B1-31 SOLENOID VALVE (PRC HIGH TEMP) (INJ)






B-1b



B-1c ■ ENGINE CONTROL SYSTEM (3/3)



B-1c



Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
1A	—	—	Battery	Constant	V _B	For backup
1B	○		Main relay (FUEL INJ relay)	Ignition switch OFF	0V	—
				ON	V _B	
1C	○		Ignition switch (START)	While cranking	Approx. 10V	—
				Ignition switch ON	0V	
1D		○	Self-Diagnosis Checker (monitor lamp)	Test switch at SELF TEST Lamp illuminated for 3 sec. after ignition switch OFF→ON	Approx. 5V	With Self-Diagnosis Checker and System Selector
				Lamp not illuminated after 3 sec.	V _B	
				Test switch at O ₂ MONITOR with engine idling Monitor lamp illuminated	Approx. 5V	
				Test switch at O ₂ MONITOR with engine idling Monitor lamp not illuminated	V _B	
1E	—	—	—	—	—	—
1F		○	Self-Diagnosis Checker (service code)	Buzzer sounded for 3 sec. after ignition switch OFF→ON	Below 2.5V	• With Self-Diagnosis Checker and System Selector • With System Selector test switch at SELF TEST
				Buzzer not sounded after 3 sec.	V _B	
				Buzzer sounded	Below 2.5V	
				Buzzer not sounded	V _B	
1G		○	Igniter	Ignition switch ON	0V	—
				idle	Approx. 0.2V	
1H		○	Solenoid valve (wastegate)	Ignition switch ON	V _B	—
				idle	Approx. 2V	—
1I		○	Fuel pump resistor/relay	While cranking	Approx. 10V	—
				idle	Below 1.5V	—
1J		○	A/C relay	Ignition switch ON	V _B	—
				A/C switch ON at idle	Below 2.5V	
				A/C switch OFF at idle	V _B	
1K	○		Diagnosis connector (TEN terminal)	System Selector test switch at O ₂ MONITOR	V _B	—
				System Selector test switch at SELF TEST	Below 1.0V	
1L	—	—	—	—	—	—
1M	—	—	—	—	—	—

2Y	2W	2U	2S	2O	2Q	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
1N	○		Throttle sensor (idle switch)	Accelerator pedal released	Below 1.0V	Ignition switch ON
				Accelerator pedal depressed	V _B	
1Q	○		Foglight relay	Foglight switch ON	V _B	—
				Foglight switch OFF	0V	
1P	○		P/S pressure switch	Ignition switch ON	V _B	—
				P/S pressure switch ON at idle	Below 1.0V	
				P/S pressure switch OFF at idle	V _B	
1Q	○		A/C switch	A/C switch ON	Below 2.5V	Ignition switch ON and blower motor ON
				A/C switch OFF	V _B	
1R	○		Electric cooling fan switch	Fan operating (coolant temperature over 97°C [207°F] or diagnosis connector terminal 1FA grounded)	Below 1.0V	—
				Fan not operating (idle)	V _B	
1S	○		Blower control switch	Blower control switch OFF or 1st position	V _B	Ignition switch ON
				Blower control switch 2nd or higher position	Below 1.0V	
1T	○		Rear window defroster switch	Rear window defroster OFF	Below 1.0V	Ignition switch ON
				Rear window defroster ON	V _B	
1U	○		Headlight switch	Headlights ON	V _B	—
				Headlights OFF	Below 1.0V	
1V	○		Neutral/Clutch switches	Neutral position or clutch pedal depressed	Below 1.0V	—
				Others	V _B	

2Y	2W	2U	2S	2O	2Q	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B

Vs: Battery voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
2A	—	—	Ground (injector)	Constant	0V	—
2B	—	—	Ground (output)	Constant	0V	—
2C	—	—	Ground (CPU)	Constant	0V	—
2D	—	—	Ground (input)	Constant	0V	—
2E	○	—	Distributor (NE signal)	Ignition switch ON Idle	0V or 5V Approx. 2V	—
2F	—	—	—	—	—	—
2G	○	—	Distributor (G signal)	Ignition switch ON Idle	0V or 5V Approx. 1.5V	—
2H	—	—	—	—	—	—
2I	—	—	—	—	—	—
2J	○	—	Knock control unit	Idle	Approx. 4.0V	—
2K	○	—	Throttle sensor/ Airflow meter	Constant	4.5—5.5V	—
2L	○	—	Speedometer sensor	Ignition switch ON	0 or 5V	—
2M	○	—	Throttle sensor	Accelerator pedal released Accelerator pedal fully depressed	Approx. 0.5V Approx. 4.0V	—
2N	○	—	Oxygen sensor	Ignition switch ON Idle (cold engine) Idle (after warm-up) Increasing engine speed (after warm-up) Deceleration	0V 0V 0—1.0V 0.5—1.0V 0—0.4V	—
2O	○	—	Airflow meter	Ignition switch ON Idle	Approx. 3.8V Approx. 3.0V	—
2P	○	—	Intake air thermosensor	Ambient air temperature 20°C (68°F)	Approx. 2.5V	In airflow meter
2Q	○	—	Water thermosensor	Engine coolant temperature 20°C (68°F) After warm-up	Approx. 2.5V Below 0.5V	—
2R	—	○	Turbocharge indicator	Ignition switch ON	V _B	—


Vs: Battery voltage

Terminal	Input	Output	Connected to	Test condition	Correct voltage	Remark
2S	—	○	Overboost warning buzzer	Ignition switch ON	V _B	—
2T	—	○	Solenoid valve (PRC low temp.)	180 sec. after engine started with coolant temperature is above 90°C (194°F) and intake air temperature is between 40°C (104°F) and 50°C (122°F) Other condition at idle	Below 1.5V V _B	No-load engine condition
2U	—	○	Injector (Nos. 1, 3)	Ignition switch ON Idle Engine speed above 2,000 rpm during deceleration (after warm-up)	V _B V _B * V _B	* Engine Signal Monitor: Green and red lamps flash
2V	—	○	Injector (Nos. 2, 4)	Ignition switch ON Idle Engine speed above 2,000 rpm during deceleration (after warm-up)	V _B V _B * V _B	—
2W	—	○	ISC valve	Ignition switch ON Idle	Approx. 7V Approx. 9V	—
2X	—	○	Solenoid valve (purge control)	Ignition switch ON Idle	V _B V _B	—
2Y	—	○	Circuit-opening relay	Ignition switch ON Idle	V _B Below 1.0V	—
2Z	—	○	Solenoid valve (PRC high temp.)	210 sec. after engine started with coolant temperature above 90°C (194°F) and intake air temperature above 50°C (122°F) Other condition at idle	Below 1.5V V _B	No-load engine condition

2Y	2W	2U	2S	2O	2Q	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B


2Y	2W	2U	2S	2O	2Q	2M	2K	2I	2G	2E	2C	2A	1U	1S	1Q	1O	1M	1K	1I	1G	1E	1C	1A
2Z	2X	2V	2T	2R	2P	2N	2L	2J	2H	2F	2D	2B	1V	1T	1R	1P	1N	1L	1J	1H	1F	1D	1B



B-2 ■ COOLING FAN SYSTEM








B2-01 COOLING FAN RELAY NO. 1 (E) 	B2-02 COOLING FAN MOTOR (F) 	B2-03 WATER THERMO-SWITCH (EM) 	B2-04 SHORT CONNECTOR (EM)
B2-05 COOLING FAN RELAY NO. 2 (F) 		B2-06 COOLING FAN RELAY NO. 3 (F) 	B2-07 WATER THERMO-SWITCH (F)


B-2





C





D-01 WINDSHIELD WIPER & WASHER SWITCH (F)

L/Y	L/O	L
L/W	B	L/R

D-02 WINDSHIELD WIPER MOTOR (F)

L/W	L/R
L	L/Y

D-03 WINDSHIELD WASHER MOTOR (F)

B
L/O


C-05 HEADLIGHT CLEANER MOTOR (F)

*	L/G/W	(*)
*	B	G/L
		Y/W
		(*)

D-05 HEADLIGHT CLEANER SWITCH (I)


*	R/B
*	Y/W
	B
	R

E-17 FUSE (F)




- ① HEAD CLEANER 30A
- ② *
- ③ DEFOG 20A
- ④ F.FOG 15A
- ⑤ *
- ⑥ *

D-1




D-2 ■ REAR WIPER & WASHER



D-07 REAR WIPER MOTOR (R3)	D-08 REAR WASHER MOTOR (R)	D-09 REAR WIPER & WASHER SWITCH (F)	


D-2








E-1


EXCEPT F.R.GERMANY


■ HEADLIGHTS
■ POSITION LIGHTS




E-01 COMBINATION SWITCH (F) 	E-02 COMBINATION SWITCH (F) <table border="1"><tr><td>G/O</td><td>R/Y</td><td>*</td></tr><tr><td>R/B</td><td>Y</td><td>R/W</td></tr></table>	G/O	R/Y	*	R/B	Y	R/W	E-03 HEADLIGHT LH (F) 	E-04 HEADLIGHT RH (F) 	E-05 HING LIGHT NO. 1 (F) <table border="1"><tr><td>L</td><td>R/W</td></tr><tr><td>*</td><td>B</td></tr></table>	L	R/W	*	B	E-10 POSITION LIGHT LH (F) 
G/O	R/Y	*													
R/B	Y	R/W													
L	R/W														
*	B														
E-11 POSITION LIGHT RH (F) 															

E-1






E-2





E-3 EXCEPT F.R.GERMANY ■ TAILLIGHTS ■ LICENSE PLATE LIGHTS



E-01 COMBINATION SWITCH (F)	E-02 COMBINATION SWITCH (F)	E-12 TAILLIGHT LH (R)	E-13 TAILLIGHT RH (R)	E-14 LICENSE PLATE LIGHT (R)	E-15 RUNNING LIGHT RELAY NO. 2 (F)
W/B R	G/O R/Y * R/B Y R/W	* R/G G/B B L/Y G	* R/G G/W B W G	B W	B/R L/Y L R/B * B



E-3






E-01 COMBINATION SWITCH (F)	E-02 COMBINATION SWITCH (F)	E-10 POSITION LIGHT LH (F)	E-11 POSITION LIGHT RH (F)	E-12 TAILLIGHT LH (R)	E-13 TAILLIGHT RH (R)	E-14 LICENSE PLATE LIGHT (R)

E-4




FUSE BOX



X-01 FUSE BOX

X-01 MAIN FUSE


JOINT BOX




JB-04


JB-05

JB-07






E-5




F-1 ■ TURN & HAZARD FLASHER LIGHTS








F-01 TURN SWITCH (F) <table><tr><td>Y</td><td>*</td><td>*</td><td>*</td></tr><tr><td>B/Y</td><td>G</td><td>*</td><td>*</td></tr></table>	Y	*	*	*	B/Y	G	*	*	F-02 FLASHER UNIT (F) <table><tr><td>G/W</td><td>G</td><td>O</td><td>B</td></tr><tr><td>B/R (B/L)</td><td>Y</td><td>G/B</td><td>*</td></tr></table>	G/W	G	O	B	B/R (B/L)	Y	G/B	*	F-03 HAZARD SWITCH (I) <table><tr><td>*</td><td>*</td><td></td><td>O</td><td>B</td></tr><tr><td>*</td><td>*</td><td>R/B</td><td>R</td><td>*</td><td>G/W</td></tr></table>	*	*		O	B	*	*	R/B	R	*	G/W	F-04 FRONT SIDE TURN LIGHT LH (F) <table><tr><td>B</td></tr><tr><td>G/B</td></tr></table>	B	G/B	F-05 FRONT SIDE TURN LIGHT RH (F) <table><tr><td>B</td></tr><tr><td>G/W</td></tr></table>	B	G/W	E-10 FRONT TURN LIGHT LH (F) <table><tr><td>R/B</td><td>B</td><td>G/B</td></tr></table>	R/B	B	G/B
Y	*	*	*																																				
B/Y	G	*	*																																				
G/W	G	O	B																																				
B/R (B/L)	Y	G/B	*																																				
*	*		O	B																																			
*	*	R/B	R	*	G/W																																		
B																																							
G/B																																							
B																																							
G/W																																							
R/B	B	G/B																																					
E-11 FRONT TURN LIGHT RH (F) <table><tr><td>R/B</td><td>B</td><td>G/W</td></tr></table>	R/B	B	G/W	E-12 REAR TURN LIGHT LH (R) <table><tr><td>*</td><td>R/G</td><td>G/B</td></tr><tr><td>B</td><td>L/Y</td><td>G</td></tr></table>	*	R/G	G/B	B	L/Y	G	E-13 REAR TURN LIGHT RH (R) <table><tr><td>*</td><td>R/G</td><td>G/W</td></tr><tr><td>B</td><td>W</td><td>G</td></tr></table>	*	R/G	G/W	B	W	G																						
R/B	B	G/W																																					
*	R/G	G/B																																					
B	L/Y	G																																					
*	R/G	G/W																																					
B	W	G																																					

F-1




- **STOPLIGHTS**




F-06 STOPLIGHT SWITCH (F)	F-07 STOPLIGHT CHECKER (F)	E-12 STOPLIGHT LH (R)	E-13 STOPLIGHT RH (R)
			

F-2




F-3




F-4 • HORNS • BACK-UP LIGHTS

() . . . F.R.GERMANY




F-08 HORN RELAY (F)	F-09 HORN LH (F)	F-10 HORN RH (F)	F-11 BACK-UP LIGHT SWITCH (EM)
<div> <div>G/R</div> <div>G/O</div> <div>G/W</div> <div>G/W (B/R)</div> <div>(B/R)</div> </div>	<div> <div>G/R</div> <div></div> </div>	<div> <div>G/R</div> <div></div> </div>	<div> <div>B/Y</div> <div>*</div> <div>R/G</div> <div>*</div> </div>
E-02 HORN SWITCH (F)	E-12 BACK-UP LIGHT LH (R)	E-13 BACK-UP LIGHT RH (R)	
<div> <div>G/O</div> <div>R/Y</div> <div>*</div> <div>R/B</div> <div>Y</div> <div>(R)</div> <div>(W/B)</div> <div>(R)</div> <div>R/W</div> </div>	<div> <div>*</div> <div>R/G</div> <div>G/B</div> <div>B</div> <div>L/Y</div> <div>G</div> </div>	<div> <div>*</div> <div>R/G</div> <div>G/W</div> <div>B</div> <div>W</div> <div>G</div> </div>	

F-4




G

HEATER




G-01 BLOWER MOTOR (F)	G-02 RESISTOR ASSEMBLY (I)	G-03 BLOWER SWITCH (I)	
L/W	L/R L/Y L/W L	L L/Y X O/L R R/B L/W L/R B	

G



JOINT BOX




G-02
RESISTOR
ASSEMBLY


G-03
BLOWER
SWITCH

JB-06

JB-04




JOINT BOX




FUSE BOX
X-01

FUSE BOX




FUSE BOX
X-01

X-01
MAIN FUSE



I-01 REAR WINDOW DEFROSTER SWITCH (I)



I-02 REAR WINDOW DEFROSTER (R3)



I-03 CIGARETTE LIGHTER (I)




I-04 DIGITAL CLOCK (I)




I-18 REAR WINDOW DEFROSTER RELAY (F)



E-17 FUSE (F)




I-19 FUSE (F)




- ① HEAD CLEANER 30A (DIM. LH 10A)
 (DIM. RH 10A)
 ② *
 ③ DEFROG 20A (MAIN. LH 10A)
 ④ F.F.DG 15A (MAIN. RH 10A)
 (R. FOG 10A)
 (F. FOG 15A)
 ⑤ *
 ⑥ *

I-1







I-2 ■ INTERIOR & SPOT LAMPS ■ SOUND WARNING SYSTEM ■ IG KEY CYLINDER LAMP







I-05 IG KEY CYLINDER LAMP (F) 	I-06 INTERIOR & SPOT LAMP (IN) WITHOUT SUNROOF WITH SUNROOF	I-07 DOOR SWITCH LH (R) 	I-08 DOOR SWITCH RH (R) 	M-01 SPOT LAMP (IN) 	M-02 SLIDING SUNROOF SWITCH
M-03 SLIDING SUNROOF MOTOR 					

I-2




- TRUNK COMPARTMENT LAMP
- COURTESY LAMPS





<p>I-11 TRUNK COMPARTMENT LAMP (R3)</p> 	<p>I-16 COURTESY LAMP LH (DR1)</p> 	<p>I-17 COURTESY LAMP RH (DR2)</p> 	

I-3

FUSE BOX




JOINT BOX






I-4 ■ ILLUMINATION LAMPS


() ... F. R. GERMANY
* ... ABS




<div>I-01 REAR WINDOW DEFROSTER SWITCH (I)</div> <div><table><tr><td>*</td><td>B/W</td><td>R/B</td></tr><tr><td>B</td><td>B/Y</td><td>R</td></tr></table></div>	*	B/W	R/B	B	B/Y	R	<div>I-14 PANEL LIGHT CONTROL (I)</div> <div><table><tr><td>B</td><td></td><td>R</td></tr><tr><td>*</td><td>*</td><td>R/B</td></tr></table></div>	B		R	*	*	R/B	<div>I-15 CIGARETTE LIGHTER (I)</div> <div><table><tr><td>R/B</td><td>R</td></tr></table></div>	R/B	R	<div>C-01 INSTRUMENT CLUSTER (F)</div> <div><table><tr><td>*</td><td>*</td><td>W</td><td></td><td>W/R</td><td>G/W</td><td>G/Y</td><td>Y</td><td>R</td><td>R/B</td></tr></table></div>	*	*	W		W/R	G/W	G/Y	Y	R	R/B	<div>D-05 HEADLIGHT CLEANER SWITCH (I)</div> <div><table><tr><td>*</td><td></td><td>R/B</td></tr><tr><td>*</td><td>Y/W</td><td>B</td></tr></table></div>	*		R/B	*	Y/W	B	<div>E-01 COMBINATION SWITCH (F)</div> <div><table><tr><td>W/B</td><td>R</td></tr><tr><td>(R)</td><td>(R)</td></tr></table></div>	W/B	R	(R)	(R)																	
*	B/W	R/B																																																						
B	B/Y	R																																																						
B		R																																																						
*	*	R/B																																																						
R/B	R																																																							
*	*	W		W/R	G/W	G/Y	Y	R	R/B																																															
*		R/B																																																						
*	Y/W	B																																																						
W/B	R																																																							
(R)	(R)																																																							
<div>E-02 COMBINATION SWITCH (F)</div> <div><table><tr><td>G/O</td><td></td><td>*</td></tr><tr><td>R/B</td><td>Y</td><td>R/W</td></tr><tr><td>(W/B)</td><td>(R)</td><td></td></tr></table></div>	G/O		*	R/B	Y	R/W	(W/B)	(R)		<div>E-09 HEADLIGHT LEVELING SWITCH (I)</div> <div><table><tr><td>*</td><td></td><td>B</td><td>R/B</td></tr><tr><td>*</td><td>*</td><td>*</td><td>G</td></tr></table></div>	*		B	R/B	*	*	*	G	<div>E-20 REAR FOG LIGHT SWITCH (I)</div> <div><table><tr><td>*</td><td>B</td><td>R/B</td></tr><tr><td>*</td><td>Y</td><td>R</td></tr></table></div>	*	B	R/B	*	Y	R	<div>E-27 FRONT FOG LIGHT SWITCH (I)</div> <div><table><tr><td>*</td><td></td><td>G/Y</td></tr><tr><td>R/B</td><td>B</td><td>R/B</td></tr></table></div>	*		G/Y	R/B	B	R/B	<div>F-03 HAZARD SWITCH (I)</div> <div><table><tr><td>*</td><td>*</td><td></td><td>O</td><td>B</td></tr><tr><td>*</td><td>*</td><td>R/B</td><td>R</td><td>G/W</td></tr></table></div>	*	*		O	B	*	*	R/B	R	G/W	<div>G-03 BLOWER SWITCH (I)</div> <div><table><tr><td>L</td><td>L/Y</td><td></td><td>G/L</td><td>R</td><td>R/B</td></tr><tr><td>L/W</td><td></td><td>L/R</td><td></td><td>B</td><td></td></tr></table></div>	L	L/Y		G/L	R	R/B	L/W		L/R		B	
G/O		*																																																						
R/B	Y	R/W																																																						
(W/B)	(R)																																																							
*		B	R/B																																																					
*	*	*	G																																																					
*	B	R/B																																																						
*	Y	R																																																						
*		G/Y																																																						
R/B	B	R/B																																																						
*	*		O	B																																																				
*	*	R/B	R	G/W																																																				
L	L/Y		G/L	R	R/B																																																			
L/W		L/R		B																																																				
<div>J-01 AUDIO SYSTEM (I)</div> <div><table><tr><td>L</td><td>V</td><td></td><td>R/R</td><td>L/R</td><td>L/B</td></tr><tr><td>W</td><td>L/O</td><td>*</td><td>*</td><td>*</td><td>*</td></tr></table></div>	L	V		R/R	L/R	L/B	W	L/O	*	*	*	*	<div>P-02 SEAT WARMER SWITCH LH (R)</div> <div><table><tr><td>R/B</td><td>R</td><td>G/Y</td><td>*</td><td>L/R</td><td>B</td></tr></table></div>	R/B	R	G/Y	*	L/R	B	<div>P-03 SEAT WARMER SWITCH RH (R)</div> <div><table><tr><td>R/B</td><td></td><td>L/R</td></tr><tr><td>R</td><td>G</td><td>B</td></tr></table></div>	R/B		L/R	R	G	B																														
L	V		R/R	L/R	L/B																																																			
W	L/O	*	*	*	*																																																			
R/B	R	G/Y	*	L/R	B																																																			
R/B		L/R																																																						
R	G	B																																																						

I-4





J-01 AUDIO SYSTEM (I)




J-02 DOOR SPEAKER LH (DR1)




J-03 DOOR SPEAKER RH (DR2)




J-04 REAR SPEAKER CORD (R)



J-05 AUDIO SYSTEM








J-06 REAR SPEAKER LH (R)




J-07 REAR SPEAKER RH (R)



J







K-1 ■ POWER WINDOWS




K-01 POWER WINDOW MAIN SWITCH (DR1)		K-02 POWER WINDOW MOTOR LH (DR1)		K-03 POWER WINDOW SWITCH RH (DR2)		K-04 POWER WINDOW MOTOR RH (DR2)	
<div><div>R/G</div><div>B</div><div>R/W</div><div>R/B</div><div>B/W</div><div>B/L</div><div>G/W</div></div>		<div><div>R/B</div><div>R/G</div></div>		<div><div>R</div><div>G/W</div><div>R/W</div><div>*</div><div>G</div><div>B/L</div></div>		<div><div>R</div><div>G</div></div>	

K-1




K-2 ■ POWER DOOR LOCK



K-09 POWER DOOR LOCK SWITCH (DR1)







K-10 POWER DOOR LOCK TIMER UNIT (F)



K-11 POWER DOOR LOCK ACTUATOR (DR2)




K-2



L

■ POWER OUTSIDE MIRRORS



L-01 POWER OUTSIDE MIRROR SWITCH (I)

BR	L/B		LG/B	LG
B	*	*	*	BR/Y

L-02 DR1-MIRROR (DR1)

LG	BR
BR/Y	*

L-03 POWER OUTSIDE MIRROR MOTOR LH

Y	BR
B	*






L-04 DR2-MIRROR (DR2)


LG/B	BR
BR/B	*

L-05 POWER OUTSIDE MIRROR MOTOR RH

Y	BR
B	*





L






M-01 SLIDING SUNROOF (IN)	M-02 SLIDING SUNROOF SWITCH	M-03 SLIDING SUNROOF MOTOR	M-04 SLIDING SUNROOF RELAY
<div><div>G/O</div><div>L/R</div></div>	<div><div>L/G</div><div>L/W</div><div>G</div><div>B</div><div>L</div><div>L/Y</div></div>	<div><div>Y</div><div><div></div></div><div>L/Y</div><div>L/G</div><div>Y/R</div><div>B</div><div>L</div><div>L/G</div><div>L/W</div></div>	<div><div>Y/R</div><div><div></div></div><div>G</div><div>Y</div><div>L/G</div><div>B</div><div>G</div><div>G</div><div>L</div></div>

M



0 ■ ANTI-LOCK BRAKE SYSTEM (ABS)



0-01 ABS CONTROL UNIT (FR)

B ¹	L ²	G ³	*	*	*	*	G/B ⁸	*	*	*	*	*	*	*	*	*	*	*	*	*	B ²⁰
Y ²¹	L/G ²²	*	*	*	*	L/W ²⁴	G/O ²⁵	B/O ²⁶	B/L ²⁷	B/R ²⁸	B/W ²⁹	*	*	W/G ³⁰	G ³¹	L/B ³²	*	*	L/O ³³	*	
R ³⁴	Y/R ³⁵	*	*	*	*	G/R ³⁷	L/R ³⁸	R/L ³⁹	O ⁴⁰	O/W ⁴¹	*	*	*	Y/B ⁴³	G/W ⁴⁴	B/Y ⁴⁵	Y/W ⁴⁶	*	*	*	


0-05 ABS MOTOR (F)



0-06 HYDRAULIC UNIT NO. 1 (EM)



0-07 HYDRAULIC UNIT NO. 2 (F)



0-08 HYDRAULIC UNIT NO. 3 (F)




0-02 G SENSOR (FR)




0-03 ABS MAIN RELAY (F)



0-04 ABS MOTOR RELAY (F)



0-12 ABS WHEEL SPEED SENSOR RR (R)




0-09 ABS WHEEL SPEED SENSOR FL (F)




0-10 ABS WHEEL SPEED SENSOR FR (F)



0-11 ABS WHEEL SPEED SENSOR RL (R)



0



A




P-01 SEAT WARMER
RELAY (F)

L/R	B	P
	L/G	


P-02 SEAT WARMER SWITCH LH (R)

R/B	R	G/Y	*	L/R	B
-----	---	-----	---	-----	---

P-03 SEAT WARMER
SWITCH RH (R)

R/B			L/R
R	G	*	B

P-04 SEAT WARMER LH (R)





G/Y



B


P-05 SEAT WARMER RH (R)

P





JOINT BOX






U-01 DIAGNOSIS CONNECTOR (EM)



NOTE: THIS IS THE CONNECTOR AS SEEN FROM THE TERMINAL SIDE.

U




This page left intentionally blank

X

X-1 ■ COMMON CONNECTOR LIST (1/2)


★ ... ABS
() ... F.R.GERMANY

X-01 MAIN FUSE




- ① FUEL INJ
- ② HEAD (HAZARD)
- ③ MAIN
- ④ STN
- ⑤ ABS
- ⑥ COOLING FAN
- ⑦ AD FAN
- ⑧ (STOP)
- ⑨ ST SIGN
- ⑩ ABS VALVE


MAIN FUSE (E)




FUSE BOX (F)




X-02 IGNITION SWITCH (F)



X-04 FRONT (F) - EMISSION (EM)



X-03 FRONT (F) - EMISSION (EM)




X-05 FRONT (F) - INSTRUMENT PANEL (I)




X-06 FRONT (F) - REAR (R)



X-08 FRONT (F) - DOOR NO. 1 (DR1)




X-09 FRONT (F) - DOOR NO. 2 (DR2)




X-10 REAR (R) - REAR NO. 2 (R2)




X-11 REAR NO. 2 (R2) - REAR NO. 3 (R3)




X-14 EMISSION (EM) - INJECTOR (INJ)




X-15 FRONT (F) - ENGINE (E)




X-16 FRONT (F) - ENGINE (E)




X-17 ENGINE (E) - EMISSION (EM)




X-18 JOINT CONNECTOR (F)



X-21 JOINT CONNECTOR (I)



X-26 FRONT (F) - INSTRUMENT PANEL (I)



X-2 ■ COMMON CONNECTOR LIST (2/2)

X-28 REAR (R) -FLOOR (FR)

(R)		(FR)	
R/L	W	L/R	R/L
B/L	B/O	B/O	B/L

X-29 FRONT (F) -FLOOR (FR)

(F)							
O/W	*	*		G/B	G/W	B/W	
B/W	*		G	W	Y/B	W/G	
*		L/B	*		B		

(FR)

B/Y	G/W	G/B		*	*	O/W	
W/G	Y/B		W	G	*	B/W	
B		*	L/B	*			


X-30 FRONT (F) -FLOOR (FR)


(F)			
Y/R	L/G	Y	O
*	L	L/O	R

(FR)

O	Y		L/G	Y/R
B/R	Y/W	R	L/O	L

JB





- | | | | |
|---|-------------|------------------|------|
| ① | REAR WIPER | 15A | |
| ② | HAZARD | 15A (HORN | 10A) |
| ③ | ROOM | 10A | |
| ④ | ENGINE | 15A | |
| ⑤ | RADIO | 15A | |
| ⑥ | DOOR LOCK | 30A | |
| ⑦ | SEAT WARMER | 15A (TAIL RH | 10A) |
| ⑧ | POWER WIND | 30A | |
| ⑨ | METER | 15A | |
| ⑩ | WIPER | 20A | |
| ⑪ | STOP | 10A (SEAT WARMER | 15A) |
| ⑫ | TAIL | 15A (TAIL LH | 10A) |
| ⑬ | SUN ROOF | 15A | |
| ⑭ | ABS | 10A | |
| ⑮ | FUEL | 20A | |
| ⑯ | HEATER | 30A | |

JB-01 INTERIOR LAMP HARNESS

G/O	R/W	L/R
C	B	A

JB-02 INSTRUMENT PANEL HARNESS

J	I	G	E	C	A
L/R	R/B	B/Y		*	*
*		*	G	L/B	*
K	H	F	D	B	

JB-03 REAR HARNESS

N	L	K	I	G	E	C	A
*	*	L/G	G/B	*	R/B	*	*
G/W	B/Y	*	*	*	*	L/R	R/W
D	M	J	H	F	O	B	

JB-04 FRONT HARNESS

L	K	I	G	E	C	A
R/B	R/B (*)	*	B/Y	G/W	B/W	G/B
B/W	W/B (R/B)	L/W	L	*	*	*
H	J	H	F	O	B	

JB-05 FRONT HARNESS

E	C	A
W/G	B/W	*
W/R	W/B (P)	G/W
F	D	B

JB-06 FRONT HARNESS

C	B	A
B/R	B/W	L

JB-07 FRONT HARNESS

S	B	D	M	G	E	C	A
B/G	*	G/W	B/Y	*	R/B	L/R	L/R
B/R	L/G	G/B	B/W	*	*	L/O	P (L/B)
T	R	P	N	L	J	H	F

JB-08 FRONT HARNESS

V	B	*	*	*	O	L/B	*
H	G	F	E	D	C	B	A

JB-09 CPU

P	O	N	M	L	K	J	I	H	G	F	E	D	C	B	A
---	---	---	---	---	---	---	---	---	---	---	---	---	---	---	---




01/01/2011

01/01/2011

01/01/2011

PL

PL



PARTS INDEX

PARTS NAME	PAGE	PARTS NAME	PAGE
A ABS CONTROL UNIT.....	82	K KNOCK CONTROL UNIT.....	30
ABS MAIN RELAY.....	82	KNOCK SENSOR.....	30
ABS MOTOR RELAY.....	82	L LICENSE PLATE LIGHT.....	48, 50
ABS MOTOR.....	82	M MAIN RELAY (FUEL INJ).....	28
ABS WHEEL SPEED SENSOR.....	82	N NEUTRAL SWITCH.....	32
AIRFLOW METER.....	32	O OIL PRESSURE SWITCH.....	38
ALTERNATOR.....	26	OXYGEN SENSOR.....	28
AUDIO SYSTEM.....	72	P PANEL LIGHT CONTROL.....	70
B BACK-UP LIGHT SWITCH.....	60	PARKING BRAKE SWITCH.....	38
BACK-UP LIGHT.....	60	POSITION LIGHT.....	44, 50
BLOWER MOTOR.....	62	POWER DOOR LOCK SWITCH.....	76
BLOWER SWITCH.....	62	POWER DOOR LOCK TIMER UNIT.....	76
BRAKE FLUID SWITCH.....	38	POWER DOOR LOCK ACTUATOR.....	76
C CIGARETTE LIGHTER.....	64	POWER OUTSIDE MIRROR MOTOR.....	78
CIRCUIT OPENING RELAY.....	28	POWER OUTSIDE MIRROR SWITCH.....	78
CLUTCH SWITCH.....	32	POWER STEERING PRESSURE SWITCH.....	32
COMBINATION SWITCH.....	44, 46, 48, 50, 52, 70	POWER WINDOW MAIN SWITCH.....	74
CONDENSER.....	28	POWER WINDOW MOTOR.....	74
COOLING FAN MOTOR.....	36	POWER WINDOW SWITCH.....	74
COOLING FAN RELAY.....	36	R REAR FOG LIGHT RELAY.....	52
COURTESY LAMP.....	68	REAR FOG LIGHT SWITCH.....	52
CPU.....	42, 66	REAR FOG LIGHT.....	52
D DIAGNOSIS CONNECTOR.....	86	REAR SPEAKER.....	72
DIGITAL CLOCK.....	64	REAR TURN LIGHT.....	54
DIODE.....	52	REAR WASHER MOTOR.....	42
DISTRIBUTOR.....	30	REAR WASHER SWITCH.....	42
DOOR SPEAKER.....	72	REAR WINDOW DEFROSTER.....	64
DOOR SWITCH.....	66	REAR WINDOW DEFROSTER RELAY.....	64
E ENGINE CONTROL UNIT.....	28, 30, 32	REAR WINDOW DEFROSTER SWITCH.....	64
F FLASHER UNIT.....	54	REAR WIPER MOTOR.....	42
FRONT FOG LIGHT RELAY.....	52	REAR WIPER SWITCH.....	42
FRONT FOG LIGHT SWITCH.....	52	RESISTOR ASSEMBLY.....	62
FRONT FOG LIGHT.....	52	RUNNING LIGHT RELAY.....	44, 48
FRONT SIDE TURN LIGHT.....	54	S SEAT WARMER.....	84
FRONT TURN LIGHT.....	54	SEAT WARMER REALY.....	84
FUEL METER.....	38	SEAT WARMER SWITCH.....	84
FUEL PUMP REALY.....	28	SHORT CONNECTOR.....	36
FUEL PUMP UNIT.....	28	SLIDING SUNROOF MOTOR.....	66, 80
FUEL PUMP.....	28	SLIDING SUNROOF RELAY.....	80
FUSE.....	40, 46, 52, 64	SLIDING SUNROOF SWITCH.....	66, 80
G G SENSOR.....	82	SLIDING SUNROOF.....	80
H HAZARD SWITCH.....	54	SOLENOID RESISTOR.....	30
HEADLIGHT CLEANER MOTOR.....	40	SOLENOID VALVES	
HEADLIGHT CLEANER SWITCH.....	40	PRC HIGH TEMP.....	30
HEADLIGHT LEVELING ACTUATOR.....	46	PRC LOW TEMP.....	30
HEADLIGHT LEVELING SWITCH.....	46	PURGE CONTROL.....	30
HEADLIGHT RELAY.....	44	WASTEGATE.....	30
HEADLIGHT.....	44, 46	SPEED SENSOR.....	38
HORN RELAY.....	60	SPOT LAMP.....	66
HORN SWITCH.....	60	STARTER.....	24
HORN.....	60	STOPLIGHT CHECKER.....	56, 58
HYDRAULIC UNIT.....	82	STOPLIGHT SWITCH.....	56, 58
I IC REGURATOR.....	26	STOPLIGHT.....	56, 58
IG KEY CYLINDER LAMP.....	66	T TACHOMETER.....	38
IGNITER.....	28	TAILLIGHT.....	48, 50
IGNITION COIL.....	28	TEMP METER.....	38
ILLUMINATION LAMP.....	70	THROTTLE SENSOR.....	32
AUDIO SYSTEM.....	70	TRANSFER PUMP.....	28
BLOWER SWITCH.....	70	TRUNK COMPARTMENT LAMP SWITCH.....	68
CIGARETTE LIGHTER.....	70	TRUNK COMPARTMENT LAMP.....	68
FRONT FOG LIGHT SWITCH.....	70	TURN SWITCH.....	54
HAZARD SWITCH.....	70	W WARNING LAMP.....	38
HEADLIGHT CLEANER SWITCH.....	70	WASHER LEVEL SENSOR.....	38
HEADLIGHT LEVELING SWITCH.....	70	WATER THERMOSENSOR.....	30, 38
INSTRUMENT CLUSTER.....	70	WATER THERMOSWITCH.....	36
REAR FOG LIGHT SWITCH.....	70	WINDSHIELD WASHER MOTOR.....	40
REAR WINDOW DEFROSTER SWITCH.....	70	WINDSHIELD WASHER SWITCH.....	40
SEAT WARMER SWITCH.....	70	WINDSHIELD WIPER MOTOR.....	40
INDICATOR LAMP.....	38	WINDSHIELD WIPER SWITCH.....	40
INJECTOR.....	30		
INJECTOR RESISTOR.....	30		
INSTRUMENT CLUSTER.....	38		
INTERIOR LAMP.....	66		
ISC VALVE.....	30		

© 1992 Mazda Motor Corporation

Printed in Japan

5232-10-92A